




Model 200

Announcer's Console




Configuration Guide



Model 200 configuration settings label as affixed to security plate
Actual size 4.25" x 2.50"
Cut along lines for use as a spare

Model 200 Bottom Panel



**Settings
Detailed Below**

Mic Preamp Gain



20 dB



30 dB



40 dB



50 dB




60 dB




0 dB (no gain) Factory use only!

Phantom Power (48 V)



Off



On

Spares

