



# Model 371 Intercom Beltpack

## Configuration Guide

This Configuration Guide is applicable for the following serial numbers: M371-00151 and later with application firmware 1.2 and later and Dante firmware 1.2.0 (UltimoX2 3.10.3.1) and later



### SW1 – Mic Preamp Gain



40 dB



46 dB

### SW2 – Channel 1 Talk Button Mode



Push to Talk



Push to Talk / Tap to Latch

### SW3 – Channel 2 Talk Button Mode



Push to Talk



Push to Talk / Tap to Latch

### SW4 & SW5 – Not used



## Headset Connector Pinout

