



Replacement Parts List

All prices effective June 1, 2018. Subject to change without notice.

Parts availability subject to factory stock levels. Certain parts may become obsolete without notice.

Table of Contents

Model 2 Central Controller (all S/N)	3
Model 2A Central Controller (all S/N)	3
Model 22 Access Station (all S/N)	3
Model 24 Access Station (all S/N)	3
Model 32 Talent Amplifier (S/N 00001 – 00299)	4
Model 32 Talent Amplifier (S/N 00300 and later)	4
Model 32A Talent Amplifier (all S/N)	4
Model 33 Talent Amplifier (all S/N)	5
Model 33A Talent Amplifier (all S/N)	5
Model 34 Talent Amplifiers (all S/N)	5
Model 35 Talent Amplifier (S/N 00001 – 00385)	6
Model 35 Talent Amplifier (S/N 00386 and later)	6
Model 36 Talent Interface (all S/N)	6
Model 37 Intercom Beltpack (all S/N)	7
Model 41 Interface (S/N 00151 – 01050)	7
Model 41 Interface (S/N 01051 and later)	7
Model 42A Interface (all S/N)	7
Model 43D IFB Interface (all S/N)	8
Model 44D Audio Interface (all S/N)	8
Model 45 Interface (all S/N)	8
Model 45A Interface (all S/N)	8
Model 45DC Intercom Interface (all S/N)	8
Model 45DR Intercom Interface (all S/N)	8
Model 46 Interface (all S/N)	9
Model 46A Interface (all S/N)	9
Model 47 Interface (all S/N)	9
Model 47A Interface (all S/N)	9
Model 48D Dante Bridge (all S/N)	9
Model 72 Level Meter / Interface (all S/N)	9
Model 51 Control Console (all S/N)	10
Model 56 Control Console (all S/N)	10
Models 59 & 591 Control Console (all S/N)	10
Model 60 Central Controller (S/N 00200 – 00300)	11
Model 60 Central Controller (S/N 00301 and later)	11
Model 60A Central Controller (all S/N)	11

Table of Contents, continued

Model 61 Control Console (all S/N)	12
Model 69 Control Console (all S/N)	12
Model 69A Control Console (all S/N)	12
Model 71 Control Console (all S/N)	12
Model 74 Central Controller (all S/N)	12
Model 75 Control Console (all S/N)	13
Model 77 Control Console (all S/N)	13
Model 77B Control Console (all S/N)	13
Model 79 Control Console (all S/N)	13
Model 790 Control Console (all S/N)	13
Model 92 DT12 Cable Assembly Test Unit (all S/N)	14
Model 93 W1 Cable Assembly Test Unit (all S/N)	14
Model 200-Series Announcer's and Producer's Consoles (all S/N).	15
Models 204, 205 & 206 Announcer's Consoles (all S/N).	15
Model 208 Announcer's Console (all S/N)	16
Model 362 Listen-Only Beltpack (all S/N)	16
Model 370 Intercom Beltpack (all S/N)	17
Model 370A Intercom Beltpack (all S/N)	17
Model 371 Intercom Beltpack (all S/N)	18
Model 371A Intercom Beltpack (all S/N)	18
Model 374 Intercom Beltpack (all S/N)	19
Model 374A Intercom Beltpack (all S/N)	19
Model 380 On-Air Beltpack (all S/N)	20
Model 391 Dante Alerting Unit (all S/N)	20
Model 400 SDI-Over-Fiber Transport Systems (all S/N)	21
Model 410 SDI-Over-Fiber Transport Systems (all S/N)	21
Model 412 Fiber Transport Systems (all S/N)	21
Model 742 Audio Mixer (all S/N)	22
Model 742A Audio Mixer (all S/N)	22
Model 5100-Series Broadcast Support Modules (all S/N)	22
Model 5202 Dante to Phones and Line Output Interface (all S/N)	23
Model 5204 Dual Line Input to Dante Interface (all S/N)	23
Model 5330 Flex-Use Dante Audio Interface (all S/N)	23
Model 5401 Dante Master Clock (all S/N)	23
Model 5414 Mic/Line Input & Line Output Interface (all S/N)	24
Model 5415 & MD-4 Mic/Line Input & Line Output Interface (all S/N)	24
Model 5422-Series Dante Audio Intercom Engines (all S/N)	24
Live-Link Remote Camera Interface Systems (all S/N)	25
Live-Link Jr. Remote Camera Interface Systems (all S/N)	25
Live-Link Mini Remote Camera Interface Systems (all S/N)	25
Miscellaneous Parts	26

	Qty	US List Price	Total
Model 2 Central Controller (all Serial Numbers)			
Knob – Program and Monitor Output (black, push-on, 15 mm) (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
Knob Cap – Program and Monitor Output (black w/white line, 15 mm) (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
Pushbutton Cap (gray) (Order Code: 12050; Mfg No.: E-Switch TACGRY; Digi-Key No.: EG1082-ND)	_____	\$ 4.00	_____
Potentiometer – Program 1, Program 2, Monitor Output (Order Code: 2126)	_____	\$ 4.00	_____
Pushbutton Switch (momentary) – IFB 1, IFB 2 (Order Code: 12064)	_____	\$ 4.00	_____
Pushbutton Switch Assembly (6-position, interlock) – Program Select (Order Code: 12036)	_____	\$12.00	_____
Toggle Switch – VOX IFB Input Select (Order Code: 12054)	_____	\$26.00	_____
Toggle Switch – VOX IFB Output Select (Order Code: 12052)	_____	\$22.00	_____
Toggle Switch (momentary) – Telco 1, Telco 2, Manual Off-Hook/Hang-Up Select (Order Code: 12053)	_____	\$22.00	_____
Toggle Switch – Telco 2 Send/Rcv and Monitor Source Select (Order Code: 12051)	_____	\$22.00	_____
Pushbutton Switch (push-push) – Telco Std/Wet 1, Telco Std/Wet 2 (Order Code: 12016)	_____	\$ 3.00	_____

Model 2A Central Controller (all Serial Numbers)			
Knob – Program and Monitor Output (black, push-on, 15 mm) (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
Knob Cap – Program and Monitor Output (black w/white line, 15 mm) (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
Pushbutton Cap (gray) (Order Code: 12050; Mfg No.: E-Switch TACGRY; Digi-Key No.: EG1082-ND)	_____	\$ 4.00	_____
Potentiometer – Program 1, Program 2, Monitor Output (Order Code: 2126)	_____	\$ 4.00	_____
Pushbutton Switch (momentary) – IFB 1, IFB 2 (Order Code: 12064)	_____	\$ 4.00	_____
Pushbutton Switch Assembly (6-position, interlock) – Program Select Order Code: 12036)	_____	\$12.00	_____
Toggle Switch (momentary) – Telco 1, Telco 2, Manual Off-Hook/Hang Up Select (Order Code: 12093)	_____	\$ 9.00	_____
Toggle Switch – VOX IFB, Telco 2 Send/Rcv, Monitor Source Select (Order Code: 12091)	_____	\$ 9.00	_____
Pushbutton Switch (push-push) – Telco Std/Wet 1, Telco Std/Wet 2 (Order Code: 12016)	_____	\$ 3.00	_____

Model 22 Access Station (all Serial Numbers)			
Button Cap, Lenses, and Label 15154 Kit (includes five each button caps, clear lens, frosted lens, and one set of button function labels) (Order Code: 31069)	_____	\$40.00	_____
Backlight Lamp (T1, 18 V) (Order Code: 12030)	_____	\$ 4.00	_____

Model 24 Access Station (all Serial Numbers)			
Button Cap, Lenses, and Label 15154 Kit (includes five each button caps, clear lens, frosted lens, and one set of button function labels) (Order Code: 31069)	_____	\$40.00	_____
Backlight Lamp (T1, 18 V) (Order Code: 12030)	_____	\$ 4.00	_____

	Qty	US List Price	Total
Model 32 Talent Amplifier (Serial Numbers 00001 – 00299)			
Knob (black, push-on, 15 mm) (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
Knob Cap (black w/white line, 15 mm) (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
Potentiometer (Order Code: 2148)	_____	\$ 4.00	_____
Toggle Switch – Ch 1/2 Select (Order Code: 12021)	_____	\$ 6.00	_____
3-Pin Male XLR Connector (Order Code: 1093)	_____	\$ 7.00	_____
3-Pin Female XLR Connector (Order Code: 1094)	_____	\$ 8.00	_____
1/4" Phone Jack (Order Code: 1053)	_____	\$ 7.00	_____

Model 32 Talent Amplifier (Serial Numbers 00300 and later)

Knob (black, push-on, 15 mm) (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
Knob Cap (black w/white line, 15 mm) (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
Potentiometer (Order Code: 2148)	_____	\$ 4.00	_____
Toggle Switch – Ch 1/2 Select (Order Code: 12021)	_____	\$ 6.00	_____
3-Pin Male XLR Connector (Order Code: 1093)	_____	\$ 7.00	_____
3-Pin Female XLR Connector (Order Code: 1094)	_____	\$ 8.00	_____
1/4" Phone Jack (Order Code: 1086)	_____	\$ 4.00	_____

Model 32A Talent Amplifier (all Serial Numbers)

Knob (black, push-on, 15 mm) (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
Knob Cap (black w/white line, 15 mm) (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
Potentiometer (Order Code: 2148)	_____	\$ 4.00	_____
Toggle Switch – Ch 1/2 Select (Order Code: 12021)	_____	\$ 6.00	_____
3-Pin Male XLR Connector (Order Code: 1093)	_____	\$ 7.00	_____
3-Pin Female XLR Connector (Order Code: 1094)	_____	\$ 8.00	_____
1/4" Phone Jack (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
Nut (plastic) (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
3.5 mm Stereo Jack (Order Code: 1198)	_____	\$ 3.00	_____

	Qty	US List Price	Total
Model 33 Talent Amplifier (all Serial Numbers)			
Knob – Ch 1 and Ch 2 (black, push-on, 15 mm) (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
Knob Cap – Ch 1 and Ch 2 (black w/white line, 15 mm) (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
Potentiometer – Ch 1 and Ch 2 (Order Code: 2148)	_____	\$ 4.00	_____
Toggle Switch – Ch 1/2 Select (Order Code: 12063)	_____	\$ 9.00	_____
3-Pin Male XLR Connector (Order Code: 1093)	_____	\$ 7.00	_____
3-Pin Female XLR Connector (Order Code: 1094)	_____	\$ 8.00	_____
1/4" Phone Jack (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
Nut (plastic) (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____

Model 33A Talent Amplifier (all Serial Numbers)

Knob – Ch 1 and Ch 2 (black, push-on, 15 mm) (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
Knob Cap – Ch 1 and Ch 2 (black w/white line, 15 mm) (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
Potentiometer – Ch 1 and Ch 2 (Order Code: 2148)	_____	\$ 4.00	_____
Toggle Switch – Ch 1/2 Select (Order Code: 12063)	_____	\$ 9.00	_____
3-Pin Male XLR Connector (Order Code: 1093)	_____	\$ 7.00	_____
3-Pin Female XLR Connector (Order Code: 1094)	_____	\$ 8.00	_____
1/4" Phone Jack (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
Nut (plastic) (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
3.5 mm Stereo Jack (Order Code: 1198)	_____	\$ 3.00	_____

Model 34 Talent Amplifier (all Serial Numbers)

Knob – Ch 1/Left and Ch 2/Right (black, push-on, 15 mm) (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
Knob Cap – Ch 1/Left and Ch 2/Right (black w/white line, 15 mm) (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
Potentiometer – Ch 1/Left and Ch 2/Right (Order Code: 2148)	_____	\$ 4.00	_____
Toggle Switch – Output Mic/Stereo Select (Order Code: 12021)	_____	\$ 6.00	_____
3-Pin Female XLR Connector (Order Code: 1094)	_____	\$ 8.00	_____
1/4" Phone Jack (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
Nut (plastic) (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
3.5 mm Stereo Jack (Order Code: 1198)	_____	\$ 3.00	_____

	Qty	US List Price	Total
Model 35 Talent Amplifier (Serial Numbers 00001 – 00385)			
Knob (black, push-on, 15 mm) (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
Knob Cap (black w/white line, 15 mm) (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
Potentiometer (Order Code: 2124)	_____	\$ 5.00	_____
Pushbutton Switch (push-push) – Stereo/Mono (Order Code: 12016)	_____	\$ 3.00	_____
Pushbutton Cap (gray) (Order Code: 12015)	_____	\$ 3.00	_____
3-Pin Male XLR Connector (Order Code: 1093)	_____	\$ 7.00	_____
3-Pin Female XLR Connector (Order Code: 1094)	_____	\$ 8.00	_____
Dual 1/4" Phone Jack (Order Code: 1087)	_____	\$ 6.00	_____
Self-Adhesive Rubber Bumpons (black, set of 4) (Order Code: 14028)	_____	\$ 2.00	_____

Model 35 Talent Amplifier (Serial Numbers 00386 and later)

Knob (black, push-on, 15 mm) (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
Knob Cap (black w/white line, 15 mm) (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
Potentiometer (Order Code: 2124)	_____	\$ 5.00	_____
Pushbutton Switch (push-push) – Stereo/Mono (Order Code: 12016)	_____	\$ 3.00	_____
Pushbutton Cap (gray) (Order Code: 12015)	_____	\$ 3.00	_____
3-Pin Male XLR Connector (Order Code: 1093)	_____	\$ 7.00	_____
3-Pin Female XLR Connector (Order Code: 1094)	_____	\$ 8.00	_____
Dual 1/4" Phone Jack (Order Code: 1113)	_____	\$ 7.00	_____
Self-Adhesive Rubber Bumpons (black, set of 4) (Order Code: 14028)	_____	\$ 2.00	_____

Model 36 Talent Interface (all Serial Numbers)

Knob (black, push-on, 15 mm) (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
Knob Cap (black w/white line, 15 mm) (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
Potentiometer (Order Code: 2148)	_____	\$ 4.00	_____
1/4" Phone Jack (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
Nut (plastic) (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
3.5 mm Stereo Jack (Order Code: 1198)	_____	\$ 3.00	_____
5-Pin Headset Connector Assembly (Order Code: 13579)	_____	\$56.00	_____
6-Pin Headset Connector Assembly (Order Code: 13595)	_____	\$56.00	_____
7-Pin Headset Connector Assembly (Order Code: 13561)	_____	\$56.00	_____

	Qty	US List Price	Total
Model 37 Intercom Beltpack (all Serial Numbers)			
Knob – Main and Aux (black, push-on, 15 mm) (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
Knob Cap – Main and Aux (black w/white line, 15 mm) (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
Potentiometer – Main and Aux (Order Code: 2148)	_____	\$ 4.00	_____
Toggle Switch – Mic On Select (on/off/mom) (Order Code: 12088)	_____	\$ 6.00	_____
12 Vdc, 1.5 A Power Supply (Order Code: PS-DC-02)	_____	\$72.00	_____
Power Entry & Aux Audio Input Kit (Order Code: M37-MK-01)	_____	\$84.00	_____

Model 41 Interface (Serial Numbers 00151 – 01050)

Knob (black, push-on, 15 mm) (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
Knob Cap (black, w/white line, 15 mm) (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
Potentiometer (Order Code: 2166)	_____	\$ 4.00	_____
1/4" Phone Jack (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
Nut (plastic) (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
Pushbutton Cap (gray) (Order Code: 14229)	_____	\$ 1.50	_____

Model 41 Interface (Serial Numbers 01051 and later)

Knob (black, push-on, 15 mm) (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
Knob Cap (black w/white line, 15 mm) (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
Potentiometer (Order Code: 2166)	_____	\$ 4.00	_____
1/4" Phone Jack (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
Nut (plastic) (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
Pushbutton Cap (gray) (Order Code: 14229)	_____	\$ 1.50	_____

Model 42A Interface (all Serial Numbers)

Knob (black, push-on, 15 mm) (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
Knob Cap (black w/white line, 15 mm) (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
Potentiometer (Order Code: 2166)	_____	\$ 4.00	_____
1/4" Phone Jack (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
Nut (plastic) (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
Pushbutton Cap (gray) (Order Code: 14229)	_____	\$ 1.50	_____

	Qty	US List Price	Total
Model 43D IFB Interface (all Serial Numbers)			
4-Position DIP Switch <i>(Order Code: 12071)</i>	_____	\$ 5.00	_____
Screw-On Bumper Kit (black, set of 8) <i>(Order Code: 31064)</i>	_____	\$10.00	_____
12 Vdc, 1.5 A Power Supply <i>(Order Code: PS-DC-02)</i>	_____	\$72.00	_____

Model 44D Audio Interface (all Serial Numbers)			
4-Position DIP Switch <i>(Order Code: 12071)</i>	_____	\$ 5.00	_____
Screw-On Bumper Kit (black, set of 8) <i>(Order Code: 31064)</i>	_____	\$10.00	_____
12 Vdc, 1.5 A Power Supply <i>(Order Code: PS-DC-02)</i>	_____	\$72.00	_____

Model 45 Interface (all Serial Numbers)			
5-Position DIP Switch <i>(Order Code: 12069)</i>	_____	\$ 6.00	_____
Pushbutton Switch (momentary) – Auto Null <i>(Order Code: 12056)</i>	_____	\$ 4.00	_____
Pushbutton Cap (gray) <i>(Order Code: 14207)</i>	_____	\$ 3.00	_____
Screw-On Bumper Kit (black, set of 8) <i>(Order Code: 31064)</i>	_____	\$10.00	_____
24 Vdc, 0.75 A Power Supply <i>(Order Code: PS-DC-03)</i>	_____	\$46.00	_____

Model 45A Interface (all Serial Numbers)			
5-Position DIP Switch <i>(Order Code: 12069)</i>	_____	\$ 6.00	_____
Pushbutton Switch (momentary) – Auto Null <i>(Order Code: 12056)</i>	_____	\$ 4.00	_____
Pushbutton Cap (gray) <i>(Order Code: 14207)</i>	_____	\$ 3.00	_____
Screw-On Bumper Kit (black, set of 8) <i>(Order Code: 31064)</i>	_____	\$10.00	_____
24 Vdc, 0.75 A Power Supply <i>(Order Code: PS-DC-03)</i>	_____	\$46.00	_____

Model 45DC Intercom Interface (all Serial Numbers)			
4-Position DIP Switch <i>(Order Code: 12071)</i>	_____	\$ 5.00	_____
Pushbutton Switch (momentary) – Auto Null <i>(Order Code: 12056)</i>	_____	\$ 4.00	_____
Pushbutton Cap (gray) <i>(Order Code: 14207)</i>	_____	\$ 3.00	_____
Screw-On Bumper Kit (black, set of 8) <i>(Order Code: 31064)</i>	_____	\$10.00	_____
12 Vdc, 1.5 A Power Supply <i>(Order Code: PS-DC-02)</i>	_____	\$72.00	_____

Model 45DR Intercom Interface (all Serial Numbers)			
4-Position DIP Switch <i>(Order Code: 12071)</i>	_____	\$ 5.00	_____
Pushbutton Switch (momentary) – Auto Null <i>(Order Code: 12056)</i>	_____	\$ 4.00	_____
Pushbutton Cap (gray) <i>(Order Code: 14207)</i>	_____	\$ 3.00	_____
Screw-On Bumper Kit (black, set of 8) <i>(Order Code: 31064)</i>	_____	\$10.00	_____
12 Vdc, 1.5 A Power Supply <i>(Order Code: PS-DC-02)</i>	_____	\$72.00	_____

	Qty	US List Price	Total
Model 46 Interface (all Serial Numbers)			
4-Position DIP Switch <i>(Order Code: 12071)</i>	_____	\$ 5.00	_____
Pushbutton Switch (momentary) – Auto Null <i>(Order Code: 12056)</i>	_____	\$ 4.00	_____
Pushbutton Cap (gray) <i>(Order Code: 14207)</i>	_____	\$ 3.00	_____

Model 46A Interface (all Serial Numbers)			
4-Position DIP Switch <i>(Order Code: 12071)</i>	_____	\$ 5.00	_____
Pushbutton Switch (momentary) – Auto Null <i>(Order Code: 12056)</i>	_____	\$ 4.00	_____
Pushbutton Cap (gray) <i>(Order Code: 14207)</i>	_____	\$ 3.00	_____

Model 47 Interface (all Serial Numbers)			
4-Position DIP Switch <i>(Order Code: 12071)</i>	_____	\$ 5.00	_____
Pushbutton Switch (momentary) – Auto Null <i>(Order Code: 12056)</i>	_____	\$ 4.00	_____
Pushbutton Cap (gray) <i>(Order Code: 14207)</i>	_____	\$ 3.00	_____

Model 47A Interface (all Serial Numbers)			
4-Position DIP Switch <i>(Order Code: 12071)</i>	_____	\$ 5.00	_____
Pushbutton Switch (momentary) – Auto Null <i>(Order Code: 12056)</i>	_____	\$ 4.00	_____
Pushbutton Cap (gray) <i>(Order Code: 14207)</i>	_____	\$ 3.00	_____

Model 48D Dante Bridge (all Serial Numbers)

Contact Factory as Required

Model 72 Level Meter / Interface (all Serial Numbers)

Self-Adhesive Rubber Bumpons (black, set of 4) <i>(Order Code: 14028)</i>	_____	\$ 2.00	_____
---	-------	---------	-------

	Qty	US List Price	Total
Model 51 Control Console (all Serial Numbers)			
Pushbutton Switch (momentary) (Order Code: 12055; Mfg No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND)	_____	\$ 4.00	_____
Knob – Studio Level (black, push-on, 15 mm) (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
Knob Cap – Studio Level (black w/white line, 15 mm) (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
Potentiometer – Studio Level (Order Code: 30333-001)	_____	\$12.00	_____
Knob – Control Room Level (black, collet, 47 mm) (Order Code: 14205) <i>Note: Knob and knob cap are sold separately. See 14206 for knob cap.</i>	_____	\$18.00	_____
Knob Cap – Control Room Level (black w/white line, 47 mm) (Order Code: 14206) <i>Note: Knob and knob cap are sold separately. See 14205 for knob.</i>	_____	\$ 4.00	_____
Potentiometer – Control Room Level (Order Code: 30332-001)	_____	\$12.00	_____
Self-Adhesive Rubber Bumpons (black, set of 4) (Order Code: 14028)	_____	\$ 2.00	_____

Model 56 Control Console (all Serial Numbers)

Pushbutton Switch (momentary) (Order Code: 12055; Mfg No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND)	_____	\$ 4.00	_____
Knob – Control Room Level (black, collet, 38 mm) (Order Code: 14209) <i>Note: Knob and knob cap are sold separately. See 14210 for knob cap.</i>	_____	\$14.00	_____
Knob Cap – Control Room Level (black w/white line, 38 mm) (Order Code: 14210) <i>Note: Knob and knob cap are sold separately. See 14209 for knob.</i>	_____	\$ 3.00	_____
Potentiometer – Control Room Level (Order Code: 2123)	_____	\$ 5.00	_____
Self-Adhesive Rubber Bumpons (black, set of 4) (Order Code: 14028)	_____	\$ 2.00	_____

Models 59 & 591 Control Console (all Serial Numbers)

Pushbutton Switch (momentary) (Order Code: 12055; Mfg No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND)	_____	\$ 4.00	_____
Knob – Control Room Level (black, collet, 38 mm) (Order Code: 14209) <i>Note: Knob and knob cap are sold separately. See 14210 for knob cap.</i>	_____	\$14.00	_____
Knob Cap – Control Room Level (black w/white line, 38 mm) (Order Code: 14210) <i>Note: Knob and knob cap are sold separately. See 14209 for knob.</i>	_____	\$ 3.00	_____
Potentiometer – Control Room Level (Order Code: 2123)	_____	\$ 5.00	_____
Self-Adhesive Rubber Bumpons (black, set of 4) (Order Code: 14028)	_____	\$ 2.00	_____

	Qty	US List Price	Total
Model 60 Central Controller (Serial Numbers 00200 – 00300)			
1/4" Phone Jack (Order Code: 1086)	_____	\$ 4.00	_____
Dual 1/4" Phone Jack (Order Code: 1087)	_____	\$ 6.00	_____
Knob – Level (black, push-on, 15 mm) (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
Knob Cap – Level (black w/white line, 15 mm) (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
Potentiometer – Phones Level and Dub Level (Order Code: 2128)	_____	\$ 8.00	_____
Pushbutton Switch (push-push) (Order Code: 12016)	_____	\$ 3.00	_____
Pushbutton Switch Assembly (4-station) – Source (Order Code: 12061)	_____	\$16.00	_____
Pushbutton Cap (gray) (Order Code: 12050; Mfg No.: E-Switch TACGRY; Digi-Key No.: EG1082-ND)	_____	\$ 4.00	_____

Model 60 Central Controller (Serial Numbers 00301 – later)

1/4" Phone Jack (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
Nut (plastic) (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
Dual 1/4" Phone Jack (Order Code: 1113)	_____	\$ 7.00	_____
Knob – Level (black, push-on, 15 mm) (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
Knob Cap – Level (black w/white line, 15 mm) (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
Potentiometer – Phones Level and Dub Level (Order Code: 2128)	_____	\$ 8.00	_____
Pushbutton Switch (push-push) (Order Code: 12016)	_____	\$ 3.00	_____
Pushbutton Switch Assembly (4-station) – Source (Order Code: 12061)	_____	\$16.00	_____
Pushbutton Cap (gray) (Order Code: 12050; Mfg No.: E-Switch TACGRY; Digi-Key No.: EG1082-ND)	_____	\$ 4.00	_____

Model 60A Central Controller (all Serial Numbers)

1/4" Phone Jack (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
Nut (plastic) (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
Dual 1/4" Phone Jack (Order Code: 1168)	_____	\$ 7.00	_____
Knob – Level (black, push-on, 15 mm) (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
Knob Cap – Level (black w/white line, 15 mm) (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
Potentiometer – Phones Level and Dub Level (Order Code: 2128)	_____	\$ 8.00	_____
Pushbutton Switch (push-push) (Order Code: 12016)	_____	\$ 3.00	_____
Pushbutton Switch Assembly (4-station) – Source (Order Code: 12061)	_____	\$16.00	_____
Pushbutton Switch Assembly (3-station) – Switcher (Order Code: 12074)	_____	\$12.00	_____
Pushbutton Cap (gray) (Order Code: 12050; Mfg No.: E-Switch TACGRY; Digi-Key No.: EG1082-ND)	_____	\$ 4.00	_____

	Qty	US List Price	Total
Model 61 Control Console (all Serial Numbers)			
Pushbutton Switch (momentary) (Order Code: 12055; Mfg No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND)	_____	\$ 4.00	_____
Knob – Level (black, collet, 29 mm) (Order Code: 14214) <i>Note: Knob and knob cap are sold separately. See 14215 for knob cap.</i>	_____	\$ 7.00	_____
Knob Cap – Level (black w/white line, 29 mm) (Order Code: 14215) <i>Note: Knob and knob cap are sold separately. See 14209 for knob.</i>	_____	\$ 3.00	_____
Potentiometer – Level (Order Code: 2123)	_____	\$ 5.00	_____
Self-Adhesive Rubber Bumpons (black, set of 4) (Order Code: 14028)	_____	\$ 2.00	_____

Model 69 Control Console (all Serial Numbers)			
Pushbutton Switch (momentary) (Order Code: 12055; Mfg No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND)	_____	\$ 4.00	_____
Knob – Level (black, collet, 38 mm) (Order Code: 14209) <i>Note: Knob and knob cap are sold separately. See 14210 for knob cap.</i>	_____	\$14.00	_____
Knob Cap – Level (black w/white line, 38 mm) (Order Code: 14210) <i>Note: Knob and knob cap are sold separately. See 14209 for knob.</i>	_____	\$ 3.00	_____
Potentiometer – Level (Order Code: 2123)	_____	\$ 5.00	_____
Self-Adhesive Rubber Bumpons (black, set of 4) (Order Code: 14028)	_____	\$ 2.00	_____

Model 69A Control Console (all Serial Numbers)			
Pushbutton Switch (momentary) (Order Code: 12055; Mfg No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND)	_____	\$ 4.00	_____
Knob – Level (black, collet, 38 mm) (Order Code: 14209) <i>Note: Knob and knob cap are sold separately. See 14210 for knob cap.</i>	_____	\$14.00	_____
Knob Cap – Level (black w/white line, 38 mm) (Order Code: 14210) <i>Note: Knob and knob cap are sold separately. See 14209 for knob.</i>	_____	\$ 3.00	_____
Potentiometer – Level (Order Code: 2123)	_____	\$ 5.00	_____
Self-Adhesive Rubber Bumpons (black, set of 4) (Order Code: 14028)	_____	\$ 2.00	_____

Model 71 Control Console (all Serial Numbers)			
Pushbutton Switch (momentary) (Order Code: 12055; Mfg No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND)	_____	\$ 4.00	_____
Knob – Level (black, collet, 29 mm) (Order Code: 14214) <i>Note: Knob and knob cap are sold separately. See 14260 for knob cap.</i>	_____	\$ 7.00	_____
Knob Cap – Level (black, 29 mm) (Order Code: 14260) <i>Note: Knob and knob cap are sold separately. See 14214 for knob.</i>	_____	\$ 2.00	_____
Rotary Encoder – Level (Order Code: 12034)	_____	\$ 4.00	_____
Self-Adhesive Rubber Bumpons (black, set of 4) (Order Code: 14028)	_____	\$ 2.00	_____

Model 74 Central Controller (all Serial Numbers)			
3.5 mm Jack (Order Code: 1315)	_____	\$ 4.00	_____

	Qty	US List Price	Total
Model 75 Control Console (all Serial Numbers)			
Pushbutton Switch (momentary) (Order Code: 12055; Mfg No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND)	_____	\$ 4.00	_____
Knob – Level (black, collet, 38 mm) (Order Code: 14209) <i>Note: Knob and knob cap are sold separately. See 14210 for knob cap.</i>	_____	\$14.00	_____
Knob Cap – Level (black w/white line, 38 mm) (Order Code: 14210) <i>Note: Knob and knob cap are sold separately. See 14209 for knob.</i>	_____	\$ 3.00	_____
Potentiometer Assembly – Level (Order Code: 32089)	_____	\$12.00	_____
Self-Adhesive Rubber Bumpons (black, set of 4) (Order Code: 14028)	_____	\$ 2.00	_____

Model 77 Control Console (all Serial Numbers)

Pushbutton Switch (momentary) (Order Code: 12055; Mfg No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND)	_____	\$ 4.00	_____
Knob – Level (black, collet, 29 mm) (Order Code: 14214) <i>Note: Knob and knob cap are sold separately. See 14260 for knob cap.</i>	_____	\$ 7.00	_____
Knob Cap – Level (black, 29 mm) (Order Code: 14260) <i>Note: Knob and knob cap are sold separately. See 14214 for knob.</i>	_____	\$ 2.00	_____
Rotary Encoder Assembly – Level (Order Code: 31378)	_____	\$ 9.00	_____
Self-Adhesive Rubber Bumpons (black, set of 4) (Order Code: 14028)	_____	\$ 2.00	_____

Model 77B Control Console (all Serial Numbers)

Pushbutton Switch (momentary) (Order Code: 12055; Mfg No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND)	_____	\$ 4.00	_____
Knob – Level (black, collet, 29 mm) (Order Code: 14214) <i>Note: Knob and knob cap are sold separately. See 14260 for knob cap.</i>	_____	\$ 7.00	_____
Knob Cap – Level (black, 29 mm) (Order Code: 14260) <i>Note: Knob and knob cap are sold separately. See 14214 for knob.</i>	_____	\$ 2.00	_____
Rotary Encoder Assembly – Level (Order Code: 31378)	_____	\$ 9.00	_____
Self-Adhesive Rubber Bumpons (black, set of 4) (Order Code: 14028)	_____	\$ 2.00	_____

Model 79 Control Console (all Serial Numbers)

Pushbutton Switch (momentary) (Order Code: 12055; Mfg No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND)	_____	\$ 4.00	_____
Knob – Level (black, collet, 29 mm) (Order Code: 14214) <i>Note: Knob and knob cap are sold separately. See 14215 for knob cap.</i>	_____	\$14.00	_____
Knob Cap – Level (black w/white line, 29 mm) (Order Code: 14215) <i>Note: Knob and knob cap are sold separately. See 14209 for knob.</i>	_____	\$ 3.00	_____
Potentiometer – Level (Order Code: 2123)	_____	\$ 5.00	_____
Self-Adhesive Rubber Bumpons (black, set of 4) (Order Code: 14028)	_____	\$ 2.00	_____

Model 790 Control Console (all Serial Numbers)

Pushbutton Switch (momentary) (Order Code: 12055; Mfg No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND)	_____	\$ 4.00	_____
Knob – Level (black, collet, 29 mm) (Order Code: 14214) <i>Note: Knob and knob cap are sold separately. See 14260 for knob cap.</i>	_____	\$ 7.00	_____
Knob Cap – Level (black, 29 mm) (Order Code: 14260) <i>Note: Knob and knob cap are sold separately. See 14214 for knob.</i>	_____	\$ 2.00	_____
Rotary Encoder Assembly – Level (Order Code: 31378)	_____	\$ 9.00	_____
Self-Adhesive Rubber Bumpons (black, set of 4) (Order Code: 14028)	_____	\$ 2.00	_____

Qty **US List** **Total**
 Price

Model 92 DT12 Cable Assembly Test Unit (all Serial Numbers)

Rechargeable Battery, 12 V, 1.3 Ah (Order Code: 10335; Mfg No.: Panasonic LC-R121R3P;
Digi-Key No.: P264-ND)

Not available from factory

Model 93 W1 Cable Assembly Test Unit (all Serial Numbers)

Rechargeable Battery, 12 V, 1.3 Ah (Order Code: 10335; Mfg No.: Panasonic LC-R121R3P;
Digi-Key No.: P264-ND)

Not available from factory

	Qty	US List Price	Total
Model 200-Series Announcer's and Producer's Consoles (all Serial Numbers)			
Backlight LED for Models 214, 215, and 216 Announcer's Consoles and Model 240 Producer's Console (Order Code: 3154)	_____	\$ 3.00	_____
Button Cap, Lenses, and Label 15154 Kit (includes five each button caps, clear lens, frosted lens, and one set of button function labels) (Order Code: 31069)	_____	\$40.00	_____
Knob – Phones Level (black, push-on, 15 mm) (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
Knob Cap – Phones Level (black w/white line, 15 mm) (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
Potentiometer – Phones Level (Order Code: 2127)	_____	\$ 5.00	_____
DC Power Entry Jack Assembly (includes PCB, washer, and nut) (Order Code: 32135) <i>Note: Requires cable assembly, sold separately. See 13690.</i>	_____	\$12.00	_____
Cable Assembly for DC Power Entry Jack Assembly (2-conductor, 5-inch) (Order Code: 13690)	_____	\$ 4.00	_____
Screw-On Bumper Kit (black, set of 8) (Order Code: 31064)	_____	\$10.00	_____
Model 210 Security Plate (Order Code: SP-M210)	_____	\$15.00	_____
Model 211 Security Plate (Order Code: SP-M211)	_____	\$15.00	_____
Model 212 Security Plate (Order Code: SP-M212)	_____	\$15.00	_____
Model 214 Security Plate (Order Code: SP-M214)	_____	\$15.00	_____
Model 215 Security Plate (Order Code: SP-M215)	_____	\$15.00	_____
Model 216 Security Plate (Order Code: SP-M216)	_____	\$15.00	_____
Model 220 Security Plate (Order Code: SP-M220)	_____	\$18.00	_____
Model 230 Security Plate (Order Code: SP-M230)	_____	\$18.00	_____
Model 233 Security Plate (Order Code: SP-M233)	_____	\$18.00	_____
Model 240 Security Plate (Order Code: SP-M240)	_____	\$18.00	_____
24 Vdc, 0.75 A Power Supply (Order Code: PS-DC-03)	_____	\$46.00	_____
12 Vdc, 1.5 A Power Supply (Order Code: PS-DC-02)	_____	\$72.00	_____

Model 204, Model 205 & Model 206 Announcer's Consoles (all Serial Numbers)

Knob (black w/white line, 9 mm) (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
Set Screw (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
Push-Pot Potentiometer Assembly (dual-section) (Order Code: 32298) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
Pushbutton Switch (momentary, 17 mm x 17 mm) (Order Code: 12101)	_____	\$ 6.00	_____
1/4" Phone Jack (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
Nut (plastic) (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
3.5 mm Stereo Jack (Order Code: 1198)	_____	\$ 3.00	_____

	Qty	US List Price	Total
Model 208 Announcer's Console (all Serial Numbers)			
Knob (black w/white line, 9 mm) (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
Set Screw (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
Push-Pot Potentiometer Assembly (dual-section) (Order Code: 32298) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
Switch Cap Adapter (Order Code: 14294) <i>Note: Switch cap and switch cap adapter are sold separately. See 14295 for 12 mm switch cap and 14296 for 10 mm switch cap.</i>	_____	\$ 1.50	_____
Switch Cap (12 mm) (Order Code: 14295) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____
1/4" Phone Jack (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
Nut (plastic) (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
3.5 mm Stereo Jack (Order Code: 1198)	_____	\$ 3.00	_____

Model 362 Listen-Only Beltpack (all Serial Numbers)			
Knob (black w/white line, 9 mm) (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
Set Screw (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
Push-Pot Potentiometer Assembly (dual-section) (Order Code: 32298) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
1/4" Phone Jack (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
Nut (plastic) (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____

	Qty	US List Price	Total
Model 370 Intercom Beltpack (all Serial Numbers)			
Knob (black w/white line, 9 mm) (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
Set Screw (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
Push-Pot Potentiometer Assembly (dual-section) (Order Code: 32298) (for s/n 00151-02000) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
Push-Pot Potentiometer Assembly (single-section) (Order Code: 32299) (for s/n 02001-later) <i>Note: Includes push-pot (2172) and sleeve (14297).</i>	_____	\$ 9.00	_____
Trim Potentiometer (for sidetone) (Order Code: 2119) <i>Note: Plastic shaft sold separately. See 14307.</i>	_____	\$ 4.00	_____
Plastic Shaft (gray, for sidetone trim pot) (Order Code: 14307)	_____	\$ 3.00	_____
Switch Cap Adapter (Order Code: 14294) <i>Note: Switch cap and switch cap adapter are sold separately. See 14295 for 12 mm switch cap and 14296 for 10 mm switch cap.</i>	_____	\$ 1.50	_____
Switch Cap – Talk (12 mm square) (Order Code: 14295) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____
Switch Cap – Call (10 mm square) (Order Code: 14296) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____

Model 370A Intercom Beltpack (all Serial Numbers)

Knob (black w/white line, 9 mm) (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
Set Screw (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
Push-Pot Potentiometer Assembly (dual-section) (Order Code: 32298) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
Switch Cap Adapter (Order Code: 14294) <i>Note: Switch cap and switch cap adapter are sold separately. See 14295 for 12 mm switch cap and 14296 for 10 mm switch cap.</i>	_____	\$ 1.50	_____
Switch Cap – Talk (12 mm square) (Order Code: 14295) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____
Switch Cap – Call (10 mm square) (Order Code: 14296) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____

	Qty	US List Price	Total
Model 371 Intercom Beltpack (all Serial Numbers)			
Knob (black w/white line, 9 mm) (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
Set Screw (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
Push-Pot Potentiometer Assembly (single-section) (Order Code: 32299) <i>Note: Includes push-pot (2172) and sleeve (14297).</i>	_____	\$ 9.00	_____
Trim Potentiometer (for sidetone) (Order Code: 2119) <i>Note: Plastic shaft sold separately. See 14307.</i>	_____	\$ 4.00	_____
Plastic Shaft (gray, for sidetone trim pot) (Order Code: 14307)	_____	\$ 3.00	_____
Switch Cap Adapter (Order Code: 14294) <i>Note: Switch cap and switch cap adapter are sold separately. See 14295 for 12 mm switch cap and 14296 for 10 mm switch cap.</i>	_____	\$ 1.50	_____
Switch Cap – Talk (12 mm square) (Order Code: 14295) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____
Switch Cap – Call (10 mm square) (Order Code: 14296) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____

Model 371A Intercom Beltpack (all Serial Numbers)

Knob (black w/white line, 9 mm) (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
Set Screw (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
Push-Pot Potentiometer Assembly (dual-section) (Order Code: 32298) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
Switch Cap Adapter (Order Code: 14294) <i>Note: Switch cap and switch cap adapter are sold separately. See 14295 for 12 mm switch cap and 14296 for 10 mm switch cap.</i>	_____	\$ 1.50	_____
Switch Cap – Talk (12 mm square) (Order Code: 14295) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____
Switch Cap – Call (10 mm square) (Order Code: 14296) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____

	Qty	US List Price	Total
Model 374 Intercom Beltpack (all Serial Numbers)			
Knob (black w/white line, 9 mm) (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
Set Screw (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
Push-Pot Potentiometer Assembly (dual-section) (Order Code: 32298) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
Trim Potentiometer (for sidetone) (Order Code: 2119) <i>Note: Plastic shaft sold separately. See 14307.</i>	_____	\$ 4.00	_____
Plastic Shaft (gray, for sidetone trim pot) (Order Code: 14307)	_____	\$ 3.00	_____
Switch Cap Adapter (Order Code: 14294) <i>Note: Switch cap and switch cap adapter are sold separately. See 14295 for 12 mm switch cap and 14296 for 10 mm switch cap.</i>	_____	\$ 1.50	_____
Switch Cap (10 mm square) (Order Code: 14296) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____

Model 374A Intercom Beltpack (all Serial Numbers)

Knob (black w/white line, 9 mm) (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
Set Screw (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
Push-Pot Potentiometer Assembly (dual-section) (Order Code: 32298) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
Switch Cap Adapter (Order Code: 14294) <i>Note: Switch cap and switch cap adapter are sold separately. See 14295 for 12 mm switch cap and 14296 for 10 mm switch cap.</i>	_____	\$ 1.50	_____
Switch Cap (10 mm square) (Order Code: 14296) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____

	Qty	US List Price	Total
Model 380 On-Air Beltpack (all Serial Numbers)			
Knob (black w/white line, 9 mm) (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
Set Screw (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
Push-Pot Potentiometer Assembly (dual-section) (Order Code: 32298) (for s/n 00151-01000) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
Push-Pot Potentiometer Assembly (single-section) (Order Code: 32299) (for s/n 01001-later) <i>Note: Includes push-pot (2172) and sleeve (14297).</i>	_____	\$ 9.00	_____
1/4" Phone Jack (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
Nut (plastic) (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
Switch Cap Adapter (Order Code: 14294) <i>Note: Switch cap and switch cap adapter are sold separately. See 14295 for 12 mm switch cap and 14296 for 10 mm switch cap.</i>	_____	\$ 1.50	_____
Switch Cap (12 mm) (Order Code: 14295) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____
<hr/>			
Model 391 Dante Alerting Unit (all Serial Numbers)			
Pushbutton Switch (momentary) – Mode (Order Code: 12056)	_____	\$ 4.00	_____
Pushbutton Cap (gray) (Order Code: 14207)	_____	\$ 3.00	_____
Screw-On Bumper Kit (black, set of 8) (Order Code: 31064)	_____	\$10.00	_____
Trim Potentiometer (Order Code: 2119) <i>Note: Plastic shaft sold separately. See 14307.</i>	_____	\$ 4.00	_____
Plastic Shaft (gray, for trim pot) (Order Code: 14307)	_____	\$ 3.00	_____
<hr/>			

	Qty	US List Price	Total
Model 400 SDI-Over-Fiber Transport Systems (all Serial Numbers)			
Pushbutton Switch (momentary) (Order Code: 12055; Mfg No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND)	_____	\$ 4.00	_____
Display Assembly (Order Code: 31579)	_____	\$122.00	_____
Display Lens (Order Code: 15203)	_____	\$ 4.00	_____

Model 410 SDI-Over-Fiber Transport Systems (all Serial Numbers)			
Pushbutton Switch (momentary) (Order Code: 12055; Mfg No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND)	_____	\$ 4.00	_____
Display Assembly (Order Code: 31601)	_____	\$122.00	_____
Display Lens (Order Code: 15203)	_____	\$ 4.00	_____
Screw-On Bumper Kit (black, set of 8) (Order Code: 31064)	_____	\$ 10.00	_____
12 Vdc, 1.5 A Power Supply (Order Code: PS-DC-02)	_____	\$ 72.00	_____

Model 412 Fiber Transport Systems (all Serial Numbers)			
Pushbutton Switch (momentary) (Order Code: 12055; Mfg No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND)	_____	\$ 4.00	_____
Display Assembly (Order Code: 31601)	_____	\$122.00	_____
Display Lens (Order Code: 15203)	_____	\$ 4.00	_____
Screw-On Bumper Kit (black, set of 8) (Order Code: 31064)	_____	\$ 10.00	_____
12 Vdc, 1.5 A Power Supply (Order Code: PS-DC-02)	_____	\$ 72.00	_____

	Qty	US List Price	Total
Model 742 Audio Mixer (all Serial Numbers)			
Knob – Inputs 1-8 (black, push-on, 15 mm) (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
Knob Cap – Inputs 1-8 (black w/white line, 15 mm) (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
Potentiometer – Inputs 1-4 (Order Code: 2145)	_____	\$ 4.00	_____
Potentiometer – Inputs 5-8 (Order Code: 2166)	_____	\$ 4.00	_____
Potentiometer – Master and Monitor (dual-shaft) (Order Code: 2167)	_____	\$12.00	_____
Knob (Top) – Master and Monitor (black w/white line, 11 mm) (Order Code: 14253) <i>Note: Knob (top), knob cap (top), and knob (bottom) are sold separately. See 14255 for knob cap (top) and 14254 for knob (bottom).</i>	_____	\$ 3.00	_____
Knob Cap (Top) – Master and Monitor (black w/white line, 11 mm) (Order Code: 14255) <i>Note: Knob (top), knob cap (top), and knob (bottom) are sold separately. See 14253 for knob (top) and 14254 for knob (bottom).</i>	_____	\$ 3.00	_____
Knob (Bottom) – Master and Monitor (black w/white line, 15 mm) (Order Code: 14254) <i>Note: Knob (top), knob cap (top), and knob (bottom) are sold separately. See 14253 for knob (top) and 14255 for knob cap (top).</i>	_____	\$ 4.00	_____

Model 742A Audio Mixer (all Serial Numbers)

4-Position DIP Switch (Order Code: 12071)	_____	\$ 5.00	_____
Knob – Inputs 1-8 (black, push-on, 15 mm) (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
Knob Cap – Inputs 1-8 (black w/white line, 15 mm) (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
Potentiometer – Inputs 1-4 (Order Code: 2145)	_____	\$ 4.00	_____
Potentiometer – Inputs 5-8 (Order Code: 2166)	_____	\$ 4.00	_____
Potentiometer – Master and Monitor (dual-shaft) (Order Code: 2167)	_____	\$12.00	_____
Knob (Top) – Master and Monitor (black w/white line, 11 mm) (Order Code: 14253) <i>Note: Knob (top), knob cap (top), and knob (bottom) are sold separately. See 14255 for knob cap (top) and 14254 for knob (bottom).</i>	_____	\$ 3.00	_____
Knob Cap (Top) – Master and Monitor (black w/white line, 11 mm) (Order Code: 14255) <i>Note: Knob (top), knob cap (top), and knob (bottom) are sold separately. See 14253 for knob (top) and 14254 for knob (bottom).</i>	_____	\$ 3.00	_____
Knob (Bottom) – Master and Monitor (black w/white line, 15 mm) (Order Code: 14254) <i>Note: Knob (top), knob cap (top), and knob (bottom) are sold separately. See 14253 for knob (top) and 14255 for knob cap (top).</i>	_____	\$ 4.00	_____

Model 5100-Series Broadcast Support Modules (all Serial Numbers)

Contact Factory as Required

	Qty	US List Price	Total
Model 5202 Dante to Phones and Line Output Interface (all Serial Numbers)			
Knob (black w/white line, 9 mm) (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
Set Screw (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
Push-Pot Potentiometer Assembly (dual-section) (Order Code: 32298) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
1/4" Phone Jack (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
Nut (plastic) (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____

Model 5204 Dual Line Input to Dante Interface (all Serial Numbers)

Knob (black w/white line, 9 mm) (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
Set Screw (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
Push-Pot Potentiometer Assembly (dual-section) (Order Code: 32298) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____

Model 5330 Flex-Use Dante Audio Interface (all Serial Numbers)

Knob (black w/white line, 9 mm) (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
Set Screw (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
Push-Pot Potentiometer Assembly (dual-section) (Order Code: 32298) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
1/4" Phone Jack (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
Nut (plastic) (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____

Model 5401 Dante Master Clock (all Serial Numbers)

Contact Factory as Required

	Qty	US List Price	Total
Model 5414 Mic/Line Input & Line Output Interface (all Serial Numbers)			
Knob (black w/white line, 9 mm) (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
Set Screw (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
Push-Pot Potentiometer Assembly (dual-section) (Order Code: 32298) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
Pushbutton Switch (momentary) – Channel Select (Order Code: 12056)	_____	\$ 4.00	_____
Pushbutton Cap (gray) (Order Code: 14207)	_____	\$ 3.00	_____
1/4" Phone Jack (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
Nut (plastic) (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____

Model 5415 & MD-4 Mic/Line Input & Line Output Interface (all Serial Numbers)

Knob (black w/white line, 9 mm) (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
Set Screw (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
Push-Pot Potentiometer Assembly (single-section) (Order Code: 32299) <i>Note: Includes push-pot (2172) and sleeve (14297).</i>	_____	\$ 9.00	_____
Pushbutton Switch (momentary) – Channel Select (Order Code: 12056)	_____	\$ 4.00	_____
Pushbutton Cap (gray) (Order Code: 14207)	_____	\$ 3.00	_____
1/4" Phone Jack (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
Nut (plastic) (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____

Model 5422-Series Dante Audio Intercom Engines (all Serial Numbers)

Contact Factory as Required

	Qty	US List Price	Total
Live-Link Remote Camera Interface Systems (all Serial Numbers)			
Recessed Bumper Kit (set of 4 each recessed bumpers, 6-32x1" screws, and 6-32 nylock nuts) (Order Code: 32203)	_____	\$ 12.00	_____
Lifting Handle Kit (black lifting handle and set of 6 6-32x1/4" screws) (Order Code: 32204)	_____	\$ 26.00	_____
Portable Cover (Order Code: 31355)	_____	\$150.00	_____
<i>Note: Does not include battery bracket, handle, or hardware.</i>			
Anton-Bauer Battery Bracket Kit (battery bracket w/insulator and 15" cable assembly) (Order Code: 31414)	_____	\$115.00	_____
12 Vdc, 5 A Power Supply (Order Code: PS-DC-01)	_____	\$ 92.00	_____
Audio Cable (XLR5M to XLR3F/XLR3M) (Order Code: 13662)	_____	\$ 42.00	_____
Rack-Ready Cover (Order Code: LL-COVER-02)	_____	\$150.00	_____
10/100/1000 Ethernet Media Converter Upgrade Kit (Order Code: M432-KIT)	_____	\$240.00	_____

Live-Link Jr. Remote Camera Interface Systems (all Serial Numbers)

Pushbutton Switch (momentary) – Auto Null (Order Code: 12056)	_____	\$ 4.00	_____
Pushbutton Cap – Truck End Auto Null (gray) (Order Code: 14207)	_____	\$ 3.00	_____
Recessed Bumper Kit (set of 4 each recessed bumpers and 6-32x3/8" screws) (Order Code: 32202)	_____	\$ 12.00	_____
Lifting Handle Kit (black lifting handle and set of 6 6-32x1/4" screws) (Order Code: 32204)	_____	\$ 26.00	_____
12 Vdc, 5 A Power Supply (Order Code: PS-DC-01)	_____	\$ 92.00	_____

Live-Link Mini Remote Camera Interface Systems (all Serial Numbers)

Pushbutton Switch (momentary) – Auto Null (Order Code: 12056)	_____	\$ 4.00	_____
Pushbutton Cap – Camera End and Truck End Auto Null (gray) (Order Code: 14207)	_____	\$ 3.00	_____
Recessed Bumper Kit (set of 4 each recessed bumpers and 6-32x5/8" screws) (Order Code: 32205)	_____	\$ 12.00	_____
Lifting Handle Kit (black lifting handle and set of 6 6-32x1/4" screws) (Order Code: 32204)	_____	\$ 26.00	_____
12 Vdc, 5 A Power Supply (Order Code: PS-DC-01)	_____	\$ 92.00	_____
Audio Cable (XLR5F to Dual XLR3M) (Order Code: 13684)	_____	\$ 42.00	_____

	Qty	US List Price	Total
Miscellaneous Parts			
Belt Clip (black, steel) <i>(Order Code: 30247)</i>	_____	\$ TBD	_____
Pop-Rivet – for Belt Clip (black, aluminum, 0.125" grip) <i>(Order Code: 8201-.125)</i>	_____	\$ TBD	_____
Machine Screw – for Belt Clip (black, 6-32x1/4") <i>(Order Code: 8054-1/4)</i>	_____	\$ TBD	_____
Pushbutton Switch (momentary, EAO) – M200-Series, M22, M24 <i>(Order Code: 12028)</i>	_____	\$ TBD	_____
