



# Replacement Parts List

All prices effective March 21, 2019. Subject to change without notice.

Parts availability subject to factory stock levels. Certain parts may become obsolete without notice.

## Table of Contents

Model 2 Central Controller (all S/N) . . . . .	3
Model 2A Central Controller (all S/N) . . . . .	3
Model 22 Access Station (all S/N). . . . .	3
Model 24 Access Station (all S/N). . . . .	3
Model 32 Talent Amplifier (S/N 00001 – 00299) . . . . .	4
Model 32 Talent Amplifier (S/N 00300 and later). . . . .	4
Model 32A Talent Amplifier (all S/N) . . . . .	4
Model 33 Talent Amplifier (all S/N) . . . . .	5
Model 33A Talent Amplifier (all S/N) . . . . .	5
Model 34 Talent Amplifiers (all S/N). . . . .	5
Model 35 Talent Amplifier (S/N 00001 – 00385) . . . . .	6
Model 35 Talent Amplifier (S/N 00386 and later). . . . .	6
Model 36 Talent Interface (all S/N) . . . . .	6
Model 37 Intercom Beltpack (all S/N) . . . . .	7
Model 41 Interface (S/N 00151 – 01050) . . . . .	7
Model 41 Interface (S/N 01051 and later) . . . . .	7
Model 42A Interface (all S/N) . . . . .	7
Model 43D IFB Interface (all S/N) . . . . .	8
Model 44D Audio Interface (all S/N). . . . .	8
Model 45 Interface (all S/N) . . . . .	8
Model 45A Interface (all S/N) . . . . .	8
Model 45DC Intercom Interface (all S/N) . . . . .	8
Model 45DR Intercom Interface (all S/N) . . . . .	8
Model 46 Interface (all S/N) . . . . .	9
Model 46A Interface (all S/N) . . . . .	9
Model 47 Interface (all S/N) . . . . .	9
Model 47A Interface (all S/N) . . . . .	9
Model 48D Dante Bridge (all S/N). . . . .	9
Model 72 Level Meter / Interface (all S/N) . . . . .	9
Model 51 Control Console (all S/N) . . . . .	10
Model 56 Control Console (all S/N) . . . . .	10
Models 59 & 591 Control Console (all S/N) . . . . .	10
Model 60 Central Controller (S/N 00200 – 00300) . . . . .	11
Model 60 Central Controller (S/N 00301 and later) . . . . .	11
Model 60A Central Controller (all S/N). . . . .	11
Model 61 Control Console (all S/N) . . . . .	12
Model 69 Control Console (all S/N) . . . . .	12
Model 69A Control Console (all S/N) . . . . .	12
Model 71 Control Console (all S/N) . . . . .	12

**Table of Contents, continued**

Model 74 Central Controller (all S/N) . . . . . 13

Model 75 Control Console (all S/N) . . . . . 13

Model 76 Central Controller (all S/N) . . . . . 13

Model 76B Central Controller (all S/N). . . . . 13

Model 77 Control Console (all S/N) . . . . . 13

Model 77B Control Console (all S/N) . . . . . 14

Model 79 Control Console (all S/N) . . . . . 14

Model 790 Control Console (all S/N). . . . . 14

Model 92 DT12 Cable Assembly Test Unit (all S/N). . . . . 15

Model 93 W1 Cable Assembly Test Unit (all S/N) . . . . . 15

Model 200-Series Announcer's and Producer's Consoles (all S/N) . . . . 16

Models 204, 205 & 206 Announcer's Consoles (all S/N) . . . . . 16

Model 207 eSports Console . . . . . 17

Model 208 Announcer's Console (all S/N) . . . . . 17

Model 348 Intercom Station . . . . . 17

Model 362 Listen-Only Beltpack (all S/N) . . . . . 17

Model 370 Intercom Beltpack (all S/N). . . . . 18

Model 370A Intercom Beltpack (all S/N) . . . . . 18

Model 371 Intercom Beltpack (all S/N). . . . . 19

Model 371A Intercom Beltpack (all S/N) . . . . . 19

Model 372A Intercom Beltpack (all S/N) . . . . . 19

Model 373A Intercom Beltpack (all S/N) . . . . . 20

Model 374 Intercom Beltpack (all S/N). . . . . 20

Model 374A Intercom Beltpack (all S/N) . . . . . 20

Model 380 On-Air Beltpack (all S/N). . . . . 21

Model 381 On-Air Beltpack (all S/N). . . . . 21

Model 391 Dante Alerting Unit (all S/N) . . . . . 21

Model 400 SDI-Over-Fiber Transport Systems (all S/N) . . . . . 22

Model 410 SDI-Over-Fiber Transport Systems (all S/N) . . . . . 22

Model 412 Fiber Transport Systems (all S/N) . . . . . 22

Model 742 Audio Mixer (all S/N) . . . . . 23

Model 742A Audio Mixer (all S/N) . . . . . 23

Model 5100-Series Broadcast Support Modules (all S/N) . . . . . 23

Model 5202 Dante to Phones and Line Output Interface (all S/N) . . . . 24

Model 5204 Dual Line Input to Dante Interface (all S/N). . . . . 24

Model 5330 Flex-Use Dante Audio Interface (all S/N) . . . . . 24

Model 5401 Dante Master Clock (all S/N). . . . . 24

Model 5414 Mic/Line Input & Line Output Interface (all S/N). . . . . 25

Model 5415 & MD-4 Mic/Line Input & Line Output Interface (all S/N) . . 25

Model 5422-Series Dante Audio Intercom Engines (all S/N) . . . . . 25

Live-Link Remote Camera Interface Systems (all S/N). . . . . 26

Live-Link Jr. Remote Camera Interface Systems (all S/N). . . . . 26

Live-Link Mini Remote Camera Interface Systems (all S/N) . . . . . 26

Miscellaneous Parts . . . . . 26

	Qty	US List Price	Total
<b>Model 2 Central Controller (all Serial Numbers)</b>			
<b>Knob – Program and Monitor Output (black, push-on, 15 mm)</b> (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
<b>Knob Cap – Program and Monitor Output (black w/white line, 15 mm)</b> (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
<b>Pushbutton Cap (gray)</b> (Order Code: 12050) <i>Mfg. No.: E-Switch TACGRY; Digi-Key No.: EG1082-ND</i>	_____	\$ 4.00	_____
<b>Potentiometer – Program 1, Program 2, Monitor Output</b> (Order Code: 2126)	_____	\$ 4.00	_____
<b>Pushbutton Switch (momentary) – IFB 1, IFB 2</b> (Order Code: 12064)	_____	\$ 4.00	_____
<b>Pushbutton Switch Assembly (6-position, interlock) – Program Select</b> (Order Code: 12036)	_____	\$12.00	_____
<b>Toggle Switch – VOX IFB Input Select</b> (Order Code: 12054)	_____	\$26.00	_____
<b>Toggle Switch – VOX IFB Output Select</b> (Order Code: 12052)	_____	\$22.00	_____
<b>Toggle Switch (momentary) – Telco 1, Telco 2, Manual Off-Hook/Hang-Up Select</b> (Order Code: 12053)	_____	\$22.00	_____
<b>Toggle Switch – Telco 2 Send/Rcv and Monitor Source Select</b> (Order Code: 12051)	_____	\$22.00	_____
<b>Pushbutton Switch (push-push) – Telco Std/Wet 1, Telco Std/Wet 2</b> (Order Code: 12016)	_____	\$ 3.00	_____

**Model 2A Central Controller (all Serial Numbers)**

<b>Knob – Program and Monitor Output (black, push-on, 15 mm)</b> (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
<b>Knob Cap – Program and Monitor Output (black w/white line, 15 mm)</b> (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
<b>Pushbutton Cap (gray)</b> (Order Code: 12050) <i>Mfg. No.: E-Switch TACGRY; Digi-Key No.: EG1082-ND</i>	_____	\$ 4.00	_____
<b>Potentiometer – Program 1, Program 2, Monitor Output</b> (Order Code: 2126)	_____	\$ 4.00	_____
<b>Pushbutton Switch (momentary) – IFB 1, IFB 2</b> (Order Code: 12064)	_____	\$ 4.00	_____
<b>Pushbutton Switch Assembly (6-position, interlock) – Program Select</b> Order Code: 12036)	_____	\$12.00	_____
<b>Toggle Switch (momentary) – Telco 1, Telco 2, Manual Off-Hook/Hang Up Select</b> (Order Code: 12093)	_____	\$ 9.00	_____
<b>Toggle Switch – VOX IFB, Telco 2 Send/Rcv, Monitor Source Select</b> (Order Code: 12091)	_____	\$ 9.00	_____
<b>Pushbutton Switch (push-push) – Telco Std/Wet 1, Telco Std/Wet 2</b> (Order Code: 12016)	_____	\$ 3.00	_____

**Model 22 Access Station (all Serial Numbers)**

<b>Button Cap, Lenses, and Label 15154 Kit (includes five each button caps, clear lens, frosted lens, and one set of button function labels)</b> (Order Code: 31069)	_____	\$40.00	_____
<b>Backlight Lamp (T1, 18 V)</b> (Order Code: 12030)	_____	\$ 4.00	_____

**Model 24 Access Station (all Serial Numbers)**

<b>Button Cap, Lenses, and Label 15154 Kit (includes five each button caps, clear lens, frosted lens, and one set of button function labels)</b> (Order Code: 31069)	_____	\$40.00	_____
<b>Backlight Lamp (T1, 18 V)</b> (Order Code: 12030)	_____	\$ 4.00	_____

	Qty	US List Price	Total
<b>Model 32 Talent Amplifier (Serial Numbers 00001 – 00299)</b>			
<b>Knob (black, push-on, 15 mm)</b> (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
<b>Knob Cap (black w/white line, 15 mm)</b> (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
<b>Potentiometer</b> (Order Code: 2148)	_____	\$ 4.00	_____
<b>Toggle Switch – Ch 1/2 Select</b> (Order Code: 12021)	_____	\$ 6.00	_____
<b>3-Pin Male XLR Connector</b> (Order Code: 1093)	_____	\$ 7.00	_____
<b>3-Pin Female XLR Connector</b> (Order Code: 1094)	_____	\$ 8.00	_____
<b>1/4" Phone Jack</b> (Order Code: 1053)	_____	\$ 7.00	_____

---

**Model 32 Talent Amplifier (Serial Numbers 00300 and later)**

<b>Knob (black, push-on, 15 mm)</b> (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
<b>Knob Cap (black w/white line, 15 mm)</b> (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
<b>Potentiometer</b> (Order Code: 2148)	_____	\$ 4.00	_____
<b>Toggle Switch – Ch 1/2 Select</b> (Order Code: 12021)	_____	\$ 6.00	_____
<b>3-Pin Male XLR Connector</b> (Order Code: 1093)	_____	\$ 7.00	_____
<b>3-Pin Female XLR Connector</b> (Order Code: 1094)	_____	\$ 8.00	_____
<b>1/4" Phone Jack</b> (Order Code: 1086)	_____	\$ 4.00	_____

---

**Model 32A Talent Amplifier (all Serial Numbers)**

<b>Knob (black, push-on, 15 mm)</b> (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
<b>Knob Cap (black w/white line, 15 mm)</b> (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
<b>Potentiometer</b> (Order Code: 2148)	_____	\$ 4.00	_____
<b>Toggle Switch – Ch 1/2 Select</b> (Order Code: 12021)	_____	\$ 6.00	_____
<b>3-Pin Male XLR Connector</b> (Order Code: 1093)	_____	\$ 7.00	_____
<b>3-Pin Female XLR Connector</b> (Order Code: 1094)	_____	\$ 8.00	_____
<b>1/4" Phone Jack</b> (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
<b>Nut (plastic)</b> (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
<b>3.5 mm Stereo Jack</b> (Order Code: 1198)	_____	\$ 3.00	_____

	Qty	US List Price	Total
<b>Model 33 Talent Amplifier (all Serial Numbers)</b>			
<b>Knob – Ch 1 and Ch 2 (black, push-on, 15 mm)</b> (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
<b>Knob Cap – Ch 1 and Ch 2 (black w/white line, 15 mm)</b> (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
<b>Potentiometer – Ch 1 and Ch 2</b> (Order Code: 2148)	_____	\$ 4.00	_____
<b>Toggle Switch – Ch 1/2 Select</b> (Order Code: 12063)	_____	\$ 9.00	_____
<b>3-Pin Male XLR Connector</b> (Order Code: 1093)	_____	\$ 7.00	_____
<b>3-Pin Female XLR Connector</b> (Order Code: 1094)	_____	\$ 8.00	_____
<b>1/4" Phone Jack</b> (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
<b>Nut (plastic)</b> (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____

---

**Model 33A Talent Amplifier (all Serial Numbers)**

<b>Knob – Ch 1 and Ch 2 (black, push-on, 15 mm)</b> (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
<b>Knob Cap – Ch 1 and Ch 2 (black w/white line, 15 mm)</b> (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
<b>Potentiometer – Ch 1 and Ch 2</b> (Order Code: 2148)	_____	\$ 4.00	_____
<b>Toggle Switch – Ch 1/2 Select</b> (Order Code: 12063)	_____	\$ 9.00	_____
<b>3-Pin Male XLR Connector</b> (Order Code: 1093)	_____	\$ 7.00	_____
<b>3-Pin Female XLR Connector</b> (Order Code: 1094)	_____	\$ 8.00	_____
<b>1/4" Phone Jack</b> (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
<b>Nut (plastic)</b> (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
<b>3.5 mm Stereo Jack</b> (Order Code: 1198)	_____	\$ 3.00	_____

---

**Model 34 Talent Amplifier (all Serial Numbers)**

<b>Knob – Ch 1/Left and Ch 2/Right (black, push-on, 15 mm)</b> (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
<b>Knob Cap – Ch 1/Left and Ch 2/Right (black w/white line, 15 mm)</b> (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
<b>Potentiometer – Ch 1/Left and Ch 2/Right</b> (Order Code: 2148)	_____	\$ 4.00	_____
<b>Toggle Switch – Output Mic/Stereo Select</b> (Order Code: 12021)	_____	\$ 6.00	_____
<b>3-Pin Female XLR Connector</b> (Order Code: 1094)	_____	\$ 8.00	_____
<b>1/4" Phone Jack</b> (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
<b>Nut (plastic)</b> (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
<b>3.5 mm Stereo Jack</b> (Order Code: 1198)	_____	\$ 3.00	_____

	Qty	US List Price	Total
<b>Model 35 Talent Amplifier (Serial Numbers 00001 – 00385)</b>			
<b>Knob (black, push-on, 15 mm)</b> (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
<b>Knob Cap (black w/white line, 15 mm)</b> (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
<b>Potentiometer</b> (Order Code: 2124)	_____	\$ 5.00	_____
<b>Pushbutton Switch (push-push) – Stereo/Mono</b> (Order Code: 12016)	_____	\$ 3.00	_____
<b>Pushbutton Cap (gray)</b> (Order Code: 12015)	_____	\$ 3.00	_____
<b>3-Pin Male XLR Connector</b> (Order Code: 1093)	_____	\$ 7.00	_____
<b>3-Pin Female XLR Connector</b> (Order Code: 1094)	_____	\$ 8.00	_____
<b>Dual 1/4" Phone Jack</b> (Order Code: 1087)	_____	\$ 6.00	_____
<b>Self-Adhesive Rubber Bumpons (black, set of 4, 1/2" dia. by 0.138" tall)</b> (Order Code: 14028)	_____	\$ 2.00	_____

**Model 35 Talent Amplifier (Serial Numbers 00386 and later)**

<b>Knob (black, push-on, 15 mm)</b> (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
<b>Knob Cap (black w/white line, 15 mm)</b> (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
<b>Potentiometer</b> (Order Code: 2124)	_____	\$ 5.00	_____
<b>Pushbutton Switch (push-push) – Stereo/Mono</b> (Order Code: 12016)	_____	\$ 3.00	_____
<b>Pushbutton Cap (gray)</b> (Order Code: 12015)	_____	\$ 3.00	_____
<b>3-Pin Male XLR Connector</b> (Order Code: 1093)	_____	\$ 7.00	_____
<b>3-Pin Female XLR Connector</b> (Order Code: 1094)	_____	\$ 8.00	_____
<b>Dual 1/4" Phone Jack</b> (Order Code: 1113)	_____	\$ 7.00	_____
<b>Self-Adhesive Rubber Bumpons (black, set of 4, 1/2" dia. by 0.138" tall)</b> (Order Code: 14028)	_____	\$ 2.00	_____

**Model 36 Talent Interface (all Serial Numbers)**

<b>Knob (black, push-on, 15 mm)</b> (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
<b>Knob Cap (black w/white line, 15 mm)</b> (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
<b>Potentiometer</b> (Order Code: 2148)	_____	\$ 4.00	_____
<b>1/4" Phone Jack</b> (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
<b>Nut (plastic)</b> (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
<b>3.5 mm Stereo Jack</b> (Order Code: 1198)	_____	\$ 3.00	_____
<b>5-Pin Headset Connector Assembly</b> (Order Code: 13579)	_____	\$56.00	_____
<b>6-Pin Headset Connector Assembly</b> (Order Code: 13595)	_____	\$56.00	_____
<b>7-Pin Headset Connector Assembly</b> (Order Code: 13561)	_____	\$56.00	_____

	Qty	US List Price	Total
<b>Model 37 Intercom Beltpack (all Serial Numbers)</b>			
<b>Knob – Main and Aux (black, push-on, 15 mm)</b> (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
<b>Knob Cap – Main and Aux (black w/white line, 15 mm)</b> (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
<b>Potentiometer – Main and Aux</b> (Order Code: 2148)	_____	\$ 4.00	_____
<b>Toggle Switch – Mic On Select (on/off/mom)</b> (Order Code: 12088)	_____	\$ 6.00	_____
<b>12 Vdc, 1.5 A Power Supply</b> (Order Code: PS-DC-02)	_____	\$72.00	_____
<b>Power Entry &amp; Aux Audio Input Kit</b> (Order Code: M37-MK-01)	_____	\$84.00	_____

---

**Model 41 Interface (Serial Numbers 00151 – 01050)**

<b>Knob (black, push-on, 15 mm)</b> (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
<b>Knob Cap (black, w/white line, 15 mm)</b> (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
<b>Potentiometer</b> (Order Code: 2166)	_____	\$ 4.00	_____
<b>1/4" Phone Jack</b> (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
<b>Nut (plastic)</b> (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
<b>Pushbutton Cap (gray)</b> (Order Code: 14229)	_____	\$ 1.50	_____

---

**Model 41 Interface (Serial Numbers 01051 and later)**

<b>Knob (black, push-on, 15 mm)</b> (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
<b>Knob Cap (black w/white line, 15 mm)</b> (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
<b>Potentiometer</b> (Order Code: 2166)	_____	\$ 4.00	_____
<b>1/4" Phone Jack</b> (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
<b>Nut (plastic)</b> (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
<b>Pushbutton Cap (gray)</b> (Order Code: 14229)	_____	\$ 1.50	_____

---

**Model 42A Interface (all Serial Numbers)**

<b>Knob (black, push-on, 15 mm)</b> (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
<b>Knob Cap (black w/white line, 15 mm)</b> (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
<b>Potentiometer</b> (Order Code: 2166)	_____	\$ 4.00	_____
<b>1/4" Phone Jack</b> (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
<b>Nut (plastic)</b> (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
<b>Pushbutton Cap (gray)</b> (Order Code: 14229)	_____	\$ 1.50	_____

	Qty	US List Price	Total
<b>Model 43D IFB Interface (all Serial Numbers)</b>			
4-Position DIP Switch <i>(Order Code: 12071)</i>	_____	\$ 5.00	_____
Screw-On Bumper Kit (black, set of 8) <i>(Order Code: 31064)</i>	_____	\$10.00	_____
12 Vdc, 1.5 A Power Supply <i>(Order Code: PS-DC-02)</i>	_____	\$72.00	_____

---

**Model 44D Audio Interface (all Serial Numbers)**

4-Position DIP Switch <i>(Order Code: 12071)</i>	_____	\$ 5.00	_____
Screw-On Bumper Kit (black, set of 8) <i>(Order Code: 31064)</i>	_____	\$10.00	_____
12 Vdc, 1.5 A Power Supply <i>(Order Code: PS-DC-02)</i>	_____	\$72.00	_____

---

**Model 45 Interface (all Serial Numbers)**

5-Position DIP Switch <i>(Order Code: 12069)</i>	_____	\$ 6.00	_____
Pushbutton Switch (momentary) – Auto Null <i>(Order Code: 12056)</i>	_____	\$ 4.00	_____
Pushbutton Cap (gray) <i>(Order Code: 14207)</i>	_____	\$ 3.00	_____
Screw-On Bumper Kit (black, set of 8) <i>(Order Code: 31064)</i>	_____	\$10.00	_____
24 Vdc, 0.75 A Power Supply <i>(Order Code: PS-DC-03)</i>	_____	\$46.00	_____

---

**Model 45A Interface (all Serial Numbers)**

5-Position DIP Switch <i>(Order Code: 12069)</i>	_____	\$ 6.00	_____
Pushbutton Switch (momentary) – Auto Null <i>(Order Code: 12056)</i>	_____	\$ 4.00	_____
Pushbutton Cap (gray) <i>(Order Code: 14207)</i>	_____	\$ 3.00	_____
Screw-On Bumper Kit (black, set of 8) <i>(Order Code: 31064)</i>	_____	\$10.00	_____
24 Vdc, 0.75 A Power Supply <i>(Order Code: PS-DC-03)</i>	_____	\$46.00	_____

---

**Model 45DC Intercom Interface (all Serial Numbers)**

4-Position DIP Switch <i>(Order Code: 12071)</i>	_____	\$ 5.00	_____
Pushbutton Switch (momentary) – Auto Null <i>(Order Code: 12056)</i>	_____	\$ 4.00	_____
Pushbutton Cap (gray) <i>(Order Code: 14207)</i>	_____	\$ 3.00	_____
Screw-On Bumper Kit (black, set of 8) <i>(Order Code: 31064)</i>	_____	\$10.00	_____
12 Vdc, 1.5 A Power Supply <i>(Order Code: PS-DC-02)</i>	_____	\$72.00	_____

---

**Model 45DR Intercom Interface (all Serial Numbers)**

4-Position DIP Switch <i>(Order Code: 12071)</i>	_____	\$ 5.00	_____
Pushbutton Switch (momentary) – Auto Null <i>(Order Code: 12056)</i>	_____	\$ 4.00	_____
Pushbutton Cap (gray) <i>(Order Code: 14207)</i>	_____	\$ 3.00	_____
Screw-On Bumper Kit (black, set of 8) <i>(Order Code: 31064)</i>	_____	\$10.00	_____
12 Vdc, 1.5 A Power Supply <i>(Order Code: PS-DC-02)</i>	_____	\$72.00	_____

---



	Qty	US List Price	Total
<b>Model 46 Interface (all Serial Numbers)</b>			
4-Position DIP Switch <i>(Order Code: 12071)</i>	_____	\$ 5.00	_____
Pushbutton Switch (momentary) – Auto Null <i>(Order Code: 12056)</i>	_____	\$ 4.00	_____
Pushbutton Cap (gray) <i>(Order Code: 14207)</i>	_____	\$ 3.00	_____

---

<b>Model 46A Interface (all Serial Numbers)</b>			
4-Position DIP Switch <i>(Order Code: 12071)</i>	_____	\$ 5.00	_____
Pushbutton Switch (momentary) – Auto Null <i>(Order Code: 12056)</i>	_____	\$ 4.00	_____
Pushbutton Cap (gray) <i>(Order Code: 14207)</i>	_____	\$ 3.00	_____

---

<b>Model 47 Interface (all Serial Numbers)</b>			
4-Position DIP Switch <i>(Order Code: 12071)</i>	_____	\$ 5.00	_____
Pushbutton Switch (momentary) – Auto Null <i>(Order Code: 12056)</i>	_____	\$ 4.00	_____
Pushbutton Cap (gray) <i>(Order Code: 14207)</i>	_____	\$ 3.00	_____

---

<b>Model 47A Interface (all Serial Numbers)</b>			
4-Position DIP Switch <i>(Order Code: 12071)</i>	_____	\$ 5.00	_____
Pushbutton Switch (momentary) – Auto Null <i>(Order Code: 12056)</i>	_____	\$ 4.00	_____
Pushbutton Cap (gray) <i>(Order Code: 14207)</i>	_____	\$ 3.00	_____

---

**Model 48D Dante Bridge (all Serial Numbers)**

Contact Factory as Required

---

**Model 72 Level Meter / Interface (all Serial Numbers)**

Self-Adhesive Rubber Bumpons (black, set of 4, 1/2" dia. by 0.138" tall) <i>(Order Code: 14028)</i>	_____	\$ 2.00	_____
---	-------	---------	-------

---

	Qty	US List Price	Total
<b>Model 51 Control Console (all Serial Numbers)</b>			
<b>Pushbutton Switch (momentary)</b> (Order Code: 12055) <i>Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND</i>	_____	\$ 4.00	_____
<b>Knob – Studio Level (black, push-on, 15 mm)</b> (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
<b>Knob Cap – Studio Level (black w/white line, 15 mm)</b> (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
<b>Potentiometer – Studio Level</b> (Order Code: 2054)	_____	\$12.00	_____
<b>Knob – Control Room Level (black, collet, 47 mm)</b> (Order Code: 14205) <i>Note: Knob and knob cap are sold separately. See 14206 for knob cap.</i>	_____	\$18.00	_____
<b>Knob Cap – Control Room Level (black w/white line, 47 mm)</b> (Order Code: 14206) <i>Note: Knob and knob cap are sold separately. See 14205 for knob.</i>	_____	\$ 4.00	_____
<b>Potentiometer – Control Room Level</b> (Order Code: 2122)	_____	\$12.00	_____
<b>Self-Adhesive Rubber Bumpons (black, set of 4, 1/2" dia. by 0.138" tall)</b> (Order Code: 14028)	_____	\$ 2.00	_____

---

**Model 56 Control Console (all Serial Numbers)**

<b>Pushbutton Switch (momentary)</b> (Order Code: 12055) <i>Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND</i>	_____	\$ 4.00	_____
<b>Knob – Control Room Level (black, collet, 38 mm)</b> (Order Code: 14209) <i>Note: Knob and knob cap are sold separately. See 14210 for knob cap.</i>	_____	\$14.00	_____
<b>Knob Cap – Control Room Level (black w/white line, 38 mm)</b> (Order Code: 14210) <i>Note: Knob and knob cap are sold separately. See 14209 for knob.</i>	_____	\$ 3.00	_____
<b>Potentiometer – Control Room Level</b> (Order Code: 2123)	_____	\$ 5.00	_____
<b>Self-Adhesive Rubber Bumpons (black, set of 4, 1/2" dia. by 0.138" tall)</b> (Order Code: 14028)	_____	\$ 2.00	_____

---

**Models 59 & 591 Control Console (all Serial Numbers)**

<b>Pushbutton Switch (momentary)</b> (Order Code: 12055) <i>Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND</i>	_____	\$ 4.00	_____
<b>Knob – Control Room Level (black, collet, 38 mm)</b> (Order Code: 14209) <i>Note: Knob and knob cap are sold separately. See 14210 for knob cap.</i>	_____	\$14.00	_____
<b>Knob Cap – Control Room Level (black w/white line, 38 mm)</b> (Order Code: 14210) <i>Note: Knob and knob cap are sold separately. See 14209 for knob.</i>	_____	\$ 3.00	_____
<b>Potentiometer – Control Room Level</b> (Order Code: 2123)	_____	\$ 5.00	_____
<b>Self-Adhesive Rubber Bumpons (black, set of 4, 1/2" dia. by 0.138" tall)</b> (Order Code: 14028)	_____	\$ 2.00	_____

---

	Qty	US List Price	Total
<b>Model 60 Central Controller (Serial Numbers 00200 – 00300)</b>			
1/4" Phone Jack (Order Code: 1086)	_____	\$ 4.00	_____
Dual 1/4" Phone Jack (Order Code: 1087)	_____	\$ 6.00	_____
Knob – Level (black, push-on, 15 mm) (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
Knob Cap – Level (black w/white line, 15 mm) (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
Potentiometer – Phones Level and Dub Level (Order Code: 2128)	_____	\$ 8.00	_____
Pushbutton Switch (push-push) (Order Code: 12016)	_____	\$ 3.00	_____
Pushbutton Switch Assembly (4-station) – Source (Order Code: 12061)	_____	\$16.00	_____
Pushbutton Cap (gray) (Order Code: 12050) <i>Mfg. No.: E-Switch TACGRY; Digi-Key No.: EG1082-ND</i>	_____	\$ 4.00	_____

**Model 60 Central Controller (Serial Numbers 00301 – later)**

1/4" Phone Jack (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
Nut (plastic) (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
Dual 1/4" Phone Jack (Order Code: 1113)	_____	\$ 7.00	_____
Knob – Level (black, push-on, 15 mm) (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
Knob Cap – Level (black w/white line, 15 mm) (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
Potentiometer – Phones Level and Dub Level (Order Code: 2128)	_____	\$ 8.00	_____
Pushbutton Switch (push-push) (Order Code: 12016)	_____	\$ 3.00	_____
Pushbutton Switch Assembly (4-station) – Source (Order Code: 12061)	_____	\$16.00	_____
Pushbutton Cap (gray) (Order Code: 12050) <i>Mfg. No.: E-Switch TACGRY; Digi-Key No.: EG1082-ND</i>	_____	\$ 4.00	_____

**Model 60A Central Controller (all Serial Numbers)**

1/4" Phone Jack (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
Nut (plastic) (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
Dual 1/4" Phone Jack (Order Code: 1168)	_____	\$ 7.00	_____
Knob – Level (black, push-on, 15 mm) (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
Knob Cap – Level (black w/white line, 15 mm) (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
Potentiometer – Phones Level and Dub Level (Order Code: 2128)	_____	\$ 8.00	_____
Pushbutton Switch (push-push) (Order Code: 12016)	_____	\$ 3.00	_____
Pushbutton Switch Assembly (4-station) – Source (Order Code: 12061)	_____	\$16.00	_____
Pushbutton Switch Assembly (3-station) – Switcher (Order Code: 12074)	_____	\$12.00	_____
Pushbutton Cap (gray) (Order Code: 12050) <i>Mfg. No.: E-Switch TACGRY; Digi-Key No.: EG1082-ND</i>	_____	\$ 4.00	_____

	Qty	US List Price	Total
<b>Model 61 Control Console (all Serial Numbers)</b>			
<b>Pushbutton Switch (momentary)</b> (Order Code: 12055) <i>Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND</i>	_____	\$ 4.00	_____
<b>Knob – Level (black, collet, 29 mm)</b> (Order Code: 14214) <i>Note: Knob and knob cap are sold separately. See 14215 for knob cap.</i>	_____	\$ 7.00	_____
<b>Knob Cap – Level (black w/white line, 29 mm)</b> (Order Code: 14215) <i>Note: Knob and knob cap are sold separately. See 14209 for knob.</i>	_____	\$ 3.00	_____
<b>Potentiometer – Level</b> (Order Code: 2123)	_____	\$ 5.00	_____
<b>Self-Adhesive Rubber Bumpons (black, set of 4, 1/2" dia. by 0.138" tall)</b> (Order Code: 14028)	_____	\$ 2.00	_____
<b>9-Pin Male D-Sub/9-Pin Male D-Sub Cable Assembly (overall length 20 feet/6.1 m)</b> (Order Code: 13179-20)	_____	\$19.00	_____

<b>Model 69 Control Console (all Serial Numbers)</b>			
<b>Pushbutton Switch (momentary)</b> (Order Code: 12055) <i>Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND</i>	_____	\$ 4.00	_____
<b>Knob – Level (black, collet, 38 mm)</b> (Order Code: 14209) <i>Note: Knob and knob cap are sold separately. See 14210 for knob cap.</i>	_____	\$14.00	_____
<b>Knob Cap – Level (black w/white line, 38 mm)</b> (Order Code: 14210) <i>Note: Knob and knob cap are sold separately. See 14209 for knob.</i>	_____	\$ 3.00	_____
<b>Potentiometer – Level</b> (Order Code: 2123)	_____	\$ 5.00	_____
<b>Self-Adhesive Rubber Bumpons (black, set of 4, 1/2" dia. by 0.138" tall)</b> (Order Code: 14028)	_____	\$ 2.00	_____
<b>9-Pin Male D-Sub/9-Pin Male D-Sub Cable Assembly (overall length 20 feet/6.1 m)</b> (Order Code: 13179-20)	_____	\$19.00	_____

<b>Model 69A Control Console (all Serial Numbers)</b>			
<b>Pushbutton Switch (momentary)</b> (Order Code: 12055) <i>Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND</i>	_____	\$ 4.00	_____
<b>Knob – Level (black, collet, 38 mm)</b> (Order Code: 14209) <i>Note: Knob and knob cap are sold separately. See 14210 for knob cap.</i>	_____	\$14.00	_____
<b>Knob Cap – Level (black w/white line, 38 mm)</b> (Order Code: 14210) <i>Note: Knob and knob cap are sold separately. See 14209 for knob.</i>	_____	\$ 3.00	_____
<b>Potentiometer – Level</b> (Order Code: 2123)	_____	\$ 5.00	_____
<b>Self-Adhesive Rubber Bumpons (black, set of 4, 1/2" dia. by 0.138" tall)</b> (Order Code: 14028)	_____	\$ 2.00	_____
<b>9-Pin Male D-Sub/9-Pin Male D-Sub Cable Assembly (overall length 20 feet/6.1 m)</b> (Order Code: 13179-20)	_____	\$19.00	_____

<b>Model 71 Control Console (all Serial Numbers)</b>			
<b>Pushbutton Switch (momentary)</b> (Order Code: 12055) <i>Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND</i>	_____	\$ 4.00	_____
<b>Knob – Level (black, collet, 29 mm)</b> (Order Code: 14214) <i>Note: Knob and knob cap are sold separately. See 14260 for knob cap.</i>	_____	\$ 7.00	_____
<b>Knob Cap – Level (black, 29 mm)</b> (Order Code: 14260) <i>Note: Knob and knob cap are sold separately. See 14214 for knob.</i>	_____	\$ 2.00	_____
<b>Rotary Encoder – Level</b> (Order Code: 12034)	_____	\$ 4.00	_____
<b>Self-Adhesive Rubber Bumpons (black, set of 4, 1/2" dia. by 0.138" tall)</b> (Order Code: 14028)	_____	\$ 2.00	_____
<b>9-Pin Male D-Sub/9-Pin Male D-Sub Cable Assembly (overall length 20 feet/6.1 m)</b> (Order Code: 13179-20)	_____	\$19.00	_____

	Qty	US List Price	Total
<b>Model 74 Central Controller (all Serial Numbers)</b>			
<b>3.5 mm Jack</b> (Order Code: 1315)	_____	\$ 4.00	_____
<hr/>			
<b>Model 75 Control Console (all Serial Numbers)</b>			
<b>Pushbutton Switch (momentary)</b> (Order Code: 12055)	_____	\$ 4.00	_____
<i>Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND</i>			
<b>Knob – Level (black, collet, 38 mm)</b> (Order Code: 14209)	_____	\$14.00	_____
<i>Note: Knob and knob cap are sold separately. See 14210 for knob cap.</i>			
<b>Knob Cap – Level (black w/white line, 38 mm)</b> (Order Code: 14210)	_____	\$ 3.00	_____
<i>Note: Knob and knob cap are sold separately. See 14209 for knob.</i>			
<b>Potentiometer Assembly – Level</b> (Order Code: 32089)	_____	\$12.00	_____
<b>Self-Adhesive Rubber Bumpons (black, set of 4, 1/2" dia. by 0.138" tall)</b> (Order Code: 14028)	_____	\$ 2.00	_____
<b>9-Pin Male D-Sub/9-Pin Male D-Sub Cable Assembly (overall length 20 feet/6.1 m)</b> (Order Code: 13179-20)	_____	\$19.00	_____
<hr/>			
<b>Model 76 Central Controller (all serial numbers)</b>			
<b>Capacitor (surface mount, aluminum electrolytic, 47 uF, 25 V)</b> (Order Code: 4975)	_____	\$ 2.00	_____
<i>Mfg. No.: Panasonic FK-Series, EEE-FK1E470P; Digi-Key No.: PCE3804, Mouser No. 667-EEE-FK1E4760P</i>			
<i>Alternate, Mfg. No.: Nichicon UUD-Series, UUD1E470MCL1GS; Digi-Key No. 4893-2273-2, Mouser No. 647-UUD1E470MCL</i>			
<i>Notes: For revision B circuit boards: C36, C73, C178, C193 (C193 is bypass for –15 volt DC rail and is most critical)</i>			
<i>For revision C circuit boards: C39, C76, C181, C196 (C196 is bypass for –15 volt DC rail and is most critical)</i>			
<hr/>			
<b>Model 76B Central Controller (all serial numbers)</b>			
<b>Capacitor (surface mount, aluminum electrolytic, 47 uF, 25 V)</b> (Order Code: 4975)	_____	\$ 2.00	_____
<i>Mfg. No.: Panasonic FK-Series, EEE-FK1E470P; Digi-Key No.: PCE3804, Mouser No. 667-EEE-FK1E4760P</i>			
<i>Alternate, Mfg. No.: Nichicon UUD-Series, UUD1E470MCL1GS; Digi-Key No. 4893-2273-2, Mouser No. 647-UUD1E470MCL</i>			
<i>Notes: For revision B circuit boards: C36, C73, C178, C193 (C193 is bypass for –15 volt DC rail and is most critical)</i>			
<i>For revision C circuit boards: C39, C76, C181, C196 (C196 is bypass for –15 volt DC rail and is most critical)</i>			
<hr/>			
<b>Model 77 Control Console (all Serial Numbers)</b>			
<b>Pushbutton Switch (momentary)</b> (Order Code: 12055)	_____	\$ 4.00	_____
<i>Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND</i>			
<b>Knob – Level (black, collet, 29 mm)</b> (Order Code: 14214)	_____	\$ 7.00	_____
<i>Note: Knob and knob cap are sold separately. See 14260 for knob cap.</i>			
<b>Knob Cap – Level (black, 29 mm)</b> (Order Code: 14260)	_____	\$ 2.00	_____
<i>Note: Knob and knob cap are sold separately. See 14214 for knob.</i>			
<b>Rotary Encoder Assembly – Level</b> (Order Code: 31378)	_____	\$ 9.00	_____
<b>Self-Adhesive Rubber Bumpons (black, set of 4, 1/2" dia. by 0.138" tall)</b> (Order Code: 14028)	_____	\$ 2.00	_____
<b>9-Pin Male D-Sub/9-Pin Male D-Sub Cable Assembly (overall length 20 feet/6.1 m)</b> (Order Code: 13179-20)	_____	\$19.00	_____
<hr/>			

	Qty	US List Price	Total
<b>Model 77B Control Console (all Serial Numbers)</b>			
<b>Pushbutton Switch (momentary)</b> (Order Code: 12055) <i>Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND</i>	_____	\$ 4.00	_____
<b>Knob – Level (black, collet, 29 mm)</b> (Order Code: 14214) <i>Note: Knob and knob cap are sold separately. See 14260 for knob cap.</i>	_____	\$ 7.00	_____
<b>Knob Cap – Level (black, 29 mm)</b> (Order Code: 14260) <i>Note: Knob and knob cap are sold separately. See 14214 for knob.</i>	_____	\$ 2.00	_____
<b>Rotary Encoder Assembly – Level</b> (Order Code: 31378)	_____	\$ 9.00	_____
<b>Self-Adhesive Rubber Bumpons (black, set of 4, 1/2" dia. by 0.138" tall)</b> (Order Code: 14028)	_____	\$ 2.00	_____
<b>9-Pin Male D-Sub/9-Pin Male D-Sub Cable Assembly (overall length 20 feet/6.1 m)</b> (Order Code: 13179-20)	_____	\$19.00	_____

<b>Model 79 Control Console (all Serial Numbers)</b>			
<b>Pushbutton Switch (momentary)</b> (Order Code: 12055) <i>Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND</i>	_____	\$ 4.00	_____
<b>Knob – Level (black, collet, 29 mm)</b> (Order Code: 14214) <i>Note: Knob and knob cap are sold separately. See 14215 for knob cap.</i>	_____	\$14.00	_____
<b>Knob Cap – Level (black w/white line, 29 mm)</b> (Order Code: 14215) <i>Note: Knob and knob cap are sold separately. See 14209 for knob.</i>	_____	\$ 3.00	_____
<b>Potentiometer – Level</b> (Order Code: 2123)	_____	\$ 5.00	_____
<b>Self-Adhesive Rubber Bumpons (black, set of 4, 1/2" dia. by 0.138" tall)</b> (Order Code: 14028)	_____	\$ 2.00	_____
<b>9-Pin Male D-Sub/9-Pin Male D-Sub Cable Assembly (overall length 20 feet/6.1 m)</b> (Order Code: 13179-20)	_____	\$19.00	_____

<b>Model 790 Control Console (all Serial Numbers)</b>			
<b>Pushbutton Switch (momentary)</b> (Order Code: 12055) <i>Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND</i>	_____	\$ 4.00	_____
<b>Knob – Level (black, collet, 29 mm)</b> (Order Code: 14214) <i>Note: Knob and knob cap are sold separately. See 14260 for knob cap.</i>	_____	\$ 7.00	_____
<b>Knob Cap – Level (black, 29 mm)</b> (Order Code: 14260) <i>Note: Knob and knob cap are sold separately. See 14214 for knob.</i>	_____	\$ 2.00	_____
<b>Rotary Encoder Assembly – Level</b> (Order Code: 31378)	_____	\$ 9.00	_____
<b>Self-Adhesive Rubber Bumpons (black, set of 4, 1/2" dia. by 0.138" tall)</b> (Order Code: 14028)	_____	\$ 2.00	_____
<b>9-Pin Male D-Sub/9-Pin Male D-Sub Cable Assembly (overall length 20 feet/6.1 m)</b> (Order Code: 13179-20)	_____	\$19.00	_____

**Qty**    **US List**    **Total**  
                  **Price**

**Model 92 DT12 Cable Assembly Test Unit (all Serial Numbers)**

**Rechargeable Battery, 12 V, 1.3 Ah** (Order Code: 10335)  
Mfg. No.: Panasonic LC-R121R3P; Digi-Key No.: P264-ND

Not available from factory

---

**Model 93 W1 Cable Assembly Test Unit (all Serial Numbers)**

**Rechargeable Battery, 12 V, 1.3 Ah** (Order Code: 10335)  
Mfg. No.: Panasonic LC-R121R3P; Digi-Key No.: P264-ND

Not available from factory

---

	Qty	US List Price	Total
<b>Model 200-Series Announcer's and Producer's Consoles (all Serial Numbers)</b>			
<b>Backlight LED for Models 214, 215, and 216 Announcer's Consoles and Model 240 Producer's Console</b> (Order Code: 3154)	_____	\$ 3.00	_____
<b>Button Cap, Lenses, and Label 15154 Kit (includes five each button caps, clear lens, frosted lens, and one set of button function labels)</b> (Order Code: 31069)	_____	\$40.00	_____
<b>Knob – Phones Level (black, push-on, 15 mm)</b> (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
<b>Knob Cap – Phones Level (black w/white line, 15 mm)</b> (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
<b>Potentiometer – Phones Level</b> (Order Code: 2127)	_____	\$ 5.00	_____
<b>DC Power Entry Jack Assembly (includes PCB, washer, and nut)</b> (Order Code: 32135) <i>Note: Requires cable assembly, sold separately. See 13690.</i>	_____	\$12.00	_____
<b>Cable Assembly for DC Power Entry Jack Assembly (2-conductor, 5-inch)</b> (Order Code: 13690)	_____	\$ 4.00	_____
<b>Screw-On Bumper Kit (black, set of 8)</b> (Order Code: 31064)	_____	\$10.00	_____
<b>Model 210 Security Plate</b> (Order Code: SP-M210)	_____	\$15.00	_____
<b>Model 211 Security Plate</b> (Order Code: SP-M211)	_____	\$15.00	_____
<b>Model 212 Security Plate</b> (Order Code: SP-M212)	_____	\$15.00	_____
<b>Model 214 Security Plate</b> (Order Code: SP-M214)	_____	\$15.00	_____
<b>Model 215 Security Plate</b> (Order Code: SP-M215)	_____	\$15.00	_____
<b>Model 216 Security Plate</b> (Order Code: SP-M216)	_____	\$15.00	_____
<b>Model 220 Security Plate</b> (Order Code: SP-M220)	_____	\$18.00	_____
<b>Model 230 Security Plate</b> (Order Code: SP-M230)	_____	\$18.00	_____
<b>Model 233 Security Plate</b> (Order Code: SP-M233)	_____	\$18.00	_____
<b>Model 240 Security Plate</b> (Order Code: SP-M240)	_____	\$18.00	_____
<b>24 Vdc, 0.75 A Power Supply</b> (Order Code: PS-DC-03)	_____	\$46.00	_____
<b>12 Vdc, 1.5 A Power Supply</b> (Order Code: PS-DC-02)	_____	\$72.00	_____
<hr/>			
<b>Model 204, Model 205 &amp; Model 206 Announcer's Consoles (all Serial Numbers)</b>			
<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
<b>Push-Pot Potentiometer Assembly (dual-section)</b> (Order Code: 32298) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
<b>Pushbutton Switch (momentary, 17 mm x 17 mm)</b> (Order Code: 12101)	_____	\$ 6.00	_____
<b>1/4" Phone Jack</b> (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
<b>Nut (plastic)</b> (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
<b>3.5 mm Stereo Jack</b> (Order Code: 1198)	_____	\$ 3.00	_____
<b>Self-Adhesive Rubber Bumpons (black, set of 4, 1/2" dia. by 0.138" tall)</b> (Order Code: 14028)	_____	\$ 2.00	_____



	Qty	US List Price	Total
<b>Model 207 eSports Consoles (all Serial Numbers)</b>			
<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
<b>Push-Pot Potentiometer Assembly (dual-section)</b> (Order Code: 32298) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
<b>Pushbutton Switch (momentary, 17 mm x 17 mm)</b> (Order Code: 12101)	_____	\$ 6.00	_____
<b>3.5 mm 4-Conductor (TRRS) Jack</b> (Order Code: 1410)	_____	\$ 5.00	_____
<b>Self-Adhesive Rubber Bumpons (black, set of 4, 1/2" dia. by 1/4" tall)</b> (Order Code: 14326)	_____	\$ 3.00	_____

**Model 208 Announcer's Console (all Serial Numbers)**

<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
<b>Push-Pot Potentiometer Assembly (dual-section)</b> (Order Code: 32298) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
<b>Switch Cap Adapter</b> (Order Code: 14294) <i>Note: Switch cap and switch cap adapter are sold separately. See 14295 for 12 mm switch cap.</i>	_____	\$ 1.50	_____
<b>Switch Cap (12 mm)</b> (Order Code: 14295) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____
<b>1/4" Phone Jack</b> (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
<b>Nut (plastic)</b> (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
<b>3.5 mm Stereo Jack</b> (Order Code: 1198)	_____	\$ 3.00	_____

**Model 348 Intercom Station (all Serial Numbers)**

<b>Knob-Glow (black w/clear center, 13 mm)</b> (Order Code: 14321)	_____	\$ 5.00	_____
<b>Rotary Encoder (24-step w/switch)</b> (Order Code: 12103)	_____	\$ 8.00	_____
<b>Pushbutton Switch (momentary, 17 mm x 17 mm)</b> (Order Code: 12101)	_____	\$ 6.00	_____
<b>3.5 mm 4-Conductor (TRRS) Jack</b> (Order Code: 1410)	_____	\$ 5.00	_____
<b>Loudspeaker (32 mm dia., 8 ohm)</b> (Order Code: 10701)	_____	\$22.00	_____
<b>Self-Adhesive Rubber Bumpons (black, set of 4, 1/2" dia. by 1/4" tall)</b> (Order Code: 14326)	_____	\$ 3.00	_____

**Model 362 Listen-Only Beltpack (all Serial Numbers)**

<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
<b>Push-Pot Potentiometer Assembly (dual-section)</b> (Order Code: 32298) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
<b>1/4" Phone Jack</b> (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
<b>Nut (plastic)</b> (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____

	Qty	US List Price	Total
<b>Model 370 Intercom Beltpack (all Serial Numbers)</b>			
<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
<b>Push-Pot Potentiometer Assembly (dual-section)</b> (Order Code: 32298) (for s/n 00151-02000) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
<b>Push-Pot Potentiometer Assembly (single-section)</b> (Order Code: 32299) (for s/n 02001-later) <i>Note: Includes push-pot (2172) and sleeve (14297).</i>	_____	\$ 9.00	_____
<b>Trim Potentiometer (for sidetone)</b> (Order Code: 2119) <i>Note: Plastic shaft sold separately. See 14307.</i>	_____	\$ 4.00	_____
<b>Plastic Shaft (gray, for sidetone trim pot)</b> (Order Code: 14307)	_____	\$ 3.00	_____
<b>Switch Cap Adapter</b> (Order Code: 14294) <i>Note: Switch cap and switch cap adapter are sold separately. See 14295 for 12 mm switch cap and 14296 for 10 mm switch cap.</i>	_____	\$ 1.50	_____
<b>Switch Cap – Talk (12 mm square)</b> (Order Code: 14295) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____
<b>Switch Cap – Call (10 mm square)</b> (Order Code: 14296) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____

---

**Model 370A Intercom Beltpack (all Serial Numbers)**

<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
<b>Push-Pot Potentiometer Assembly (dual-section)</b> (Order Code: 32298) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
<b>Switch Cap Adapter</b> (Order Code: 14294) <i>Note: Switch cap and switch cap adapter are sold separately. See 14295 for 12 mm switch cap and 14296 for 10 mm switch cap.</i>	_____	\$ 1.50	_____
<b>Switch Cap – Talk (12 mm square)</b> (Order Code: 14295) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____
<b>Switch Cap – Call (10 mm square)</b> (Order Code: 14296) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____

---

	Qty	US List Price	Total
<b>Model 371 Intercom Beltpack (all Serial Numbers)</b>			
<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
<b>Push-Pot Potentiometer Assembly (single-section)</b> (Order Code: 32299) <i>Note: Includes push-pot (2172) and sleeve (14297).</i>	_____	\$ 9.00	_____
<b>Trim Potentiometer (for sidetone)</b> (Order Code: 2119) <i>Note: Plastic shaft sold separately. See 14307.</i>	_____	\$ 4.00	_____
<b>Plastic Shaft (gray, for sidetone trim pot)</b> (Order Code: 14307)	_____	\$ 3.00	_____
<b>Switch Cap Adapter</b> (Order Code: 14294) <i>Note: Switch cap and switch cap adapter are sold separately. See 14295 for 12 mm switch cap and 14296 for 10 mm switch cap.</i>	_____	\$ 1.50	_____
<b>Switch Cap – Talk (12 mm square)</b> (Order Code: 14295) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____
<b>Switch Cap – Call (10 mm square)</b> (Order Code: 14296) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____

---

**Model 371A Intercom Beltpack (all Serial Numbers)**

<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
<b>Push-Pot Potentiometer Assembly (dual-section)</b> (Order Code: 32298) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
<b>Switch Cap Adapter</b> (Order Code: 14294) <i>Note: Switch cap and switch cap adapter are sold separately. See 14295 for 12 mm switch cap and 14296 for 10 mm switch cap.</i>	_____	\$ 1.50	_____
<b>Switch Cap – Talk (12 mm square)</b> (Order Code: 14295) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____
<b>Switch Cap – Call (10 mm square)</b> (Order Code: 14296) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____

---

**Model 372A Intercom Beltpack (all Serial Numbers)**

<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
<b>Push-Pot Potentiometer Assembly (dual-section)</b> (Order Code: 32298) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
<b>Switch Cap Adapter</b> (Order Code: 14294) <i>Note: Switch cap and switch cap adapter are sold separately. See 14295 for 12 mm switch cap.</i>	_____	\$ 1.50	_____
<b>Switch Cap – Talk (12 mm square)</b> (Order Code: 14295) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____

---

	Qty	US List Price	Total
<b>Model 373A Intercom Beltpack (all Serial Numbers)</b>			
<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
<b>Push-Pot Potentiometer Assembly (dual-section)</b> (Order Code: 32298) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
<b>Switch Cap Adapter</b> (Order Code: 14294) <i>Note: Switch cap and switch cap adapter are sold separately. See 14295 for 12 mm switch cap.</i>	_____	\$ 1.50	_____
<b>Switch Cap – Talk (12 mm square)</b> (Order Code: 14295) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____

---

**Model 374 Intercom Beltpack (all Serial Numbers)**

<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
<b>Push-Pot Potentiometer Assembly (dual-section)</b> (Order Code: 32298) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
<b>Trim Potentiometer (for sidetone)</b> (Order Code: 2119) <i>Note: Plastic shaft sold separately. See 14307.</i>	_____	\$ 4.00	_____
<b>Plastic Shaft (gray, for sidetone trim pot)</b> (Order Code: 14307)	_____	\$ 3.00	_____
<b>Switch Cap Adapter</b> (Order Code: 14294) <i>Note: Switch cap and switch cap adapter are sold separately. See 14296 for 10 mm switch cap.</i>	_____	\$ 1.50	_____
<b>Switch Cap (10 mm square)</b> (Order Code: 14296) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____

---

**Model 374A Intercom Beltpack (all Serial Numbers)**

<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
<b>Push-Pot Potentiometer Assembly (dual-section)</b> (Order Code: 32298) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
<b>Switch Cap Adapter</b> (Order Code: 14294) <i>Note: Switch cap and switch cap adapter are sold separately. See 14296 for 10 mm switch cap.</i>	_____	\$ 1.50	_____
<b>Switch Cap (10 mm square)</b> (Order Code: 14296) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____

---

	Qty	US List Price	Total
<b>Model 380 On-Air Backpack (all Serial Numbers)</b>			
<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
<b>Push-Pot Potentiometer Assembly (dual-section)</b> (Order Code: 32298) (for s/n 00151-01000) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
<b>Push-Pot Potentiometer Assembly (single-section)</b> (Order Code: 32299) (for s/n 01001-later) <i>Note: Includes push-pot (2172) and sleeve (14297).</i>	_____	\$ 9.00	_____
<b>1/4" Phone Jack</b> (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
<b>Nut (plastic)</b> (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
<b>Switch Cap Adapter</b> (Order Code: 14294) <i>Note: Switch cap and switch cap adapter are sold separately. See 14295 for 12 mm switch cap.</i>	_____	\$ 1.50	_____
<b>Switch Cap (12 mm)</b> (Order Code: 14295) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____

---

**Model 381 On-Air Backpack (all Serial Numbers)**

<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
<b>Push-Pot Potentiometer Assembly (dual-section)</b> (Order Code: 32298) (for s/n 00151-01000) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
<b>1/4" Phone Jack</b> (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
<b>Nut (plastic)</b> (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
<b>Switch Cap Adapter</b> (Order Code: 14294) <i>Note: Switch cap and switch cap adapter are sold separately. See 14295 for 12 mm switch cap.</i>	_____	\$ 1.50	_____
<b>Switch Cap (12 mm)</b> (Order Code: 14295) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____

---

**Model 391 Dante Alerting Unit (all Serial Numbers)**

<b>Pushbutton Switch (momentary) – Mode</b> (Order Code: 12056)	_____	\$ 4.00	_____
<b>Pushbutton Cap (gray)</b> (Order Code: 14207)	_____	\$ 3.00	_____
<b>Screw-On Bumper Kit (black, set of 8)</b> (Order Code: 31064)	_____	\$10.00	_____
<b>Trim Potentiometer</b> (Order Code: 2119) <i>Note: Plastic shaft sold separately. See 14307.</i>	_____	\$ 4.00	_____
<b>Plastic Shaft (gray, for trim pot)</b> (Order Code: 14307)	_____	\$ 3.00	_____

---

	Qty	US List Price	Total
<b>Model 400 SDI-Over-Fiber Transport Systems (all Serial Numbers)</b>			
<b>Pushbutton Switch (momentary)</b> (Order Code: 12055) <i>Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND</i>	_____	\$ 4.00	_____
<b>Display Assembly</b> (Order Code: 31579)	_____	\$122.00	_____
<b>Display Lens</b> (Order Code: 15203)	_____	\$ 4.00	_____

<b>Model 410 SDI-Over-Fiber Transport Systems (all Serial Numbers)</b>			
<b>Pushbutton Switch (momentary)</b> (Order Code: 12055) <i>Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND</i>	_____	\$ 4.00	_____
<b>Display Assembly</b> (Order Code: 31601)	_____	\$122.00	_____
<b>Display Lens</b> (Order Code: 15203)	_____	\$ 4.00	_____
<b>Screw-On Bumper Kit (black, set of 8)</b> (Order Code: 31064)	_____	\$ 10.00	_____
<b>12 Vdc, 1.5 A Power Supply</b> (Order Code: PS-DC-02)	_____	\$ 72.00	_____

<b>Model 412 Fiber Transport Systems (all Serial Numbers)</b>			
<b>Pushbutton Switch (momentary)</b> (Order Code: 12055) <i>Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND</i>	_____	\$ 4.00	_____
<b>Display Assembly</b> (Order Code: 31601)	_____	\$122.00	_____
<b>Display Lens</b> (Order Code: 15203)	_____	\$ 4.00	_____
<b>Screw-On Bumper Kit (black, set of 8)</b> (Order Code: 31064)	_____	\$ 10.00	_____
<b>12 Vdc, 1.5 A Power Supply</b> (Order Code: PS-DC-02)	_____	\$ 72.00	_____

	Qty	US List Price	Total
<b>Model 742 Audio Mixer (all Serial Numbers)</b>			
<b>Knob – Inputs 1-8 (black, push-on, 15 mm)</b> (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
<b>Knob Cap – Inputs 1-8 (black w/white line, 15 mm)</b> (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
<b>Potentiometer – Inputs 1-4</b> (Order Code: 2145)	_____	\$ 4.00	_____
<b>Potentiometer – Inputs 5-8</b> (Order Code: 2166)	_____	\$ 4.00	_____
<b>Potentiometer – Master and Monitor (dual-shaft)</b> (Order Code: 2167)	_____	\$12.00	_____
<b>Knob (Top) – Master and Monitor (black w/white line, 11 mm)</b> (Order Code: 14253) <i>Note: Knob (top), knob cap (top), and knob (bottom) are sold separately. See 14255 for knob cap (top) and 14254 for knob (bottom).</i>	_____	\$ 3.00	_____
<b>Knob Cap (Top) – Master and Monitor (black w/white line, 11 mm)</b> (Order Code: 14255) <i>Note: Knob (top), knob cap (top), and knob (bottom) are sold separately. See 14253 for knob (top) and 14254 for knob (bottom).</i>	_____	\$ 3.00	_____
<b>Knob (Bottom) – Master and Monitor (black w/white line, 15 mm)</b> (Order Code: 14254) <i>Note: Knob (top), knob cap (top), and knob (bottom) are sold separately. See 14253 for knob (top) and 14255 for knob cap (top).</i>	_____	\$ 4.00	_____

---

**Model 742A Audio Mixer (all Serial Numbers)**

<b>4-Position DIP Switch</b> (Order Code: 12071)	_____	\$ 5.00	_____
<b>Knob – Inputs 1-8 (black, push-on, 15 mm)</b> (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
<b>Knob Cap – Inputs 1-8 (black w/white line, 15 mm)</b> (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
<b>Potentiometer – Inputs 1-4</b> (Order Code: 2145)	_____	\$ 4.00	_____
<b>Potentiometer – Inputs 5-8</b> (Order Code: 2166)	_____	\$ 4.00	_____
<b>Potentiometer – Master and Monitor (dual-shaft)</b> (Order Code: 2167)	_____	\$12.00	_____
<b>Knob (Top) – Master and Monitor (black w/white line, 11 mm)</b> (Order Code: 14253) <i>Note: Knob (top), knob cap (top), and knob (bottom) are sold separately. See 14255 for knob cap (top) and 14254 for knob (bottom).</i>	_____	\$ 3.00	_____
<b>Knob Cap (Top) – Master and Monitor (black w/white line, 11 mm)</b> (Order Code: 14255) <i>Note: Knob (top), knob cap (top), and knob (bottom) are sold separately. See 14253 for knob (top) and 14254 for knob (bottom).</i>	_____	\$ 3.00	_____
<b>Knob (Bottom) – Master and Monitor (black w/white line, 15 mm)</b> (Order Code: 14254) <i>Note: Knob (top), knob cap (top), and knob (bottom) are sold separately. See 14253 for knob (top) and 14255 for knob cap (top).</i>	_____	\$ 4.00	_____

---

**Model 5100-Series Broadcast Support Modules (all Serial Numbers)**

Contact Factory as Required

---

	Qty	US List Price	Total
<b>Model 5202 Dante to Phones and Line Output Interface (all Serial Numbers)</b>			
<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
<b>Push-Pot Potentiometer Assembly (dual-section)</b> (Order Code: 32298) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
<b>1/4" Phone Jack</b> (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
<b>Nut (plastic)</b> (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____

<b>Model 5204 Dual Line Input to Dante Interface (all Serial Numbers)</b>			
<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
<b>Push-Pot Potentiometer Assembly (dual-section)</b> (Order Code: 32298) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____

<b>Model 5330 Flex-Use Dante Audio Interface (all Serial Numbers)</b>			
<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
<b>Push-Pot Potentiometer Assembly (dual-section)</b> (Order Code: 32298) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
<b>1/4" Phone Jack</b> (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
<b>Nut (plastic)</b> (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____

<b>Model 5401 Dante Master Clock (all Serial Numbers)</b>			
<b>Contact Factory as Required</b>			



	Qty	US List Price	Total
<b>Model 5414 Mic/Line Input &amp; Line Output Interface (all Serial Numbers)</b>			
<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
<b>Push-Pot Potentiometer Assembly (dual-section)</b> (Order Code: 32298) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
<b>Pushbutton Switch (momentary) – Channel Select</b> (Order Code: 12056)	_____	\$ 4.00	_____
<b>Pushbutton Cap (gray)</b> (Order Code: 14207)	_____	\$ 3.00	_____
<b>1/4" Phone Jack</b> (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
<b>Nut (plastic)</b> (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____

---

**Model 5415 & MD-4 Mic/Line Input & Line Output Interface (all Serial Numbers)**

<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
<b>Push-Pot Potentiometer Assembly (single-section)</b> (Order Code: 32299) <i>Note: Includes push-pot (2172) and sleeve (14297).</i>	_____	\$ 9.00	_____
<b>Pushbutton Switch (momentary) – Channel Select</b> (Order Code: 12056)	_____	\$ 4.00	_____
<b>Pushbutton Cap (gray)</b> (Order Code: 14207)	_____	\$ 3.00	_____
<b>1/4" Phone Jack</b> (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
<b>Nut (plastic)</b> (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____

---

**Model 5422-Series Dante Audio Intercom Engines (all Serial Numbers)**

Contact Factory as Required

---

	Qty	US List Price	Total
<b>Live-Link Remote Camera Interface Systems (all Serial Numbers)</b>			
<b>Rack-Ready Cover</b> (Order Code: LL-COVER-02)	_____	\$150.00	_____
<b>Portable Cover</b> (Order Code: 31355) <i>Note: Does not include lifting handle, battery bracket, bumpers, or hardware.</i>	_____	\$150.00	_____
<b>Portable Cover Assembly</b> (Order Code: LL-COVER-01) <i>Note: Consists of portable cover with lifting handle, Anton-Bauer Bracket Kit, and bumpers installed.</i>	_____	\$303.00	_____
<b>Lifting Handle Kit (black lifting handle and set of 6 6-32x1/4" screws)</b> (Order Code: 32204)	_____	\$ 26.00	_____
<b>Anton-Bauer Battery Bracket Kit (battery bracket w/insulator and 15" cable assembly)</b> (Order Code: 31414)	_____	\$115.00	_____
<b>Back of Cover Bumper Kit (set of 4 each 3/4" dia. by 5/8" tall bumpers, 10-24x3/4" screws, and 10-24 nylock nuts)</b> (Order Code: 32297) <i>Note: Used for back of portable enclosure.</i>	_____	\$ 12.00	_____
<b>Chassis Bumper Kit (set of 4 each 1.5" dia. by 3/4" tall bumpers, 80918-.708 screws, and 1/4-20 Keps nuts)</b> (Order Code: 32203) <i>Note: Used for bottom of portable enclosure.</i>	_____	\$ 16.00	_____
<b>12 Vdc, 5 A Power Supply</b> (Order Code: PS-DC-01)	_____	\$ 92.00	_____
<b>Audio Cable (XLR5M to XLR3F/XLR3M)</b> (Order Code: 13662)	_____	\$ 42.00	_____
<b>10/100/1000 Ethernet Media Converter Upgrade Kit</b> (Order Code: M432-KIT)	_____	\$240.00	_____

### Live-Link Jr. Remote Camera Interface Systems (all Serial Numbers)

<b>Pushbutton Switch (momentary) – Auto Null</b> (Order Code: 12056)	_____	\$ 4.00	_____
<b>Pushbutton Cap – Truck End Auto Null (gray)</b> (Order Code: 14207)	_____	\$ 3.00	_____
<b>Chassis Bumper Kit (set of 4 each 3/4" dia. by 3/8" tall bumpers and 6-32x3/8" screws)</b> (Order Code: 32202) <i>Note: Used for bottom of portable enclosure.</i>	_____	\$ 12.00	_____
<b>Lifting Handle Kit (black lifting handle and set of 6 6-32x1/4" screws)</b> (Order Code: 32204)	_____	\$ 26.00	_____
<b>12 Vdc, 5 A Power Supply</b> (Order Code: PS-DC-01)	_____	\$ 92.00	_____

### Live-Link Mini Remote Camera Interface Systems (all Serial Numbers)

<b>Pushbutton Switch (momentary) – Auto Null</b> (Order Code: 12056)	_____	\$ 4.00	_____
<b>Pushbutton Cap – Camera End and Truck End Auto Null (gray)</b> (Order Code: 14207)	_____	\$ 3.00	_____
<b>Chassis Bumper Kit (set of 4 each 5/8" dia. by 3/4" tall bumpers and 6-32x5/8" screws)</b> (Order Code: 32205) <i>Note: Used for bottom of portable enclosure.</i>	_____	\$ 12.00	_____
<b>Lifting Handle Kit (black lifting handle and set of 6 6-32x1/4" screws)</b> (Order Code: 32204)	_____	\$ 26.00	_____
<b>12 Vdc, 5 A Power Supply</b> (Order Code: PS-DC-01)	_____	\$ 92.00	_____
<b>Audio Cable (XLR5F to Dual XLR3M)</b> (Order Code: 13684)	_____	\$ 42.00	_____

### Miscellaneous Parts

<b>Belt Clip (black, steel)</b> (Order Code: 30247)	_____	\$ TBD	_____
<b>Pop-Rivet – for Belt Clip (black, aluminum, 0.125" grip)</b> (Order Code: 8201-.125)	_____	\$ TBD	_____
<b>Machine Screw – for Belt Clip (black, 6-32x1/4")</b> (Order Code: 8054-1/4)	_____	\$ TBD	_____
<b>Pushbutton Switch (momentary, EAO) – M200-Series, M22, M24</b> (Order Code: 12028)	_____	\$ TBD	_____

### Notes:

Prices effective March 21, 2019. Subject to change without notice.