




* ALLOWS P12 AND P48 PHANTOM POWER TO PASS FROM MICROPHONE OUTPUT TO MICROPHONE INPUT. INTERNAL P48 PHANTOM SUPPLY IS RECOMMENDED FOR OPTIMAL PERFORMANCE.

MODELS 204/205/206 ANNOUNCER'S CONSOLES
MICROPHONE INPUT AND OUTPUT
SIMPLIFIED BLOCK DIAGRAM