



# Model 5482 Front-Panel Menu Structure

## Button-Controlled Menus



### Screensaver



### Notes:

1. Screen saver automatically enables two minutes after last button press.
2. Simultaneously pressing left and right buttons enables screen saver.
3. Menu icon definitions:  
 ↵ = Enter for info or config  
 [E] = Value cannot be edited