



Model 5401A Front-Panel Menu Structure



Screen Saver (each screen active for approximately three seconds)



1. Screen saver automatically activates two minutes after last button press.
2. Press left and right buttons simultaneously to immediately enter screen saver mode.
3. Pressing Enter while screen saver is active goes directly to Current Management IP Address page.
4. This reflects operation for Model 5401A Main MCU firmware version 1.03 and later.