



# Replacement Parts List

All prices effective January 25, 2023. Subject to change without notice. Parts availability subject to factory stock levels. Certain parts may become obsolete without notice.

## Table of Contents

Page	Product	Page	Product
3	Model 2 Central Controller (all S/N)	12	Model 69 Control Console (all S/N)
3	Model 2A Central Controller (all S/N)	12	Model 69A Control Console (all S/N)
3	Model 22 Access Station (all S/N)	12	Model 71 Control Console (all S/N)
3	Model 24 Access Station (all S/N)	12	Model 74 Central Controller (all S/N)
4	Model 32 Talent Amplifier (S/N 00001 - 00299)	12	Model 75 Control Console (all S/N)
4	Model 32 Talent Amplifier (S/N 00300 - later)	13	Model 76 Central Controller (all S/N)
4	Model 32A Talent Amplifier (all S/N)	13	Model 76B Central Controller (all S/N)
5	Model 33 Talent Amplifier (all S/N)	13	Model 76D Central Controller (all S/N)
5	Model 33A Talent Amplifier (all S/N)	13	Model 76DA Central Controller (all S/N)
5	Model 34 Talent Amplifier (all S/N)	13	Model 77 Control Console (all S/N)
6	Model 35 Talent Amplifier (S/N 00001 - 00385)	13	Model 77B Control Console (all S/N)
6	Model 35 Talent Amplifier (S/N 00386 - later)	14	Model 79 Control Console (all S/N)
6	Model 36 Talent Interface (all S/N)	14	Model 760-Series Central Controllers (all S/N)
6	Model 37 Intercom Beltpack (all S/N)	14	Model 780-Series Central Controllers (all S/N)
7	Model 41 Interface (S/N 00151 - 01050)	14	Model 790 Control Console (all S/N)
7	Model 41 Interface (S/N 01051 - later)	14	Model 792 Central Controller (all S/N)
7	Model 42A Interface (all S/N)	14	Model 793 Control Console (all S/N)
7	Model 43D IFB Interface (all S/N)	15	Model 92 DT12 Cable Assembly Test Unit (all S/N)
7	Model 44D Audio Interface (all S/N)	15	Model 93 W1 Cable Assembly Test Unit (all S/N)
7	Model 45 Interface (all S/N)	16	Model 201 Interpreter's Console (all S/N)
8	Model 45A Interface (all S/N)	16	Models 210, 211, 212, 220, 230, and 233 Announcer's Consoles (all S/N)
8	Model 45DC Intercom Interface (all S/N)	17	Model 240 Producer's Console (all S/N)
8	Model 45DR Intercom Interface (all S/N)	17	Models 203, 204, 205, and 206 Announcer's Consoles (all S/N)
8	Model 544D Intercom Interface (all S/N)	17	Model 207 eSports Console (all S/N)
8	Model 545DC Intercom Interface (all S/N)	18	Model 207A eSports Console (all S/N)
8	Model 545DR Intercom Interface (all S/N)	18	Model 208 Announcer's Console (all S/N)
8	Model 46 Interface (all S/N)	18	Model 209 Talent Console (all S/N)
8	Model 46A Interface (all S/N)	19	Models 214, 215, and 216 Announcer's Consoles (all S/N)
8	Model 47 Interface (all S/N)	19	Models 214A, 215A, and 216A Announcer's Consoles (all S/N)
8	Model 47A Interface (all S/N)	20	Models 232, 234, and 236 Announcer's Consoles (all S/N)
9	Model 48D Dante Bridge (all S/N)	20	Model 348 Intercom Station (all S/N)
9	Model 72 Level Meter / Interface (all S/N)	20	Model 354 Talk Station (all S/N)
10	Model 51 Control Console (all S/N)	21	Model 354A Talk Station (all S/N)
10	Model 56 Control Console (all S/N)	21	GME-3-12 Gooseneck Microphone
10	Models 59 and 591 Control Consoles (all S/N)	21	Model 362 Listen-Only Beltpack (all S/N)
10	Model 60 Central Controller (S/N 00200 - 00300)	21	Model 362A Listen-Only Beltpack (all S/N)
11	Model 60 Central Controller (S/N 00301 - later)	22	Model 370 Intercom Beltpack (all S/N)
11	Model 60A Central Controller (all S/N)	22	Model 370A Intercom Beltpack (all S/N)
11	Model 61 Control Console (all S/N)		

## Table of Contents, continued

Page	Product
23	Model 371 Intercom Beltpack (all S/N)
23	Model 371A Intercom Beltpack (all S/N)
23	Model 372A Intercom Beltpack (all S/N)
24	Model 373A Intercom Beltpack (all S/N)
24	Model 374 Intercom Beltpack (all S/N)
24	Model 374A Intercom Beltpack (all S/N)
25	Model 380 On-Air Beltpack (all S/N)
25	Model 381 On-Air Beltpack (all S/N)
25	Model 391 Dante Alerting Unit (all S/N)
25	Model 392 Visual Indicator Unit (all S/N)
26	Model 400 SDI-Over-Fiber Transport Systems (all S/N)
27	Model 410 SDI-Over-Fiber Transport Systems (all S/N)
27	Model 412 Fiber Transport Systems (all S/N)
28	Model 742 Audio Mixer (all S/N)
28	Model 742A Audio Mixer (all S/N)
28	Model 750 Audio Mixer (S/N 00151 - 00400)
29	Model 750 Audio Mixer (S/N 00401 - later)
30	Model 5100-Series Broadcast Support Modules (all S/N)
30	Model 5202 Dante to Phones & Line Output Interface (all S/N)
30	Model 5204 Dual Line Input to Dante Interface (all S/N)
30	Model 5304 Intercom Station (all S/N)
30	Model 5330 Flex-Use Dante Audio Interface (all S/N)
30	Model 5364 Headset Interface (all S/N)
31	Model 5401 Dante Master Clock (all S/N)
31	Model 5401A Dante Leader Clock (all S/N)
31	Model 5402 Dante Leader Clock with GNSS Synchronization (all S/N)
31	Model 5412-Series Audio Interfaces (all S/N)
31	Model 5414 Mic/Line Input & Line Output Interface (all S/N)
31	MD-4 Mic/Line Input & Line Output Interface (all S/N)
32	Model 5418 Mic/Line Interface (all S/N)
32	Model 5421 Dante Intercom Audio Engine (all S/N)
32	Model 5422-Series Dante Intercom Audio Engines (all S/N)
32	Model 5422A-Series Dante Intercom Audio Engines (all S/N)
33	Model 5512-Series Audio Interfaces (all S/N)
33	Model 5518 Mic/Line Interface (all S/N)
34	Live-Link Sr. Remote Camera Interface Systems (all S/N)
34	Live-Link Jr. Remote Camera Interface Systems (all S/N)
34	Live-Link Mini Remote Camera Interface Systems (all S/N)
35	Live-Link Miscellaneous Parts
36	Miscellaneous Parts

	Qty	US List Price	Total
<b>Model 2 Central Controller (all Serial Numbers)</b>			
<b>Knob – Program and Monitor Output (black, push-on, 15 mm)</b> (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
<b>Knob Cap – Program and Monitor Output (black w/white line, 15 mm)</b> (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
<b>Pushbutton Cap (gray)</b> (Order Code: 12050) <i>Mfg. No.: E-Switch TACGRY; Digi-Key No.: EG1082-ND</i>	_____	\$ 4.00	_____
<b>Potentiometer – Program 1, Program 2, Monitor Output</b> (Order Code: 2126)	_____	\$ 4.00	_____
<b>Pushbutton Switch (momentary) – IFB 1, IFB 2</b> (Order Code: 12064)	_____	\$ 4.00	_____
<b>Pushbutton Switch Assembly (6-position, interlock) – Program Select</b> (Order Code: 12036)	_____	\$12.00	_____
<b>Toggle Switch – VOX IFB Input Select</b> (Order Code: 12054)	_____	\$26.00	_____
<b>Toggle Switch – VOX IFB Output Select</b> (Order Code: 12052)	_____	\$22.00	_____
<b>Toggle Switch (momentary) – Telco 1, Telco 2, Manual Off-Hook/Hang-Up Select</b> (Order Code: 12053)	_____	\$22.00	_____
<b>Toggle Switch – Telco 2 Send/Rcv and Monitor Source Select</b> (Order Code: 12051)	_____	\$22.00	_____
<b>Pushbutton Switch (push-push) – Telco Std/Wet 1, Telco Std/Wet 2</b> (Order Code: 12016)	_____	\$ 3.00	_____

### Model 2A Central Controller (all Serial Numbers)

<b>Knob – Program and Monitor Output (black, push-on, 15 mm)</b> (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
<b>Knob Cap – Program and Monitor Output (black w/white line, 15 mm)</b> (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
<b>Pushbutton Cap (gray)</b> (Order Code: 12050) <i>Mfg. No.: E-Switch TACGRY; Digi-Key No.: EG1082-ND</i>	_____	\$ 4.00	_____
<b>Potentiometer – Program 1, Program 2, Monitor Output</b> (Order Code: 2126)	_____	\$ 4.00	_____
<b>Pushbutton Switch (momentary) – IFB 1, IFB 2</b> (Order Code: 12064)	_____	\$ 4.00	_____
<b>Pushbutton Switch Assembly (6-position, interlock) – Program Select</b> Order Code: 12036)	_____	\$12.00	_____
<b>Toggle Switch (momentary) – Telco 1, Telco 2, Manual Off-Hook/Hang Up Select</b> (Order Code: 12093)	_____	\$ 9.00	_____
<b>Toggle Switch – VOX IFB, Telco 2 Send/Rcv, Monitor Source Select</b> (Order Code: 12091)	_____	\$ 9.00	_____
<b>Pushbutton Switch (push-push) – Telco Std/Wet 1, Telco Std/Wet 2</b> (Order Code: 12016)	_____	\$ 3.00	_____
<b>Power Supply (universal AC mains input/12 V, 3.34 A (40 watts) output)</b> (Order Code: 10303) <i>Mfg. No.: Cincon CFM40S120; Digi-Key No.: 2034-3674-ND; Mouser No.: 418-CFM40S120</i>	_____	\$45.00	_____

### Model 22 Access Station (all Serial Numbers)

<b>Pushbutton Switch (momentary, Mfg. by EAO)</b> (Order Code: 12028) <i>Note: Does not include button cap, lens, or label. See 31069.</i>	_____	\$14.00	_____
<b>Button Cap, Lenses, and Label Kit (includes five each button caps, clear lens, frosted lens, and one button function label sheet (15154))</b> (Order Code: 31069)	_____	\$40.00	_____
<b>Backlight Lamp (T1, 18 V, incandescent)</b> (Order Code: 12030)	_____	\$ 4.00	_____

### Model 24 Access Station (all Serial Numbers)

<b>Pushbutton Switch (momentary, Mfg. by EAO)</b> (Order Code: 12028) <i>Note: Does not include button cap, lens, or label. See 31069.</i>	_____	\$14.00	_____
<b>Button Cap, Lenses, and Label Kit (includes five each button caps, clear lens, frosted lens, and one button function label sheet (15154))</b> (Order Code: 31069)	_____	\$40.00	_____
<b>Backlight Lamp (T1, 18 V, incandescent)</b> (Order Code: 12030)	_____	\$ 4.00	_____

	Qty	US List Price	Total
<b>Model 32 Talent Amplifier (Serial Numbers 00001 – 00299)</b>			
<b>Knob (black, push-on, 15 mm)</b> (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
<b>Knob Cap (black w/white line, 15 mm)</b> (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
<b>Potentiometer</b> (Order Code: 2148)	_____	\$ 4.00	_____
<b>Toggle Switch – Ch 1/2 Select</b> (Order Code: 12021)	_____	\$ 6.00	_____
<b>3-Pin Male XLR Connector</b> (Order Code: 1093)	_____	\$ 7.00	_____
<b>3-Pin Female XLR Connector</b> (Order Code: 1094)	_____	\$ 8.00	_____
<b>1/4" Phone Jack</b> (Order Code: 1053)	_____	\$ 7.00	_____
<b>Belt Clip (black, steel)</b> (Order Code: 30247)	_____	\$ 5.00	_____
<b>Pop-Rivet – for Belt Clip (black, aluminum, 0.125" grip)</b> (Order Code: 8201-.125)	_____	\$ 1.00	_____

<b>Model 32 Talent Amplifier (Serial Numbers 00300 – later)</b>			
<b>Knob (black, push-on, 15 mm)</b> (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
<b>Knob Cap (black w/white line, 15 mm)</b> (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
<b>Potentiometer</b> (Order Code: 2148)	_____	\$ 4.00	_____
<b>Toggle Switch – Ch 1/2 Select</b> (Order Code: 12021)	_____	\$ 6.00	_____
<b>3-Pin Male XLR Connector</b> (Order Code: 1093)	_____	\$ 7.00	_____
<b>3-Pin Female XLR Connector</b> (Order Code: 1094)	_____	\$ 8.00	_____
<b>1/4" Phone Jack</b> (Order Code: 1086)	_____	\$ 4.00	_____
<b>Belt Clip (black, steel)</b> (Order Code: 30247)	_____	\$ 5.00	_____
<b>Pop-Rivet – for Belt Clip (black, aluminum, 0.125" grip)</b> (Order Code: 8201-.125)	_____	\$ 1.00	_____

<b>Model 32A Talent Amplifier (all Serial Numbers)</b>			
<b>Knob (black, push-on, 15 mm)</b> (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
<b>Knob Cap (black w/white line, 15 mm)</b> (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
<b>Potentiometer</b> (Order Code: 2148)	_____	\$ 4.00	_____
<b>Toggle Switch – Ch 1/2 Select</b> (Order Code: 12021)	_____	\$ 6.00	_____
<b>3-Pin Male XLR Connector</b> (Order Code: 1093)	_____	\$ 7.00	_____
<b>3-Pin Female XLR Connector</b> (Order Code: 1094)	_____	\$ 8.00	_____
<b>1/4" Phone Jack</b> (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
<b>Nut (plastic)</b> (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
<b>3.5 mm Stereo Jack</b> (Order Code: 1198)	_____	\$ 3.00	_____
<b>Belt Clip (black, steel)</b> (Order Code: 30247)	_____	\$ 5.00	_____
<b>Pop-Rivet – for Belt Clip (black, aluminum, 0.125" grip)</b> (Order Code: 8201-.125)	_____	\$ 1.00	_____

	Qty	US List Price	Total
<b>Model 33 Talent Amplifier (all Serial Numbers)</b>			
<b>Knob – Ch 1 and Ch 2 (black, push-on, 15 mm)</b> (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
<b>Knob Cap – Ch 1 and Ch 2 (black w/white line, 15 mm)</b> (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
<b>Potentiometer – Ch 1 and Ch 2</b> (Order Code: 2148)	_____	\$ 4.00	_____
<b>Toggle Switch – Ch 1/2 Select</b> (Order Code: 12063)	_____	\$ 9.00	_____
<b>3-Pin Male XLR Connector</b> (Order Code: 1093)	_____	\$ 7.00	_____
<b>3-Pin Female XLR Connector</b> (Order Code: 1094)	_____	\$ 8.00	_____
<b>1/4" Phone Jack</b> (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
<b>Nut (plastic)</b> (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
<b>Belt Clip (black, steel)</b> (Order Code: 30247)	_____	\$ 5.00	_____
<b>Pop-Rivet – for Belt Clip (black, aluminum, 0.125" grip)</b> (Order Code: 8201-.125)	_____	\$ 1.00	_____

---

### Model 33A Talent Amplifier (all Serial Numbers)

<b>Knob – Ch 1 and Ch 2 (black, push-on, 15 mm)</b> (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
<b>Knob Cap – Ch 1 and Ch 2 (black w/white line, 15 mm)</b> (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
<b>Potentiometer – Ch 1 and Ch 2</b> (Order Code: 2148)	_____	\$ 4.00	_____
<b>Toggle Switch – Ch 1/2 Select</b> (Order Code: 12063)	_____	\$ 9.00	_____
<b>3-Pin Male XLR Connector</b> (Order Code: 1093)	_____	\$ 7.00	_____
<b>3-Pin Female XLR Connector</b> (Order Code: 1094)	_____	\$ 8.00	_____
<b>1/4" Phone Jack</b> (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
<b>Nut (plastic)</b> (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
<b>3.5 mm Stereo Jack</b> (Order Code: 1198)	_____	\$ 3.00	_____
<b>Belt Clip (black, steel)</b> (Order Code: 30247)	_____	\$ 5.00	_____
<b>Pop-Rivet – for Belt Clip (black, aluminum, 0.125" grip)</b> (Order Code: 8201-.125)	_____	\$ 1.00	_____

---

### Model 34 Talent Amplifier (all Serial Numbers)

<b>Knob – Ch 1/Left and Ch 2/Right (black, push-on, 15 mm)</b> (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
<b>Knob Cap – Ch 1/Left and Ch 2/Right (black w/white line, 15 mm)</b> (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
<b>Potentiometer – Ch 1/Left and Ch 2/Right</b> (Order Code: 2148)	_____	\$ 4.00	_____
<b>Toggle Switch – Output Mic/Stereo Select</b> (Order Code: 12021)	_____	\$ 6.00	_____
<b>3-Pin Female XLR Connector</b> (Order Code: 1094)	_____	\$ 8.00	_____
<b>1/4" Phone Jack</b> (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
<b>Nut (plastic)</b> (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
<b>3.5 mm Stereo Jack</b> (Order Code: 1198)	_____	\$ 3.00	_____
<b>Belt Clip (black, steel)</b> (Order Code: 30247)	_____	\$ 5.00	_____
<b>Pop-Rivet – for Belt Clip (black, aluminum, 0.125" grip)</b> (Order Code: 8201-.125)	_____	\$ 1.00	_____

	Qty	US List Price	Total
<b>Model 35 Talent Amplifier (Serial Numbers 00001 – 00385)</b>			
<b>Knob (black, push-on, 15 mm)</b> (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
<b>Knob Cap (black w/white line, 15 mm)</b> (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
<b>Potentiometer</b> (Order Code: 2124)	_____	\$ 5.00	_____
<b>Pushbutton Switch (push-push) – Stereo/Mono</b> (Order Code: 12016)	_____	\$ 3.00	_____
<b>Pushbutton Cap (gray)</b> (Order Code: 12015)	_____	\$ 3.00	_____
<b>3-Pin Male XLR Connector</b> (Order Code: 1093)	_____	\$ 7.00	_____
<b>3-Pin Female XLR Connector</b> (Order Code: 1094)	_____	\$ 8.00	_____
<b>Dual 1/4" Phone Jack</b> (Order Code: 1087)	_____	\$ 6.00	_____
<b>Self-Adhesive Rubber Bumpons (black, set of 4, 1/2" dia. by 0.138" tall)</b> (Order Code: 14028)	_____	\$ 2.00	_____

<b>Model 35 Talent Amplifier (Serial Numbers 00386 – later)</b>			
<b>Knob (black, push-on, 15 mm)</b> (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
<b>Knob Cap (black w/white line, 15 mm)</b> (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
<b>Potentiometer</b> (Order Code: 2124)	_____	\$ 5.00	_____
<b>Pushbutton Switch (push-push) – Stereo/Mono</b> (Order Code: 12016)	_____	\$ 3.00	_____
<b>Pushbutton Cap (gray)</b> (Order Code: 12015)	_____	\$ 3.00	_____
<b>3-Pin Male XLR Connector</b> (Order Code: 1093)	_____	\$ 7.00	_____
<b>3-Pin Female XLR Connector</b> (Order Code: 1094)	_____	\$ 8.00	_____
<b>Dual 1/4" Phone Jack</b> (Order Code: 1113)	_____	\$ 7.00	_____
<b>Self-Adhesive Rubber Bumpons (black, set of 4, 1/2" dia. by 0.138" tall)</b> (Order Code: 14028)	_____	\$ 2.00	_____

<b>Model 36 Talent Interface (all Serial Numbers)</b>			
<b>Knob (black, push-on, 15 mm)</b> (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
<b>Knob Cap (black w/white line, 15 mm)</b> (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
<b>Potentiometer</b> (Order Code: 2148)	_____	\$ 4.00	_____
<b>1/4" Phone Jack</b> (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
<b>Nut (plastic)</b> (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
<b>3.5 mm Stereo Jack</b> (Order Code: 1198)	_____	\$ 3.00	_____
<b>5-Pin Headset Connector Assembly</b> (Order Code: 13579)	_____	\$56.00	_____
<b>6-Pin Headset Connector Assembly</b> (Order Code: 13595)	_____	\$56.00	_____
<b>7-Pin Headset Connector Assembly</b> (Order Code: 13561)	_____	\$56.00	_____
<b>Belt Clip (black, steel)</b> (Order Code: 30247)	_____	\$ 5.00	_____
<b>Pop-Rivet – for Belt Clip (black, aluminum, 0.125" grip)</b> (Order Code: 8201-.125)	_____	\$ 1.00	_____

<b>Model 37 Intercom Beltpack (all Serial Numbers)</b>			
<b>Knob – Main and Aux (black, push-on, 15 mm)</b> (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
<b>Knob Cap – Main and Aux (black w/white line, 15 mm)</b> (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
<b>Potentiometer – Main and Aux</b> (Order Code: 2148)	_____	\$ 4.00	_____
<b>Toggle Switch – Mic On Select (on/off/mom)</b> (Order Code: 12088)	_____	\$ 6.00	_____
<b>Power Entry &amp; Aux Audio Input Kit</b> (Order Code: M37-MK-01)	_____	\$84.00	_____
<b>Belt Clip (black, steel)</b> (Order Code: 30247)	_____	\$ 5.00	_____
<b>Pop-Rivet – for Belt Clip (black, aluminum, 0.125" grip)</b> (Order Code: 8201-.125)	_____	\$ 1.00	_____

	Qty	US List Price	Total
<b>Model 41 Interface (Serial Numbers 00151 – 01050)</b>			
<b>Knob (black, push-on, 15 mm)</b> (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
<b>Knob Cap (black, w/white line, 15 mm)</b> (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
<b>Potentiometer</b> (Order Code: 2166)	_____	\$ 4.00	_____
<b>1/4" Phone Jack</b> (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
<b>Nut (plastic)</b> (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
<b>Pushbutton Cap (gray)</b> (Order Code: 14229)	_____	\$ 1.50	_____
<hr/>			
<b>Model 41 Interface (Serial Numbers 01051 – later)</b>			
<b>Knob (black, push-on, 15 mm)</b> (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
<b>Knob Cap (black w/white line, 15 mm)</b> (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
<b>Potentiometer</b> (Order Code: 2166)	_____	\$ 4.00	_____
<b>1/4" Phone Jack</b> (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
<b>Nut (plastic)</b> (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
<b>Pushbutton Cap (gray)</b> (Order Code: 14229)	_____	\$ 1.50	_____
<hr/>			
<b>Model 42A Interface (all Serial Numbers)</b>			
<b>Knob (black, push-on, 15 mm)</b> (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
<b>Knob Cap (black w/white line, 15 mm)</b> (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
<b>Potentiometer</b> (Order Code: 2166)	_____	\$ 4.00	_____
<b>1/4" Phone Jack</b> (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
<b>Nut (plastic)</b> (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
<b>Pushbutton Cap (gray)</b> (Order Code: 14229)	_____	\$ 1.50	_____
<hr/>			
<b>Model 43D IFB Interface (all Serial Numbers)</b>			
<b>4-Position DIP Switch</b> (Order Code: 12071)	_____	\$ 5.00	_____
<b>Screw-On Bumper Kit (black, set of 8)</b> (Order Code: 31064)	_____	\$10.00	_____
<hr/>			
<b>Model 44D Audio Interface (all Serial Numbers)</b>			
<b>4-Position DIP Switch</b> (Order Code: 12071)	_____	\$ 5.00	_____
<b>Screw-On Bumper Kit (black, set of 8)</b> (Order Code: 31064)	_____	\$10.00	_____
<hr/>			
<b>Model 45 Interface (all Serial Numbers)</b>			
<b>5-Position DIP Switch</b> (Order Code: 12069)	_____	\$ 6.00	_____
<b>Pushbutton Switch (momentary) – Auto Null</b> (Order Code: 12056)	_____	\$ 4.00	_____
<b>Pushbutton Cap (gray)</b> (Order Code: 14207)	_____	\$ 3.00	_____
<b>Screw-On Bumper Kit (black, set of 8)</b> (Order Code: 31064)	_____	\$10.00	_____
<b>24 Vdc, 0.75 A Power Supply (output terminated onto 2.1 x 5.5 mm locking coaxial jack)</b> (Order Code: PS-DC-03)	_____	\$46.00	_____

	Qty	US List Price	Total
<b>Model 45A Interface (all Serial Numbers)</b>			
5-Position DIP Switch (Order Code: 12069)	_____	\$ 6.00	_____
Pushbutton Switch (momentary) – Auto Null (Order Code: 12056)	_____	\$ 4.00	_____
Pushbutton Cap (gray) (Order Code: 14207)	_____	\$ 3.00	_____
Screw-On Bumper Kit (black, set of 8) (Order Code: 31064)	_____	\$10.00	_____
24 Vdc, 0.75 A Power Supply (output terminated onto 2.1 x 5.5 mm locking coaxial jack) (Order Code: PS-DC-03)	_____	\$46.00	_____
<hr/>			
<b>Model 45DC Intercom Interface (all Serial Numbers)</b>			
4-Position DIP Switch (Order Code: 12071)	_____	\$ 5.00	_____
Pushbutton Switch (momentary) – Auto Null (Order Code: 12056)	_____	\$ 4.00	_____
Pushbutton Cap (gray) (Order Code: 14207)	_____	\$ 3.00	_____
Screw-On Bumper Kit (black, set of 8) (Order Code: 31064)	_____	\$10.00	_____
<hr/>			
<b>Model 45DR Intercom Interface (all Serial Numbers)</b>			
4-Position DIP Switch (Order Code: 12071)	_____	\$ 5.00	_____
Pushbutton Switch (momentary) – Auto Null (Order Code: 12056)	_____	\$ 4.00	_____
Pushbutton Cap (gray) (Order Code: 14207)	_____	\$ 3.00	_____
Screw-On Bumper Kit (black, set of 8) (Order Code: 31064)	_____	\$10.00	_____
<hr/>			
<b>Model 544D Audio Interface (all Serial Numbers)</b>			
Screw-On Bumper Kit (black, set of 8) (Order Code: 31064)	_____	\$10.00	_____
<hr/>			
<b>Model 545DC Intercom Interface (all Serial Numbers)</b>			
Pushbutton Switch (momentary) – Auto Null (Order Code: 12056)	_____	\$ 4.00	_____
Pushbutton Cap (gray) (Order Code: 14207)	_____	\$ 3.00	_____
Screw-On Bumper Kit (black, set of 8) (Order Code: 31064)	_____	\$10.00	_____
<hr/>			
<b>Model 545DR Intercom Interface (all Serial Numbers)</b>			
Pushbutton Switch (momentary) – Auto Null (Order Code: 12056)	_____	\$ 4.00	_____
Pushbutton Cap (gray) (Order Code: 14207)	_____	\$ 3.00	_____
Screw-On Bumper Kit (black, set of 8) (Order Code: 31064)	_____	\$10.00	_____
<hr/>			
<b>Model 46 Interface (all Serial Numbers)</b>			
4-Position DIP Switch (Order Code: 12071)	_____	\$ 5.00	_____
Pushbutton Switch (momentary) – Auto Null (Order Code: 12056)	_____	\$ 4.00	_____
Pushbutton Cap (gray) (Order Code: 14207)	_____	\$ 3.00	_____
<hr/>			
<b>Model 46A Interface (all Serial Numbers)</b>			
4-Position DIP Switch (Order Code: 12071)	_____	\$ 5.00	_____
Pushbutton Switch (momentary) – Auto Null (Order Code: 12056)	_____	\$ 4.00	_____
Pushbutton Cap (gray) (Order Code: 14207)	_____	\$ 3.00	_____
<hr/>			
<b>Model 47 Interface (all Serial Numbers)</b>			
4-Position DIP Switch (Order Code: 12071)	_____	\$ 5.00	_____
Pushbutton Switch (momentary) – Auto Null (Order Code: 12056)	_____	\$ 4.00	_____
Pushbutton Cap (gray) (Order Code: 14207)	_____	\$ 3.00	_____
<hr/>			
<b>Model 47A Interface (all Serial Numbers)</b>			
4-Position DIP Switch (Order Code: 12071)	_____	\$ 5.00	_____
Pushbutton Switch (momentary) – Auto Null (Order Code: 12056)	_____	\$ 4.00	_____
Pushbutton Cap (gray) (Order Code: 14207)	_____	\$ 3.00	_____



	Qty	US List Price	Total
<b>Model 48D Dante Bridge (all Serial Numbers)</b>			
Screw-On Bumper Kit (black, set of 8) <i>(Order Code: 31064)</i>	_____	\$10.00	_____
<hr/>			
<b>Model 72 Level Meter / Interface (all Serial Numbers)</b>			
Self-Adhesive Rubber Bumpons (black, set of 4, 1/2" dia. by 0.138" tall) <i>(Order Code: 14028)</i>	_____	\$ 2.00	_____
<hr/>			

	Qty	US List Price	Total
<b>Model 51 Control Console (all Serial Numbers)</b>			
<b>Pushbutton Switch (momentary)</b> (Order Code: 12055) <i>Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND</i>	_____	\$ 4.00	_____
<b>Knob – Studio Level (black, push-on, 15 mm)</b> (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
<b>Knob Cap – Studio Level (black w/white line, 15 mm)</b> (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
<b>Potentiometer – Studio Level</b> (Order Code: 2054)	_____	\$12.00	_____
<b>Knob – Control Room Level (black, collet, 47 mm)</b> (Order Code: 14205) <i>Note: Knob and knob cap are sold separately. See 14206 for knob cap.</i>	_____	\$18.00	_____
<b>Knob Cap – Control Room Level (black w/white line, 47 mm)</b> (Order Code: 14206) <i>Note: Knob and knob cap are sold separately. See 14205 for knob.</i>	_____	\$ 4.00	_____
<b>Potentiometer – Control Room Level</b> (Order Code: 2122)	_____	\$12.00	_____
<b>Self-Adhesive Rubber Bumpons (black, set of 4, 1/2" dia. by 0.138" tall)</b> (Order Code: 14028)	_____	\$ 2.00	_____
<hr/>			
<b>Model 56 Control Console (all Serial Numbers)</b>			
<b>Pushbutton Switch (momentary)</b> (Order Code: 12055) <i>Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND</i>	_____	\$ 4.00	_____
<b>Knob – Control Room Level (black, collet, 38 mm)</b> (Order Code: 14209) <i>Note: Knob and knob cap are sold separately. See 14210 for knob cap.</i>	_____	\$14.00	_____
<b>Knob Cap – Control Room Level (black w/white line, 38 mm)</b> (Order Code: 14210) <i>Note: Knob and knob cap are sold separately. See 14209 for knob.</i>	_____	\$ 3.00	_____
<b>Potentiometer – Control Room Level</b> (Order Code: 2123)	_____	\$ 5.00	_____
<b>Self-Adhesive Rubber Bumpons (black, set of 4, 1/2" dia. by 0.138" tall)</b> (Order Code: 14028)	_____	\$ 2.00	_____
<hr/>			
<b>Model 59 and Model 591 Control Consoles (all Serial Numbers)</b>			
<b>Pushbutton Switch (momentary)</b> (Order Code: 12055) <i>Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND</i>	_____	\$ 4.00	_____
<b>Knob – Control Room Level (black, collet, 38 mm)</b> (Order Code: 14209) <i>Note: Knob and knob cap are sold separately. See 14210 for knob cap.</i>	_____	\$14.00	_____
<b>Knob Cap – Control Room Level (black w/white line, 38 mm)</b> (Order Code: 14210) <i>Note: Knob and knob cap are sold separately. See 14209 for knob.</i>	_____	\$ 3.00	_____
<b>Potentiometer – Control Room Level</b> (Order Code: 2123)	_____	\$ 5.00	_____
<b>Self-Adhesive Rubber Bumpons (black, set of 4, 1/2" dia. by 0.138" tall)</b> (Order Code: 14028)	_____	\$ 2.00	_____
<hr/>			
<b>Model 60 Central Controller (Serial Numbers 00200 – 00300)</b>			
<b>1/4" Phone Jack</b> (Order Code: 1086)	_____	\$ 4.00	_____
<b>Dual 1/4" Phone Jack</b> (Order Code: 1087)	_____	\$ 6.00	_____
<b>Knob – Level (black, push-on, 15 mm)</b> (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
<b>Knob Cap – Level (black w/white line, 15 mm)</b> (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
<b>Potentiometer – Phones Level and Dub Level</b> (Order Code: 2128)	_____	\$ 8.00	_____
<b>Pushbutton Switch (push-push)</b> (Order Code: 12016)	_____	\$ 3.00	_____
<b>Pushbutton Switch Assembly (4-station) – Source</b> (Order Code: 12061)	_____	\$16.00	_____
<b>Pushbutton Cap (gray)</b> (Order Code: 12050) <i>Mfg. No.: E-Switch TACGRY; Digi-Key No.: EG1082-ND</i>	_____	\$ 4.00	_____

	Qty	US List Price	Total
<b>Model 60 Central Controller (Serial Numbers 00301 – later)</b>			
<b>1/4" Phone Jack</b> (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
<b>Nut (plastic)</b> (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
<b>Dual 1/4" Phone Jack</b> (Order Code: 1113)	_____	\$ 7.00	_____
<b>Knob – Level (black, push-on, 15 mm)</b> (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
<b>Knob Cap – Level (black w/white line, 15 mm)</b> (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
<b>Potentiometer – Phones Level and Dub Level</b> (Order Code: 2128)	_____	\$ 8.00	_____
<b>Pushbutton Switch (push-push)</b> (Order Code: 12016)	_____	\$ 3.00	_____
<b>Pushbutton Switch Assembly (4-station) – Source</b> (Order Code: 12061)	_____	\$16.00	_____
<b>Pushbutton Cap (gray)</b> (Order Code: 12050) <i>Mfg. No.: E-Switch TACGRY; Digi-Key No.: EG1082-ND</i>	_____	\$ 4.00	_____
<hr/>			
<b>Model 60A Central Controller (all Serial Numbers)</b>			
<b>1/4" Phone Jack</b> (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
<b>Nut (plastic)</b> (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
<b>Dual 1/4" Phone Jack</b> (Order Code: 1168)	_____	\$ 7.00	_____
<b>Knob – Level (black, push-on, 15 mm)</b> (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
<b>Knob Cap – Level (black w/white line, 15 mm)</b> (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
<b>Potentiometer – Phones Level and Dub Level</b> (Order Code: 2128)	_____	\$ 8.00	_____
<b>Pushbutton Switch (push-push)</b> (Order Code: 12016)	_____	\$ 3.00	_____
<b>Pushbutton Switch Assembly (4-station) – Source</b> (Order Code: 12061)	_____	\$16.00	_____
<b>Pushbutton Switch Assembly (3-station) – Switcher</b> (Order Code: 12074)	_____	\$12.00	_____
<b>Pushbutton Cap (gray)</b> (Order Code: 12050) <i>Mfg. No.: E-Switch TACGRY; Digi-Key No.: EG1082-ND</i>	_____	\$ 4.00	_____
<hr/>			
<b>Model 61 Control Console (all Serial Numbers)</b>			
<b>Pushbutton Switch (momentary)</b> (Order Code: 12055) <i>Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND</i>	_____	\$ 4.00	_____
<b>Knob – Level (black, collet, 29 mm)</b> (Order Code: 14214) <i>Note: Knob and knob cap are sold separately. See 14215 for knob cap.</i>	_____	\$ 7.00	_____
<b>Knob Cap – Level (black w/white line, 29 mm)</b> (Order Code: 14215) <i>Note: Knob and knob cap are sold separately. See 14209 for knob.</i>	_____	\$ 3.00	_____
<b>Potentiometer – Level</b> (Order Code: 2123)	_____	\$ 5.00	_____
<b>Self-Adhesive Rubber Bumpons (black, set of 4, 1/2" dia. by 0.138" tall)</b> (Order Code: 14028)	_____	\$ 2.00	_____
<b>9-Pin Male D-Sub/9-Pin Male D-Sub Cable Assembly (overall length 25 feet/7.7 m)</b> (Order Code: 13179-20)	_____	\$26.00	_____

	Qty	US List Price	Total
<b>Model 69 Control Console (all Serial Numbers)</b>			
<b>Pushbutton Switch (momentary)</b> (Order Code: 12055) <i>Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND</i>	_____	\$ 4.00	_____
<b>Knob – Level (black, collet, 38 mm)</b> (Order Code: 14209) <i>Note: Knob and knob cap are sold separately. See 14210 for knob cap.</i>	_____	\$14.00	_____
<b>Knob Cap – Level (black w/white line, 38 mm)</b> (Order Code: 14210) <i>Note: Knob and knob cap are sold separately. See 14209 for knob.</i>	_____	\$ 3.00	_____
<b>Potentiometer – Level</b> (Order Code: 2123)	_____	\$ 5.00	_____
<b>Self-Adhesive Rubber Bumpons (black, set of 4, 1/2" dia. by 0.138" tall)</b> (Order Code: 14028)	_____	\$ 2.00	_____
<b>9-Pin Male D-Sub/9-Pin Male D-Sub Cable Assembly (overall length 25 feet/7.7 m)</b> (Order Code: 13179-20)	_____	\$26.00	_____

<b>Model 69A Control Console (all Serial Numbers)</b>			
<b>Pushbutton Switch (momentary)</b> (Order Code: 12055) <i>Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND</i>	_____	\$ 4.00	_____
<b>Knob – Level (black, collet, 38 mm)</b> (Order Code: 14209) <i>Note: Knob and knob cap are sold separately. See 14210 for knob cap.</i>	_____	\$14.00	_____
<b>Knob Cap – Level (black w/white line, 38 mm)</b> (Order Code: 14210) <i>Note: Knob and knob cap are sold separately. See 14209 for knob.</i>	_____	\$ 3.00	_____
<b>Potentiometer – Level</b> (Order Code: 2123)	_____	\$ 5.00	_____
<b>Self-Adhesive Rubber Bumpons (black, set of 4, 1/2" dia. by 0.138" tall)</b> (Order Code: 14028)	_____	\$ 2.00	_____
<b>9-Pin Male D-Sub/9-Pin Male D-Sub Cable Assembly (overall length 25 feet/7.7 m)</b> (Order Code: 13179-20)	_____	\$26.00	_____

<b>Model 71 Control Console (all Serial Numbers)</b>			
<b>Pushbutton Switch (momentary)</b> (Order Code: 12055) <i>Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND</i>	_____	\$ 4.00	_____
<b>Knob – Level (black, collet, 29 mm)</b> (Order Code: 14214) <i>Note: Knob and knob cap are sold separately. See 14260 for knob cap.</i>	_____	\$ 7.00	_____
<b>Knob Cap – Level (black, 29 mm)</b> (Order Code: 14260) <i>Note: Knob and knob cap are sold separately. See 14214 for knob.</i>	_____	\$ 2.00	_____
<b>Rotary Encoder – Level</b> (Order Code: 12034)	_____	\$ 4.00	_____
<b>Self-Adhesive Rubber Bumpons (black, set of 4, 1/2" dia. by 0.138" tall)</b> (Order Code: 14028)	_____	\$ 2.00	_____
<b>9-Pin Male D-Sub/9-Pin Male D-Sub Cable Assembly (overall length 25 feet/7.7 m)</b> (Order Code: 13179-20)	_____	\$26.00	_____

<b>Model 74 Central Controller (all Serial Numbers)</b>			
<b>3.5 mm Jack</b> (Order Code: 1315)	_____	\$ 4.00	_____

<b>Model 75 Control Console (all Serial Numbers)</b>			
<b>Pushbutton Switch (momentary)</b> (Order Code: 12055) <i>Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND</i>	_____	\$ 4.00	_____
<b>Knob – Level (black, collet, 38 mm)</b> (Order Code: 14209) <i>Note: Knob and knob cap are sold separately. See 14210 for knob cap.</i>	_____	\$14.00	_____
<b>Knob Cap – Level (black w/white line, 38 mm)</b> (Order Code: 14210) <i>Note: Knob and knob cap are sold separately. See 14209 for knob.</i>	_____	\$ 3.00	_____
<b>Potentiometer Assembly – Level</b> (Order Code: 32089)	_____	\$12.00	_____
<b>Self-Adhesive Rubber Bumpons (black, set of 4, 1/2" dia. by 0.138" tall)</b> (Order Code: 14028)	_____	\$ 2.00	_____
<b>9-Pin Male D-Sub/9-Pin Male D-Sub Cable Assembly (overall length 25 feet/7.7 m)</b> (Order Code: 13179-20)	_____	\$26.00	_____

	Qty	US List Price	Total
<b>Model 76 Central Controller (all serial numbers)</b>			
<b>Capacitor (surface mount, aluminum electrolytic, 47 uF, 25 V) (Order Code: 4975)</b>		\$ 2.00	
<i>Mfg. No.: Panasonic FK-Series, EEE-FK1E470P; Digi-Key No.: PCE3804, Mouser No. 667-EEE-FK1E4760P</i>			
<i>Alternate, Mfg. No.: Nichicon UUD-Series, UUD1E470MCL1GS; Digi-Key No. 4893-2273-2, Mouser No. 647-UUD1E470MCL</i>			
<i>Notes: For revision B circuit boards: C36, C73, C178, C193 (C193 is bypass for -15 volt DC rail and is most critical)</i>			
<i>For revision C circuit boards: C39, C76, C181, C196 (C196 is bypass for -15 volt DC rail and is most critical)</i>			

<b>Model 76B Central Controller (all serial numbers)</b>			
<b>Capacitor (surface mount, aluminum electrolytic, 47 uF, 25 V) (Order Code: 4975)</b>		\$ 2.00	
<i>Mfg. No.: Panasonic FK-Series, EEE-FK1E470P; Digi-Key No.: PCE3804, Mouser No. 667-EEE-FK1E4760P</i>			
<i>Alternate, Mfg. No.: Nichicon UUD-Series, UUD1E470MCL1GS; Digi-Key No. 4893-2273-2, Mouser No. 647-UUD1E470MCL</i>			
<i>Notes: For revision B circuit boards: C36, C73, C178, C193 (C193 is bypass for -15 volt DC rail and is most critical)</i>			
<i>For revision C circuit boards: C39, C76, C181, C196 (C196 is bypass for -15 volt DC rail and is most critical)</i>			

<b>Model 76D Central Controller (all serial numbers)</b>			
<b>Power Supply Assembly (universal AC mains input/12 V, 1.25 A (15 watts) output) (Order Code: 32226)</b>		\$65.00	
<i>Note: Replaces discontinued Pihong PSA15LN3-120-R power supply.</i>			

<b>Model 76DA Central Controller (all serial numbers)</b>			
<b>Power Supply Assembly (universal AC mains input/12 V, 1.25 A (15 watts) output) (Order Code: 32226)</b>		\$65.00	
<i>Note: Replaces discontinued Pihong PSA15LN3-120-R power supply.</i>			

<b>Model 77 Control Console (all Serial Numbers)</b>			
<b>Pushbutton Switch (momentary) (Order Code: 12055)</b>		\$ 4.00	
<i>Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND</i>			
<b>Knob – Level (black, collet, 29 mm) (Order Code: 14214)</b>		\$ 7.00	
<i>Note: Knob and knob cap are sold separately. See 14260 for knob cap.</i>			
<b>Knob Cap – Level (black, 29 mm) (Order Code: 14260)</b>		\$ 2.00	
<i>Note: Knob and knob cap are sold separately. See 14214 for knob.</i>			
<b>Rotary Encoder Assembly – Level (Order Code: 31378)</b>		\$ 9.00	
<b>Self-Adhesive Rubber Bumpons (black, set of 4, 1/2" dia. by 0.138" tall) (Order Code: 14028)</b>		\$ 2.00	
<b>9-Pin Male D-Sub/9-Pin Male D-Sub Cable Assembly (overall length 25 feet/7.7 m) (Order Code: 13179-20)</b>		\$26.00	

<b>Model 77B Control Console (all Serial Numbers)</b>			
<b>Pushbutton Switch (momentary) (Order Code: 12055)</b>		\$ 4.00	
<i>Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND</i>			
<b>Knob – Level (black, collet, 29 mm) (Order Code: 14214)</b>		\$ 7.00	
<i>Note: Knob and knob cap are sold separately. See 14260 for knob cap.</i>			
<b>Knob Cap – Level (black, 29 mm) (Order Code: 14260)</b>		\$ 2.00	
<i>Note: Knob and knob cap are sold separately. See 14214 for knob.</i>			
<b>Rotary Encoder Assembly – Level (Order Code: 31378)</b>		\$ 9.00	
<b>Self-Adhesive Rubber Bumpons (black, set of 4, 1/2" dia. by 0.138" tall) (Order Code: 14028)</b>		\$ 2.00	
<b>9-Pin Male D-Sub/9-Pin Male D-Sub Cable Assembly (overall length 25 feet/7.7 m) (Order Code: 13179-20)</b>		\$26.00	

	Qty	US List Price	Total
<b>Model 79 Control Console (all Serial Numbers)</b>			
<b>Pushbutton Switch (momentary)</b> (Order Code: 12055) <i>Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND</i>	_____	\$ 4.00	_____
<b>Knob – Level (black, collet, 29 mm)</b> (Order Code: 14214) <i>Note: Knob and knob cap are sold separately. See 14215 for knob cap.</i>	_____	\$14.00	_____
<b>Knob Cap – Level (black w/white line, 29 mm)</b> (Order Code: 14215) <i>Note: Knob and knob cap are sold separately. See 14209 for knob.</i>	_____	\$ 3.00	_____
<b>Potentiometer – Level</b> (Order Code: 2123)	_____	\$ 5.00	_____
<b>Self-Adhesive Rubber Bumpons (black, set of 4, 1/2" dia. by 0.138" tall)</b> (Order Code: 14028)	_____	\$ 2.00	_____
<b>9-Pin Male D-Sub/9-Pin Male D-Sub Cable Assembly (overall length 25 feet/7.7 m)</b> (Order Code: 13179-20)	_____	\$26.00	_____
<hr/>			
<b>Model 760-Series Central Controllers (all serial numbers)</b>			
<b>Power Supply Assembly (universal AC mains input/12 V, 1.25 A (15 watts) output)</b> (Order Code: 32226) <i>Note: Replaces discontinued Phihong PSA15LN3-120-R power supply.</i>	_____	\$65.00	_____
<hr/>			
<b>Model 780-Series Central Controllers (all serial numbers)</b>			
<b>Power Supply Assembly (universal AC mains input/12 V, 1.25 A (15 watts) output)</b> (Order Code: 32226) <i>Note: Replaces discontinued Phihong PSA15LN3-120-R power supply.</i>	_____	\$65.00	_____
<hr/>			
<b>Model 790 Control Console (all Serial Numbers)</b>			
<b>Pushbutton Switch (momentary)</b> (Order Code: 12055) <i>Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND</i>	_____	\$ 4.00	_____
<b>Knob – Level (black, collet, 29 mm)</b> (Order Code: 14214) <i>Note: Knob and knob cap are sold separately. See 14260 for knob cap.</i>	_____	\$ 7.00	_____
<b>Knob Cap – Level (black, 29 mm)</b> (Order Code: 14260) <i>Note: Knob and knob cap are sold separately. See 14214 for knob.</i>	_____	\$ 2.00	_____
<b>Rotary Encoder Assembly – Level</b> (Order Code: 31378)	_____	\$ 9.00	_____
<b>Self-Adhesive Rubber Bumpons (black, set of 4, 1/2" dia. by 0.138" tall)</b> (Order Code: 14028)	_____	\$ 2.00	_____
<b>9-Pin Male D-Sub/9-Pin Male D-Sub Cable Assembly (overall length 25 feet/7.7 m)</b> (Order Code: 13179-20)	_____	\$26.00	_____
<hr/>			
<b>Model 792 Central Controller (all Serial Numbers)</b>			
<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
<b>Push-Pot Potentiometer Assembly (dual-section)</b> (Order Code: 32298) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
<b>Power Supply (universal AC mains input/12 V, 1.8 A (20 watts) output)</b> (Order Code: 10355) <i>Mfg. No.: Cincon CFM2002S; Digi-Key No.: 2034-3589-ND; Mouser No.: 418-CFM2002S</i>	_____	\$32.00	_____
<hr/>			
<b>Model 793 Control Console (all Serial Numbers)</b>			
<b>Pushbutton Switch (momentary)</b> (Order Code: 12055) <i>Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND</i>	_____	\$ 4.00	_____
<b>Knob – Level (black, collet, 29 mm)</b> (Order Code: 14214) <i>Note: Knob and knob cap are sold separately. See 14260 for knob cap.</i>	_____	\$ 7.00	_____
<b>Knob Cap – Level (black, 29 mm)</b> (Order Code: 14260) <i>Note: Knob and knob cap are sold separately. See 14214 for knob.</i>	_____	\$ 2.00	_____
<b>Rotary Encoder Assembly – Level</b> (Order Code: 12110)	_____	\$ 9.00	_____
<b>Self-Adhesive Rubber Bumpons (black, set of 4, 1/2" dia. by 0.138" tall)</b> (Order Code: 14028)	_____	\$ 2.00	_____
<b>9-Pin Male D-Sub/9-Pin Male D-Sub Cable Assembly (overall length 25 feet/7.7 m)</b> (Order Code: 13179-20)	_____	\$26.00	_____

**Qty**    **US List**    **Total**  
          **Price**

**Model 92 DT12 Cable Assembly Test Unit (all Serial Numbers)**

Rechargeable Battery, 12 V, 1.3 Ah (Order Code: 10335)  
Mfg. No.: Panasonic LC-R121R3P; Digi-Key No.: P264-ND

Not available from factory

---

**Model 93 W1 Cable Assembly Test Unit (all Serial Numbers)**

Rechargeable Battery, 12 V, 1.3 Ah (Order Code: 10335)  
Mfg. No.: Panasonic LC-R121R3P; Digi-Key No.: P264-ND

Not available from factory

---

	Qty	US List Price	Total
<b>Model 201 Interpreter's Console (all Serial Numbers)</b>			
<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
<b>Push-Pot Potentiometer Assembly (dual-section)</b> (Order Code: 32298) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
<b>Pushbutton Switch (momentary, 17 mm x 17 mm)</b> (Order Code: 12106)	_____	\$ 6.00	_____
<b>1/4" Phone Jack</b> (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
<b>Nut (plastic)</b> (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
<b>3.5 mm Stereo Jack</b> (Order Code: 1198)	_____	\$ 3.00	_____
<b>Self-Adhesive Rubber Bumpons (black, set of 4, 1/2" dia. by 0.138" tall)</b> (Order Code: 14028)	_____	\$ 2.00	_____

**Model 210, Model 211, Model 212, Model 220, Model 230, and Model 233  
Announcer's Consoles (all Serial Numbers)**

<b>Pushbutton Switch (momentary, Mfg. by EAO)</b> (Order Code: 12028) <i>Note: Does not include button cap, lens, or label. See 31069.</i>	_____	\$14.00	_____
<b>Button Cap, Lenses, and Label Kit (includes five each button caps, clear lens, frosted lens, and one button function label sheet (15154))</b> (Order Code: 31069)	_____	\$40.00	_____
<b>Knob – Phones Level (black, push-on, 15 mm)</b> (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
<b>Knob Cap – Phones Level (black w/white line, 15 mm)</b> (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
<b>Potentiometer – Phones Level</b> (Order Code: 2127)	_____	\$ 5.00	_____
<b>1/4" Phone Jack</b> (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
<b>Nut (plastic)</b> (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
<b>DC Power Entry Jack Assembly (includes PCB, washer, and nut)</b> (Order Code: 32135) <i>Note: Requires cable assembly, sold separately. See 13690.</i>	_____	\$12.00	_____
<b>Cable Assembly for DC Power Entry Jack Assembly (2-conductor, 5-inch)</b> (Order Code: 13690)	_____	\$ 4.00	_____
<b>Blank Plate – XLR (black)</b> (Order Code: 1073)	_____	\$ 3.00	_____
<b>Model 210 Security Plate</b> (Order Code: SP-M210)	_____	\$15.00	_____
<b>Model 211 Security Plate</b> (Order Code: SP-M211)	_____	\$15.00	_____
<b>Model 212 Security Plate</b> (Order Code: SP-M212)	_____	\$15.00	_____
<b>Model 220 Security Plate</b> (Order Code: SP-M220)	_____	\$18.00	_____
<b>Model 230 Security Plate</b> (Order Code: SP-M230)	_____	\$18.00	_____
<b>Model 233 Security Plate</b> (Order Code: SP-M233)	_____	\$18.00	_____
<b>Screw-On Bumper Kit (black, set of 8)</b> (Order Code: 31064)	_____	\$10.00	_____
<b>24 Vdc, 0.75 A Power Supply (output terminated onto 4-pin female XLR connector)</b> (Order Code: PS-DC-03)	_____	\$46.00	_____



	Qty	US List Price	Total
<b>Model 240 Producer's Console (all Serial Numbers)</b>			
<b>Button Backlight LED</b> (Order Code: 3154)		\$ 3.00	
<b>Pushbutton Switch (momentary, Mfg. by EAO)</b> (Order Code: 12028) <i>Note: Does not include button cap, lens, or label. See 31069.</i>		\$14.00	
<b>Button Cap, Lenses, and Label Kit (includes five each button caps, clear lens, frosted lens, and one button function label sheet (15154))</b> (Order Code: 31069)		\$40.00	
<b>Knob – Phones Level (black, push-on, 15 mm)</b> (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>		\$ 3.00	
<b>Knob Cap – Phones Level (black w/white line, 15 mm)</b> (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>		\$ 1.50	
<b>Potentiometer – Phones Level</b> (Order Code: 2127)		\$ 5.00	
<b>1/4" Phone Jack</b> (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>		\$ 4.00	
<b>Nut (plastic)</b> (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>		\$ 1.50	
<b>DC Power Entry Jack Assembly (includes PCB, washer, and nut)</b> (Order Code: 32135) <i>Note: Requires cable assembly, sold separately. See 13690.</i>		\$12.00	
<b>Cable Assembly for DC Power Entry Jack Assembly (2-conductor, 5-inch)</b> (Order Code: 13690)		\$ 4.00	
<b>Blank Plate – XLR (black)</b> (Order Code: 1073)		\$ 3.00	
<b>Model 240 Security Plate</b> (Order Code: SP-M240)		\$18.00	
<b>Screw-On Bumper Kit (black, set of 8)</b> (Order Code: 31064)		\$10.00	
<b>24 Vdc, 0.75 A Power Supply (output terminated onto 4-pin female XLR connector)</b> (Order Code: PS-DC-03)		\$46.00	

#### **Model 203, Model 204, Model 205, and Model 206 Announcer's Consoles (all Serial Numbers)**

<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>		\$ 3.00	
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>		\$ 0.50	
<b>Push-Pot Potentiometer Assembly (dual-section)</b> (Order Code: 32298) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>		\$ 9.00	
<b>Pushbutton Switch (momentary, 17 mm x 17 mm)</b> (Order Code: 12106)		\$ 6.00	
<b>1/4" Phone Jack</b> (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>		\$ 4.00	
<b>Nut (plastic)</b> (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>		\$ 1.50	
<b>3.5 mm Stereo Jack</b> (Order Code: 1198)		\$ 3.00	
<b>Self-Adhesive Rubber Bumpons (black, set of 4, 1/2" dia. by 0.138" tall)</b> (Order Code: 14028)		\$ 2.00	

#### **Model 207 eSports Console (all Serial Numbers)**

<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>		\$ 3.00	
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>		\$ 0.50	
<b>Push-Pot Potentiometer Assembly (dual-section)</b> (Order Code: 32298) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>		\$ 9.00	
<b>Pushbutton Switch (momentary, 17 mm x 17 mm)</b> (Order Code: 12106)		\$ 6.00	
<b>3.5 mm 4-Conductor (TRRS) Jack</b> (Order Code: 1410)		\$ 5.00	
<b>Self-Adhesive Rubber Bumpons (black, set of 4, 1/2" dia. by 1/4" tall)</b> (Order Code: 14326)		\$ 3.00	

	Qty	US List Price	Total
<b>Model 207A eSports Console (all Serial Numbers)</b>			
<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
<b>Push-Pot Potentiometer Assembly (dual-section)</b> (Order Code: 32298) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
<b>Pushbutton Switch (momentary, 17 mm x 17 mm)</b> (Order Code: 12106)	_____	\$ 6.00	_____
<b>3.5 mm 4-Conductor (TRRS) Jack</b> (Order Code: 1410)	_____	\$ 5.00	_____
<b>Self-Adhesive Rubber Bumpons (black, set of 4, 1/2" dia. by 1/4" tall)</b> (Order Code: 14326)	_____	\$ 3.00	_____
<hr/>			
<b>Model 208 Announcer's Console (all Serial Numbers)</b>			
<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
<b>Push-Pot Potentiometer Assembly (dual-section)</b> (Order Code: 32298) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
<b>Switch Cap Adapter</b> (Order Code: 14294) <i>Note: Switch cap and switch cap adapter are sold separately. See 14295 for 12 mm switch cap.</i>	_____	\$ 1.50	_____
<b>Switch Cap (12 mm)</b> (Order Code: 14295) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____
<b>1/4" Phone Jack</b> (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
<b>Nut (plastic)</b> (Order Code: 1090) <i>Note: For use with 1/4" phone jack.</i>	_____	\$ 1.50	_____
<b>3.5 mm Stereo Jack</b> (Order Code: 1198)	_____	\$ 3.00	_____
<hr/>			
<b>Model 209 Talent Console (all Serial Numbers)</b>			
<b>Knob – Glow (black w/clear center, 13 mm dia. x 13.8 mm tall)</b> (Order Code: 14340)	_____	\$ 5.00	_____
<b>Rotary Encoder (24-step w/switch, 21 mm overall length)</b> (Order Code: 12109)	_____	\$ 8.00	_____
<b>Pushbutton Switch (momentary, 17 mm x 17 mm)</b> (Order Code: 12106)	_____	\$ 6.00	_____
<b>1/4" Phone Jack</b> (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
<b>Nut (plastic)</b> (Order Code: 1090) <i>Note: For use with 1/4" phone jack.</i>	_____	\$ 1.50	_____
<b>3.5 mm Stereo Jack</b> (Order Code: 1198)	_____	\$ 3.00	_____

	Qty	US List Price	Total
<b>Model 214, Model 215, and Model 216 Announcer's Consoles (all Serial Numbers)</b>			
Pushbutton Switch Backlight LED (Order Code: 3154)		\$ 3.00	
Pushbutton Switch (momentary, Mfg. by EAO) (Order Code: 12028)		\$14.00	
<i>Note: Does not include button cap, lens, or label. See 31069.</i>			
Button Cap, Lenses, and Label Kit (includes five each button caps, clear lens, frosted lens, and one button function label sheet (15154)) (Order Code: 31069)		\$40.00	
Knob – Phones Level (black, push-on, 15 mm) (Order Code: 2056)		\$ 3.00	
<i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>			
Knob Cap – Phones Level (black w/white line, 15 mm) (Order Code: 2057)		\$ 1.50	
<i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>			
Potentiometer – Phones Level (Order Code: 2127)		\$ 5.00	
1/4" Phone Jack (Order Code: 1084)		\$ 4.00	
<i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>			
Nut (plastic) (Order Code: 1090)		\$ 1.50	
<i>Note: Nut is required for installation of 1/4" phone jack.</i>			
Screw-On Bumper Kit (black, set of 8) (Order Code: 31064)		\$10.00	
Blank Plate – XLR (black) (Order Code: 1073)		\$ 3.00	
Model 214 Security Plate (Order Code: SP-M214)		\$15.00	
Model 215 Security Plate (Order Code: SP-M215)		\$15.00	
Model 216 Security Plate (Order Code: SP-M216)		\$15.00	
Screw-On Bumper Kit (black, set of 8) (Order Code: 31064)		\$10.00	

---

**Model 214A, Model 215A, and Model 216A Announcer's Consoles (all Serial Numbers)**

Pushbutton Switch Backlight LED (Order Code: 3154)		\$ 3.00	
Pushbutton Switch (momentary, Mfg. by EAO) (Order Code: 12028)		\$14.00	
<i>Note: Does not include button cap, lens, or label. See 31069.</i>			
Button Cap, Lenses, and Label Kit (includes five each button caps, clear lens, frosted lens, and one button function label sheet (15154)) (Order Code: 31069)		\$40.00	
Knob – Phones Level (black, push-on, 15 mm) (Order Code: 2056)		\$ 3.00	
<i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>			
Knob Cap – Phones Level (black w/white line, 15 mm) (Order Code: 2057)		\$ 1.50	
<i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>			
Potentiometer – Phones Level (Order Code: 2127)		\$ 5.00	
1/4" Phone Jack (Order Code: 1084)		\$ 4.00	
<i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>			
Nut (plastic) (Order Code: 1090)		\$ 1.50	
<i>Note: Nut is required for installation of 1/4" phone jack.</i>			
Screw-On Bumper Kit (black, set of 8) (Order Code: 31064)		\$10.00	
Blank Plate – XLR (black) (Order Code: 1073)		\$ 3.00	
Screw-On Bumper Kit (black, set of 8) (Order Code: 31064)		\$10.00	

---

	Qty	US List Price	Total
<b>Model 232, Model 234, and Model 236 Announcer's Consoles (all Serial Numbers)</b>			
<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
<b>Push-Pot Potentiometer Assembly (dual-section)</b> (Order Code: 32298) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
<b>Knob – Glow (black w/clear center, 13 mm dia. x 17.8 mm tall)</b> (Order Code: 14321)	_____	\$ 5.00	_____
<b>Rotary Encoder (24-step w/switch, 25 mm overall length)</b> (Order Code: 12103)	_____	\$ 8.00	_____
<b>Pushbutton Switch (momentary, 17 mm x 17 mm)</b> (Order Code: 12106)	_____	\$ 6.00	_____
<b>1/4" Phone Jack</b> (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
<b>Nut (plastic)</b> (Order Code: 1090) <i>Note: For use with 1/4" phone jack.</i>	_____	\$ 1.50	_____
<b>Self-Adhesive Rubber Bumpons (black, set of 4, 1/2" dia. by 1/4" tall)</b> (Order Code: 14326)	_____	\$ 3.00	_____
<b>Blank Plate – XLR (black)</b> (Order Code: 1073)	_____	\$ 3.00	_____
<hr/>			
<b>Model 348 Intercom Station (all Serial Numbers)</b>			
<b>Knob – Glow (black w/clear center, 13 mm dia. x 17.8 mm tall)</b> (Order Code: 14321)	_____	\$ 5.00	_____
<b>Rotary Encoder (24-step w/switch, 25 mm overall length)</b> (Order Code: 12103)	_____	\$ 8.00	_____
<b>Pushbutton Switch (momentary, 17 mm x 17 mm)</b> (Order Code: 12106)	_____	\$ 6.00	_____
<b>3.5 mm 4-Conductor (TRRS) Jack</b> (Order Code: 1410)	_____	\$ 5.00	_____
<b>Loudspeaker (32 mm dia., 8 ohm)</b> (Order Code: 10701)	_____	\$22.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: For use with microphone bushing.</i>	_____	\$ 0.50	_____
<b>Self-Adhesive Rubber Bumpons (black, set of 4, 1/2" dia. by 1/4" tall)</b> (Order Code: 14326)	_____	\$ 3.00	_____
<b>Blank Plate – XLR (black)</b> (Order Code: 1073)	_____	\$ 3.00	_____
<hr/>			
<b>Model 354 Talk Station (all Serial Numbers)</b>			
<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
<b>Push-Pot Potentiometer Assembly (dual-section)</b> (Order Code: 32298) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
<b>Pushbutton Switch (momentary, 17 mm x 17 mm)</b> (Order Code: 12106)	_____	\$ 6.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: For use with microphone bushing.</i>	_____	\$ 0.50	_____
<b>Rubber Bumper (black, set of 4, 1/2" dia. by 7/32" tall)</b> (Order Code: 14339) <i>Note: Bumpers and machine screws are sold separately. See 8032-5/16 for screws.</i>	_____	\$ 6.00	_____
<b>Machine Screw (SEMS, 4-40x5/16")</b> (Order Code: 8032-5/16) <i>Note: Machine screws and bumpers are sold separately. See 14339 for bumpers.</i>	_____	\$ 0.50	_____

	Qty	US List Price	Total
<b>Model 354A Talk Station (all Serial Numbers)</b>			
<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
<b>Push-Pot Potentiometer Assembly (dual-section)</b> (Order Code: 32298) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
<b>Pushbutton Switch (momentary, 17 mm x 17 mm)</b> (Order Code: 12106)	_____	\$ 6.00	_____
<b>Pushbutton Switch (momentary) – Monitor Source</b> (Order Code: 12056)	_____	\$ 4.00	_____
<b>Pushbutton Cap (gray)</b> (Order Code: 14207)	_____	\$ 3.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: For use with microphone bushing.</i>	_____	\$ 0.50	_____
<b>Rubber Bumper (black, set of 4, 1/2" dia. by 7/32" tall)</b> (Order Code: 14339) <i>Note: Bumpers and machine screws are sold separately. See 8032-5/16 for screws.</i>	_____	\$ 6.00	_____
<b>Machine Screw (SEMS, 4-40x5/16")</b> (Order Code: 8032-5/16) <i>Note: Machine screws and bumpers are sold separately. See 14339 for bumpers.</i>	_____	\$ 0.50	_____
<hr/>			
<b>GME-3-12 Gooseneck Microphone</b>			
<b>Foam Windscreen – for GME-3-12 Gooseneck Microphone</b> (Order Code: 14331) <i>Note: Also included with Model 11B Gooseneck Microphone Assembly.</i>	_____	\$ 6.00	_____
<hr/>			
<b>Model 362 Listen-Only Beltpack (all Serial Numbers)</b>			
<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
<b>Push-Pot Potentiometer Assembly (dual-section)</b> (Order Code: 32298) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
<b>1/4" Phone Jack</b> (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
<b>Nut (plastic)</b> (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
<b>3.5 mm Stereo Jack</b> (Order Code: 1198)	_____	\$ 3.00	_____
<b>Belt Clip (black, steel)</b> (Order Code: 30247)	_____	\$ 5.00	_____
<b>Pop-Rivet – for Belt Clip (black, aluminum, 0.125" grip)</b> (Order Code: 8201-.125)	_____	\$ 1.00	_____
<b>Phillips Machine Screw – for Belt Clip (black, 6-32x1/4")</b> (Order Code: 8056-1/4)	_____	\$ 0.50	_____
<hr/>			
<b>Model 362A Listen-Only Beltpack (all Serial Numbers)</b>			
<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
<b>Push-Pot Potentiometer Assembly (dual-section)</b> (Order Code: 32298) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
<b>1/4" Phone Jack</b> (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
<b>Nut (plastic)</b> (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
<b>3.5 mm Stereo Jack</b> (Order Code: 1198)	_____	\$ 3.00	_____
<b>Belt Clip (black, steel)</b> (Order Code: 30247)	_____	\$ 5.00	_____
<b>Pop-Rivet – for Belt Clip (black, aluminum, 0.125" grip)</b> (Order Code: 8201-.125)	_____	\$ 1.00	_____
<b>Phillips Machine Screw – for Belt Clip (black, 6-32x1/4")</b> (Order Code: 8056-1/4)	_____	\$ 0.50	_____

	Qty	US List Price	Total
<b>Model 370 Intercom Beltpack (all Serial Numbers)</b>			
<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
<b>Push-Pot Potentiometer Assembly (dual-section)</b> (Order Code: 32298) (for s/n 00151-02000) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
<b>Push-Pot Potentiometer Assembly (single-section)</b> (Order Code: 32299) (for s/n 02001-later) <i>Note: Includes push-pot (2172) and sleeve (14297).</i>	_____	\$ 9.00	_____
<b>Trim Potentiometer (for sidetone)</b> (Order Code: 2119) <i>Note: Plastic shaft sold separately. See 14307.</i>	_____	\$ 4.00	_____
<b>Plastic Shaft (gray, for sidetone trim pot)</b> (Order Code: 14307)	_____	\$ 3.00	_____
<b>Switch Cap Adapter</b> (Order Code: 14294) <i>Note: Switch cap and switch cap adapter are sold separately. See 14295 for 12 mm switch cap and 14296 for 10 mm switch cap.</i>	_____	\$ 1.50	_____
<b>Switch Cap – Talk (12 mm square)</b> (Order Code: 14295) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____
<b>Switch Cap – Call (10 mm square)</b> (Order Code: 14296) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____
<b>Belt Clip (black, steel)</b> (Order Code: 30247)	_____	\$ 5.00	_____
<b>Pop-Rivet – for Belt Clip (black, aluminum, 0.125" grip)</b> (Order Code: 8201-.125)	_____	\$ 1.00	_____
<b>Phillips Machine Screw – for Belt Clip (black, 6-32x1/4")</b> (Order Code: 8056-1/4)	_____	\$ 0.50	_____

**Model 370A Intercom Beltpack (all Serial Numbers)**

<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
<b>Push-Pot Potentiometer Assembly (dual-section)</b> (Order Code: 32298) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
<b>Switch Cap Adapter</b> (Order Code: 14294) <i>Note: Switch cap and switch cap adapter are sold separately. See 14295 for 12 mm switch cap and 14296 for 10 mm switch cap.</i>	_____	\$ 1.50	_____
<b>Switch Cap – Talk (12 mm square)</b> (Order Code: 14295) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____
<b>Switch Cap – Call (10 mm square)</b> (Order Code: 14296) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____
<b>Belt Clip (black, steel)</b> (Order Code: 30247)	_____	\$ 5.00	_____
<b>Hex Machine Screw – for Belt Clip (black, 6-32x1/4")</b> (Order Code: 8054-1/4)	_____	\$ 0.50	_____

	Qty	US List Price	Total
<b>Model 371 Intercom Beltpack (all Serial Numbers)</b>			
<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
<b>Push-Pot Potentiometer Assembly (single-section)</b> (Order Code: 32299) <i>Note: Includes push-pot (2172) and sleeve (14297).</i>	_____	\$ 9.00	_____
<b>Trim Potentiometer (for sidetone)</b> (Order Code: 2119) <i>Note: Plastic shaft sold separately. See 14307.</i>	_____	\$ 4.00	_____
<b>Plastic Shaft (gray, for sidetone trim pot)</b> (Order Code: 14307)	_____	\$ 3.00	_____
<b>Switch Cap Adapter</b> (Order Code: 14294) <i>Note: Switch cap and switch cap adapter are sold separately. See 14295 for 12 mm switch cap and 14296 for 10 mm switch cap.</i>	_____	\$ 1.50	_____
<b>Switch Cap – Talk (12 mm square)</b> (Order Code: 14295) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____
<b>Switch Cap – Call (10 mm square)</b> (Order Code: 14296) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____
<b>Belt Clip (black, steel)</b> (Order Code: 30247)	_____	\$ 5.00	_____
<b>Pop-Rivet – for Belt Clip (black, aluminum, 0.125" grip)</b> (Order Code: 8201-.125)	_____	\$ 1.00	_____
<b>Phillips Machine Screw – for Belt Clip (black, 6-32x1/4")</b> (Order Code: 8056-1/4)	_____	\$ 0.50	_____

#### Model 371A Intercom Beltpack (all Serial Numbers)

<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
<b>Push-Pot Potentiometer Assembly (dual-section)</b> (Order Code: 32298) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
<b>Switch Cap Adapter</b> (Order Code: 14294) <i>Note: Switch cap and switch cap adapter are sold separately. See 14295 for 12 mm switch cap and 14296 for 10 mm switch cap.</i>	_____	\$ 1.50	_____
<b>Switch Cap – Talk (12 mm square)</b> (Order Code: 14295) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____
<b>Switch Cap – Call (10 mm square)</b> (Order Code: 14296) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____
<b>Belt Clip (black, steel)</b> (Order Code: 30247)	_____	\$ 5.00	_____
<b>Hex Machine Screw – for Belt Clip (black, 6-32x1/4")</b> (Order Code: 8054-1/4)	_____	\$ 0.50	_____

#### Model 372A Intercom Beltpack (all Serial Numbers)

<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
<b>Push-Pot Potentiometer Assembly (dual-section)</b> (Order Code: 32298) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
<b>Switch Cap Adapter</b> (Order Code: 14294) <i>Note: Switch cap and switch cap adapter are sold separately. See 14295 for 12 mm switch cap.</i>	_____	\$ 1.50	_____
<b>Switch Cap – Talk (12 mm square)</b> (Order Code: 14295) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____
<b>Belt Clip (black, steel)</b> (Order Code: 30247)	_____	\$ 5.00	_____
<b>Pop-Rivet – for Belt Clip (black, aluminum, 0.125" grip)</b> (Order Code: 8201-.125)	_____	\$ 1.00	_____

	Qty	US List Price	Total
<b>Model 373A Intercom Beltpack (all Serial Numbers)</b>			
<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
<b>Push-Pot Potentiometer Assembly (dual-section)</b> (Order Code: 32298) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
<b>Switch Cap Adapter</b> (Order Code: 14294) <i>Note: Switch cap and switch cap adapter are sold separately. See 14295 for 12 mm switch cap.</i>	_____	\$ 1.50	_____
<b>Switch Cap – Talk (12 mm square)</b> (Order Code: 14295) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____
<b>Belt Clip (black, steel)</b> (Order Code: 30247)	_____	\$ 5.00	_____
<b>Pop-Rivet – for Belt Clip (black, aluminum, 0.125” grip)</b> (Order Code: 8201-.125)	_____	\$ 1.00	_____

**Model 374 Intercom Beltpack (all Serial Numbers)**

<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
<b>Push-Pot Potentiometer Assembly (dual-section)</b> (Order Code: 32298) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
<b>Trim Potentiometer (for sidetone)</b> (Order Code: 2119) <i>Note: Plastic shaft sold separately. See 14307.</i>	_____	\$ 4.00	_____
<b>Plastic Shaft (gray, for sidetone trim pot)</b> (Order Code: 14307)	_____	\$ 3.00	_____
<b>Switch Cap Adapter</b> (Order Code: 14294) <i>Note: Switch cap and switch cap adapter are sold separately. See 14296 for 10 mm switch cap.</i>	_____	\$ 1.50	_____
<b>Switch Cap (10 mm square)</b> (Order Code: 14296) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____
<b>Belt Clip (black, steel)</b> (Order Code: 30247)	_____	\$ 5.00	_____
<b>Pop-Rivet – for Belt Clip (black, aluminum, 0.125” grip)</b> (Order Code: 8201-.125)	_____	\$ 1.00	_____
<b>Phillips Machine Screw – for Belt Clip (black, 6-32x1/4”)</b> (Order Code: 8056-1/4)	_____	\$ 0.50	_____

**Model 374A Intercom Beltpack (all Serial Numbers)**

<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
<b>Push-Pot Potentiometer Assembly (dual-section)</b> (Order Code: 32298) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
<b>Switch Cap Adapter</b> (Order Code: 14294) <i>Note: Switch cap and switch cap adapter are sold separately. See 14296 for 10 mm switch cap.</i>	_____	\$ 1.50	_____
<b>Switch Cap (10 mm square)</b> (Order Code: 14296) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____
<b>Belt Clip (black, steel)</b> (Order Code: 30247)	_____	\$ 5.00	_____
<b>Hex Machine Screw – for Belt Clip (black, 6-32x1/4”)</b> (Order Code: 8054-1/4)	_____	\$ 0.50	_____



	Qty	US List Price	Total
<b>Model 380 On-Air Beltpack (all Serial Numbers)</b>			
<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
<b>Push-Pot Potentiometer Assembly (dual-section)</b> (Order Code: 32298) (for s/n 00151-01000) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
<b>Push-Pot Potentiometer Assembly (single-section)</b> (Order Code: 32299) (for s/n 01001-later) <i>Note: Includes push-pot (2172) and sleeve (14297).</i>	_____	\$ 9.00	_____
<b>1/4" Phone Jack</b> (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
<b>Nut (plastic)</b> (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
<b>Switch Cap Adapter</b> (Order Code: 14294) <i>Note: Switch cap and switch cap adapter are sold separately. See 14295 for 12 mm switch cap.</i>	_____	\$ 1.50	_____
<b>Switch Cap (12 mm)</b> (Order Code: 14295) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____
<b>Belt Clip (black, steel)</b> (Order Code: 30247)	_____	\$ 5.00	_____
<b>Pop-Rivet – for Belt Clip (black, aluminum, 0.125" grip)</b> (Order Code: 8201-.125)	_____	\$ 1.00	_____
<b>Phillips Machine Screw – for Belt Clip (black, 6-32x1/4")</b> (Order Code: 8056-1/4)	_____	\$ 0.50	_____

**Model 381 On-Air Beltpack (all Serial Numbers)**

<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
<b>Push-Pot Potentiometer Assembly (dual-section)</b> (Order Code: 32298) (for s/n 00151-01000) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
<b>1/4" Phone Jack</b> (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
<b>Nut (plastic)</b> (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
<b>Switch Cap Adapter</b> (Order Code: 14294) <i>Note: Switch cap and switch cap adapter are sold separately. See 14295 for 12 mm switch cap.</i>	_____	\$ 1.50	_____
<b>Switch Cap (12 mm)</b> (Order Code: 14295) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____
<b>Belt Clip (black, steel)</b> (Order Code: 30247)	_____	\$ 5.00	_____
<b>Pop-Rivet – for Belt Clip (black, aluminum, 0.125" grip)</b> (Order Code: 8201-.125)	_____	\$ 1.00	_____

**Model 391 Dante Alerting Unit (all Serial Numbers)**

<b>Pushbutton Switch (momentary) – Mode</b> (Order Code: 12056)	_____	\$ 4.00	_____
<b>Pushbutton Cap (gray)</b> (Order Code: 14207)	_____	\$ 3.00	_____
<b>Screw-On Bumper Kit (black, set of 8)</b> (Order Code: 31064)	_____	\$10.00	_____
<b>Trim Potentiometer</b> (Order Code: 2119) <i>Note: Plastic shaft sold separately. See 14307.</i>	_____	\$ 4.00	_____
<b>Plastic Shaft (gray, for trim pot)</b> (Order Code: 14307)	_____	\$ 3.00	_____

**Model 392 Visual Indicator Unit (all Serial Numbers)**

<b>Metal Plate</b> (Order Code: 32248) <i>Mfg. No.: Leviton® S746-N, 2-gang, 1-Decora® opening, centered, 302 stainless steel. Available from online and electrical supply sources.</i>			Not available from factory
--	--	--	----------------------------

	Qty	US List Price	Total
<b>Model 400 SDI-Over-Fiber Transport Systems (all Serial Numbers)</b>			
<b>Pushbutton Switch (momentary)</b> (Order Code: 12055) <i>Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND</i>	_____	\$ 4.00	_____
<b>Display Assembly (includes set of 4 each rubber washers (14303) and thin profile nylock nuts (8319))</b> (Order Code: 31579)	_____	\$122.00	_____
<b>Display Lens</b> (Order Code: 15203)	_____	\$ 4.00	_____
<b>Power Supply (universal AC mains input/12 V, 3.34 A (40 watts) output)</b> (Order Code: 10303) <i>Mfg. No.: Cincon CFM40S120; Digi-Key No.: 2034-3674-ND; Mouser No.: 418-CFM40S120</i>	_____	\$ 45.00	_____
<b>Model 403-03 Triple Optical to Electrical Interface Card</b> (Order Code: M403-03) <i>Note: Does not include SFP optical modules (card uses one each 6411 and 6407).</i>	_____	\$450.00	_____
<b>Model 403-30 Triple Electrical to Optical Interface Card</b> (Order Code: M403-30) <i>Note: Does not include SFP optical modules (card uses one each 6410 and 6408).</i>	_____	\$550.00	_____
<b>SFP Optical Module (video, single-channel receiver)</b> (Order Code: 6411) <i>Note: Non-MSA, supports 3G SDI video.</i>	_____	\$156.00	_____
<b>SFP Optical Module (video, dual-channel receiver)</b> (Order Code: 6407) <i>Note: Non-MSA, supports 3G SDI video.</i>	_____	\$185.00	_____
<b>SFP Optical Module (video, single-channel transmitter)</b> (Order Code: 6410) <i>Note: 1490 nm CWDM laser; non-MSA, supports 3G SDI video.</i>	_____	\$210.00	_____
<b>SFP Optical Module (video, dual-channel transmitter)</b> (Order Code: 6408) <i>Notes: 1310 nm FP laser (channel 1), 1550 nm DFB laser (channel 2), non-MSA, supports 3G SDI video.</i>	_____	\$330.00	_____
<b>Optical Attenuator (4 dB)</b> (Order Code: 6437) <i>Note: LC UPC-M/F.</i>	_____	\$ 15.00	_____
<b>ST-ST Optical Barrel Connector (with nut and lockwasher)</b> (Order Code: 1260)	_____	\$ 6.00	_____
<b>Optical Multiplexer (“mux”) (3 inputs/1 output)</b> (Order Code: 10826) <i>Note: 1310, 1490, and 1550 nm inputs use LC optical connectors; output uses ST optical connector.</i>	_____	\$ 70.00	_____
<b>Optical Demultiplexer (“demux”) (1 input/3 outputs)</b> (Order Code: 10827) <i>Note: Input uses ST optical connector; 1310, 1490, and 1550 nm outputs use LC optical connectors.</i>	_____	\$ 95.00	_____

	Qty	US List Price	Total
<b>Model 410 SDI-Over-Fiber Transport Systems (all Serial Numbers)</b>			
<b>Pushbutton Switch (momentary)</b> (Order Code: 12055) <i>Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND</i>	_____	\$ 4.00	_____
<b>Display Assembly (includes set of 4 each rubber washers (14303) and thin profile nylock nuts (8319))</b> (Order Code: 31601)	_____	\$122.00	_____
<b>Display Lens</b> (Order Code: 15203)	_____	\$ 4.00	_____
<b>Screw-On Bumper Kit (black, set of 8)</b> (Order Code: 31064)	_____	\$ 10.00	_____
<b>12 Vdc, 1.5 A Power Supply (output terminated onto 4-pin female XLR connector)</b> (Order Code: PS-DC-02)	_____	\$ 88.00	_____
<b>Model 403-03 Triple Optical to Electrical Interface Card</b> (Order Code: M403-03) <i>Note: Does not include SFP optical modules (card uses one each 6411 and 6407).</i>	_____	\$450.00	_____
<b>Model 403-30 Triple Electrical to Optical Interface Card</b> (Order Code: M403-30) <i>Note: Does not include SFP optical modules (card uses one each 6410 and 6408).</i>	_____	\$550.00	_____
<b>Model 403-33M Triple Electrical to Optical / Triple Optical to Electrical Interface Card</b> (Order Code: M403-33) <i>Notes: 1. Does not include SFP optical modules. 2. Used as a replacement for both 403-33M and 403-33 cards (card uses one each 6410, 6408, 6411, and 6407).</i>	_____	\$550.00	_____
<b>SFP Optical Module (video, single-channel receiver)</b> (Order Code: 6411) <i>Note: Non-MSA, supports 3G SDI video.</i>	_____	\$156.00	_____
<b>SFP Optical Module (video, dual-channel receiver)</b> (Order Code: 6407) <i>Note: Non-MSA, supports 3G SDI video.</i>	_____	\$185.00	_____
<b>SFP Optical Module (video, single-channel transmitter)</b> (Order Code: 6410) <i>Note: 1490 nm CWDM laser; non-MSA, supports 3G SDI video.</i>	_____	\$210.00	_____
<b>SFP Optical Module (video, dual-channel transmitter)</b> (Order Code: 6408) <i>Notes: 1310 nm FP laser (channel 1), 1550 nm DFB laser (channel 2), non-MSA, supports 3G SDI video.</i>	_____	\$330.00	_____
<b>Optical Attenuator (4 dB)</b> (Order Code: 6437) <i>Note: LC UPC-M/F.</i>	_____	\$ 15.00	_____
<b>ST-ST Optical Barrel Connector (with nut and lockwasher)</b> (Order Code: 1260)	_____	\$ 6.00	_____
<b>Optical Multiplexer (“mux”) (3 inputs/1 output)</b> (Order Code: 10826) <i>Note: 1310, 1490, and 1550 nm inputs use LC optical connectors; output uses ST optical connector.</i>	_____	\$ 70.00	_____
<b>Optical Demultiplexer (“demux”) (1 input/3 outputs)</b> (Order Code: 10827) <i>Note: Input uses ST optical connector; 1310, 1490, and 1550 nm outputs use LC optical connectors.</i>	_____	\$ 95.00	_____
<hr/>			
<b>Model 412 Fiber Transport Systems (all Serial Numbers)</b>			
<b>Pushbutton Switch (momentary)</b> (Order Code: 12055) <i>Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND</i>	_____	\$ 4.00	_____
<b>Display Assembly (includes set of 4 each rubber washers (14303) and thin profile nylock nuts (8319))</b> (Order Code: 31601)	_____	\$122.00	_____
<b>Display Lens</b> (Order Code: 15203)	_____	\$ 4.00	_____
<b>Screw-On Bumper Kit (black, set of 8)</b> (Order Code: 31064)	_____	\$ 10.00	_____
<b>12 Vdc, 1.5 A Power Supply (output terminated onto 4-pin female XLR connector)</b> (Order Code: PS-DC-02)	_____	\$ 88.00	_____
<b>SFP Optical Module (video, single-channel receiver)</b> (Order Code: 6411) <i>Note: Non-MSA, supports 3G SDI video.</i>	_____	\$156.00	_____
<b>SFP Optical Module (video, dual-channel receiver)</b> (Order Code: 6407) <i>Note: Non-MSA, supports 3G SDI video.</i>	_____	\$185.00	_____
<b>SFP Optical Module (video, single-channel transmitter)</b> (Order Code: 6410) <i>Note: 1490 nm CWDM laser; non-MSA, supports 3G SDI video.</i>	_____	\$210.00	_____
<b>SFP Optical Module (video, dual-channel transmitter)</b> (Order Code: 6408) <i>Notes: 1310 nm FP laser (channel 1), 1550 nm DFB laser (channel 2), non-MSA, supports 3G SDI video.</i>	_____	\$330.00	_____
<b>SFP Optical Module (Ethernet, transceiver)</b> (Order Code: 6433) <i>Note: 1310 nm FP laser, MSA, supports 10/100/1000 Ethernet.</i>	_____	\$ 55.00	_____
<b>Optical Attenuator (4 dB)</b> (Order Code: 6437) <i>Note: LC UPC-M/F.</i>	_____	\$ 15.00	_____
<b>ST-ST Optical Barrel Connector (with nut and lockwasher)</b> (Order Code: 1260)	_____	\$ 6.00	_____

	Qty	US List Price	Total
<b>Model 742 Audio Mixer (all Serial Numbers)</b>			
<b>Knob – Inputs 1-8 (black, push-on, 15 mm)</b> (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
<b>Knob Cap – Inputs 1-8 (black w/white line, 15 mm)</b> (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
<b>Potentiometer – Inputs 1-4</b> (Order Code: 2145)	_____	\$ 4.00	_____
<b>Potentiometer – Inputs 5-8</b> (Order Code: 2166)	_____	\$ 4.00	_____
<b>Potentiometer – Master and Monitor (dual-shaft)</b> (Order Code: 2167)	_____	\$12.00	_____
<b>Knob (Top) – Master and Monitor (black w/white line, 11 mm)</b> (Order Code: 14253) <i>Note: Knob (top), knob cap (top), and knob (bottom) are sold separately. See 14255 for knob cap (top) and 14254 for knob (bottom).</i>	_____	\$ 3.00	_____
<b>Knob Cap (Top) – Master and Monitor (black w/white line, 11 mm)</b> (Order Code: 14255) <i>Note: Knob (top), knob cap (top), and knob (bottom) are sold separately. See 14253 for knob (top) and 14254 for knob (bottom).</i>	_____	\$ 3.00	_____
<b>Knob (Bottom) – Master and Monitor (black w/white line, 15 mm)</b> (Order Code: 14254) <i>Note: Knob (top), knob cap (top), and knob (bottom) are sold separately. See 14253 for knob (top) and 14255 for knob cap (top).</i>	_____	\$ 4.00	_____

### Model 742A Audio Mixer (all Serial Numbers)

<b>4-Position DIP Switch</b> (Order Code: 12071)	_____	\$ 5.00	_____
<b>Knob – Inputs 1-8 (black, push-on, 15 mm)</b> (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
<b>Knob Cap – Inputs 1-8 (black w/white line, 15 mm)</b> (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
<b>Potentiometer – Inputs 1-4</b> (Order Code: 2145)	_____	\$ 4.00	_____
<b>Potentiometer – Inputs 5-8</b> (Order Code: 2166)	_____	\$ 4.00	_____
<b>Potentiometer – Master and Monitor (dual-shaft)</b> (Order Code: 2167)	_____	\$12.00	_____
<b>Knob (Top) – Master and Monitor (black w/white line, 11 mm)</b> (Order Code: 14253) <i>Note: Knob (top), knob cap (top), and knob (bottom) are sold separately. See 14255 for knob cap (top) and 14254 for knob (bottom).</i>	_____	\$ 3.00	_____
<b>Knob Cap (Top) – Master and Monitor (black w/white line, 11 mm)</b> (Order Code: 14255) <i>Note: Knob (top), knob cap (top), and knob (bottom) are sold separately. See 14253 for knob (top) and 14254 for knob (bottom).</i>	_____	\$ 3.00	_____
<b>Knob (Bottom) – Master and Monitor (black w/white line, 15 mm)</b> (Order Code: 14254) <i>Note: Knob (top), knob cap (top), and knob (bottom) are sold separately. See 14253 for knob (top) and 14255 for knob cap (top).</i>	_____	\$ 4.00	_____
<b>Power Supply (universal AC mains input/12 V, 1.25 A (15 watts) output)</b> (Order Code: 10354) <i>Mfg. No.: Cincon CFM1502S; Digi-Key No.: 2034-3555-ND; Mouser No.: 418-CFM1502S</i>	_____	\$35.00	_____

### Model 750 Audio Mixer (Serial Numbers 00151 – 00400)

<b>Potentiometer – Mic/Line Input (dual-shaft, 3-section 10KB//50KA/50KA)</b> (Order Code: 2130)	_____	\$16.00	_____
<b>Potentiometer – Stereo Line Input, Main, and Aux Outputs (dual-shaft 50KA/50KA)</b> (Order Code: 2131)	_____	\$12.00	_____
<b>Potentiometer – Speaker and Phones (single-shaft, dual-section 10KA/10KA)</b> (Order Code: 2128)	_____	\$ 8.00	_____
<b>Pushbutton Switch (push-push)</b> (Order Code: 12016)	_____	\$ 3.00	_____
<b>Pushbutton Cap (illuminated, gray, 12.5 mm x 6.8 mm)</b> (Order Code: 14228)	_____	\$ 3.00	_____
<b>Pushbutton Cap (gray, 5.5 mm square)</b> (Order Code: 14229)	_____	\$ 1.50	_____
<b>Knob – Speaker and Phones (black w/white line, 16 mm)</b> (Order Code: 14231)	_____	\$ 3.00	_____
<b>Knob Base– Inputs and Master (black w/white line, 16 mm)</b> (Order Code: 14233) <i>Note: Knob base and knob top are sold separately. See 14232 for knob top.</i>	_____	\$ 3.00	_____
<b>Knob Top– Inputs and Master (black w/white line, 10.5 mm)</b> (Order Code: 14232) <i>Note: Knob base and knob top are sold separately. See 14233 for knob base.</i>	_____	\$ 3.00	_____

	Qty	US List Price	Total
<b>Model 750 Audio Mixer (Serial Numbers 00401 – later)</b>			
Potentiometer – Mic/Line Input (dual-shaft, 3-section 10KB//50KA/50KA) (Order Code: 2130)	_____	\$16.00	_____
Potentiometer – Stereo Line Input, Main, and Aux Outputs (dual-shaft 50KA/50KA) (Order Code: 2131)	_____	\$12.00	_____
Potentiometer – Speaker and Phones (single-shaft, dual-section 10KA/10KA) (Order Code: 2128)	_____	\$ 8.00	_____
Pushbutton Switch (push-push) (Order Code: 12016)	_____	\$ 3.00	_____
Pushbutton Cap (illuminated, gray, 12.5 mm x 6.8 mm) (Order Code: 14228)	_____	\$ 3.00	_____
Pushbutton Cap (gray, 5.5 mm square) (Order Code: 14229)	_____	\$ 1.50	_____
Knob – Speaker and Phones (black, 15 mm) (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 14252 for knob cap.</i>	_____	\$ 3.00	_____
Knob Cap – Speaker and Phones (gray w/black line, 15 mm) (Order Code: 14252) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
Knob Base – Inputs and Master (black w/white line, 15 mm) (Order Code: 14249) <i>Note: Knob base, knob top, and knob cap are sold separately. See 14250 for knob top and 14251 for knob cap.</i>	_____	\$ 3.00	_____
Knob Top – Inputs and Master (black w/white line, push-on, 11 mm) (Order Code: 14250) <i>Note: Knob base, knob top, and knob cap are sold separately. See 14249 for knob base and 14251 for knob cap.</i>	_____	\$ 3.00	_____
Knob Cap – Inputs and Master (gray w/black line, 11 mm) (Order Code: 14251) <i>Note: Knob base, knob top, and knob cap are sold separately. See 14249 for knob base and 14250 for knob top.</i>	_____	\$ 3.00	_____

	Qty	US List Price	Total
<b>Model 5100-Series Broadcast Support Modules (all Serial Numbers)</b>			
Contact Factory as Required			
<hr/>			
<b>Model 5202 Dante to Phones and Line Output Interface (all Serial Numbers)</b>			
<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
<b>Push-Pot Potentiometer Assembly (dual-section)</b> (Order Code: 32298) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
<b>1/4" Phone Jack</b> (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
<b>Nut (plastic)</b> (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
<hr/>			
<b>Model 5204 Dual Line Input to Dante Interface (all Serial Numbers)</b>			
<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
<b>Push-Pot Potentiometer Assembly (dual-section)</b> (Order Code: 32298) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
<b>3.5 mm Stereo Jack</b> (Order Code: 1198)	_____	\$ 3.00	_____
<hr/>			
<b>Model 5304 Intercom Station (all Serial Numbers)</b>			
<b>Knob – Glow (black w/clear center, 13 mm dia. x 13.8 mm tall)</b> (Order Code: 14340)	_____	\$ 5.00	_____
<b>Rotary Encoder (24-step w/switch, 21 mm overall length)</b> (Order Code: 12109)	_____	\$ 8.00	_____
<b>Pushbutton Switch (momentary, 17 mm x 17 mm)</b> (Order Code: 12106)	_____	\$ 6.00	_____
<b>1/4" Phone Jack</b> (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
<b>Nut (plastic)</b> (Order Code: 1090) <i>Note: For use with 1/4" phone jack.</i>	_____	\$ 1.50	_____
<b>Rubber Bumper (black, set of 4, 1/2" dia. by 7/32" tall)</b> (Order Code: 14339) <i>Note: Bumpers and machine screws are sold separately. See 8032-5/16 for screws.</i>	_____	\$ 6.00	_____
<b>Machine Screw (SEMS, 4-40x5/16")</b> (Order Code: 8032-5/16) <i>Note: Machine screws and bumpers are sold separately. See 14339 for bumpers.</i>	_____	\$ 0.50	_____
<hr/>			
<b>Model 5330 Flex-Use Dante Audio Interface (all Serial Numbers)</b>			
<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
<b>Push-Pot Potentiometer Assembly (dual-section)</b> (Order Code: 32298) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
<b>1/4" Phone Jack</b> (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
<b>Nut (plastic)</b> (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
<b>Power Supply (universal AC mains input/12 V, 1.25 A (15 watts) output)</b> (Order Code: 10354) <i>Mfg. No.: Cincon CFM1502S; Digi-Key No.: 2034-3555-ND; Mouser No.: 418-CFM1502S</i>	_____	\$35.00	_____
<b>3.5 mm Stereo Jack</b> (Order Code: 1198)	_____	\$ 3.00	_____
<hr/>			
<b>Model 5364 Headset Interface (all Serial Numbers)</b>			
<b>Rubber Bumper (black, set of 4, 1/2" dia. by 7/32" tall)</b> (Order Code: 14339) <i>Note: Bumpers and machine screws are sold separately. See 8032-5/16 for screws.</i>	_____	\$ 6.00	_____
<b>Machine Screw (SEMS, 4-40x5/16")</b> (Order Code: 8032-5/16) <i>Note: Machine screws and bumpers are sold separately. See 14339 for bumpers.</i>	_____	\$ 0.50	_____

	Qty	US List Price	Total
<b>Model 5401 Dante Master Clock (all Serial Numbers)</b>			
<b>Power Supply (universal AC mains input/12 V, 1.25 A (15 watts) output) (Order Code: 10354)</b>	_____	\$35.00	_____
<i>Mfg. No.: Cincon CFM1502S; Digi-Key No.: 2034-3555-ND; Mouser No.: 418-CFM1502S</i>			
<hr/>			
<b>Model 5401A Dante Leader Clock (all Serial Numbers)</b>			
<b>Power Supply (universal AC mains input/12 V, 1.25 A (15 watts) output) (Order Code: 10354)</b>	_____	\$35.00	_____
<i>Mfg. No.: Cincon CFM1502S; Digi-Key No.: 2034-3555-ND; Mouser No.: 418-CFM1502S</i>			
<hr/>			
<b>Model 5402 Dante Leader Clock with GNSS Synchronization (all Serial Numbers)</b>			
<b>Power Supply (universal AC mains input/12 V, 1.25 A (15 watts) output) (Order Code: 10354)</b>	_____	\$35.00	_____
<i>Mfg. No.: Cincon CFM1502S; Digi-Key No.: 2034-3555-ND; Mouser No.: 418-CFM1502S</i>			
<b>GNSS Antenna (Order Code: ANT-GNSS-01)</b>	_____	\$92.00	_____
<i>Mfg. No.: U-Blox ANN-MB-00-00; Digi-Key No.: 672-ANN-MB-00-00-ND</i>			
<hr/>			
<b>Model 5412-Series Audio Interfaces (all Serial Numbers)</b>			
<b>Power Supply (universal AC mains input/12 V, 1.8 A (20 watts) output) (Order Code: 10355)</b>	_____	\$32.00	_____
<i>Mfg. No.: Cincon CFM2002S; Digi-Key No.: 2034-3589-ND; Mouser No.: 418-CFM2002S</i>			
<hr/>			
<b>Model 5414 Mic/Line Input &amp; Line Output Interface (all Serial Numbers)</b>			
<b>Knob (black w/white line, 9 mm) (Order Code: 14287)</b>	_____	\$ 3.00	_____
<i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>			
<b>Set Screw (Order Code: 8210-1/8)</b>	_____	\$ 0.50	_____
<i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>			
<b>Push-Pot Potentiometer Assembly (dual-section) (Order Code: 32298) (for s/n 00151-01150)</b>	_____	\$ 9.00	_____
<i>Note: Includes push-pot (2171) and sleeve (14297).</i>			
<b>Push-Pot Potentiometer Assembly (single-section) (Order Code: 32299) (for s/n 01151-later)</b>	_____	\$ 9.00	_____
<i>Note: Includes push-pot (2172) and sleeve (14297).</i>			
<b>Pushbutton Switch (momentary) – Channel Select (Order Code: 12056)</b>	_____	\$ 4.00	_____
<b>Pushbutton Cap (gray) (Order Code: 14207)</b>	_____	\$ 3.00	_____
<b>1/4" Phone Jack (Order Code: 1084)</b>	_____	\$ 4.00	_____
<i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>			
<b>Nut (plastic) (Order Code: 1090)</b>	_____	\$ 1.50	_____
<i>Note: Nut is required for installation of 1/4" phone jack.</i>			
<b>Power Supply (universal AC mains input/12 V, 1.25 A (15 watts) output) (Order Code: 10354)</b>	_____	\$35.00	_____
<i>Mfg. No.: Cincon CFM1502S; Digi-Key No.: 2034-3555-ND; Mouser No.: 418-CFM1502S</i>			
<hr/>			
<b>MD-4 Mic/Line Input &amp; Line Output Interface (all Serial Numbers)</b>			
<b>Knob (black w/white line, 9 mm) (Order Code: 14287)</b>	_____	\$ 3.00	_____
<i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>			
<b>Set Screw (Order Code: 8210-1/8)</b>	_____	\$ 0.50	_____
<i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>			
<b>Push-Pot Potentiometer Assembly (single-section) (Order Code: 32299)</b>	_____	\$ 9.00	_____
<i>Note: Includes push-pot (2172) and sleeve (14297).</i>			
<b>Pushbutton Switch (momentary) – Channel Select (Order Code: 12056)</b>	_____	\$ 4.00	_____
<b>Pushbutton Cap (gray) (Order Code: 14207)</b>	_____	\$ 3.00	_____
<b>1/4" Phone Jack (Order Code: 1084)</b>	_____	\$ 4.00	_____
<i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>			
<b>Nut (plastic) (Order Code: 1090)</b>	_____	\$ 1.50	_____
<i>Note: Nut is required for installation of 1/4" phone jack.</i>			
<b>Power Supply (universal AC mains input/12 V, 1.25 A (15 watts) output) (Order Code: 10354)</b>	_____	\$35.00	_____
<i>Mfg. No.: Cincon CFM1502S; Digi-Key No.: 2034-3555-ND; Mouser No.: 418-CFM1502S</i>			
<hr/>			

	Qty	US List Price	Total
<b>Model 5418 Mic/Line Interface (all Serial Numbers)</b>			
Power Supply (universal AC mains input/12 V, 1.8 A (20 watts) output) (Order Code: 10355) Mfg. No.: Cincon CFM2002S; Digi-Key No.: 2034-3589-ND; Mouser No.: 418-CFM2002S	_____	\$32.00	_____
<b>Model 5421 Dante Intercom Audio Engine (all Serial Numbers)</b>			
Screw-On Bumper Kit (black, set of 8) (Order Code: 31064)	_____	\$10.00	_____
<b>Model 5422-Series Dante Audio Intercom Engines (all Serial Numbers)</b>			
Power Supply (universal AC mains input/12 V, 1.25 A (15 watts) output) (Order Code: 10354) Mfg. No.: Cincon CFM1502S; Digi-Key No.: 2034-3555-ND; Mouser No.: 418-CFM1502S	_____	\$35.00	_____
<b>Model 5422A-Series Dante Audio Intercom Engines (all Serial Numbers)</b>			
Power Supply (universal AC mains input/12 V, 1.25 A (15 watts) output) (Order Code: 10354) Mfg. No.: Cincon CFM1502S; Digi-Key No.: 2034-3555-ND; Mouser No.: 418-CFM1502S	_____	\$35.00	_____



	Qty	US List Price	Total
<b>Model 5512-Series Audio Interfaces (all Serial Numbers)</b>			
<b>Power Supply (universal AC mains input/12 V, 1.8 A (20 watts) output) (Order Code: 10355)</b>	_____	\$32.00	_____
<i>Mfg. No.: Cincon CFM2002S; Digi-Key No.: 2034-3589-ND; Mouser No.: 418-CFM2002S</i>			

---

<b>Model 5518 Mic/Line Interface (all Serial Numbers)</b>			
<b>Power Supply (universal AC mains input/12 V, 1.8 A (20 watts) output) (Order Code: 10355)</b>	_____	\$32.00	_____
<i>Mfg. No.: Cincon CFM2002S; Digi-Key No.: 2034-3589-ND; Mouser No.: 418-CFM2002S</i>			

---

	Qty	US List Price	Total
<b>Live-Link Sr. Remote Camera Interface Systems (all Serial Numbers)</b>			
<b>Live-Link Sr. Portable Cover Assembly for Anton-Bauer Battery</b> (Order Code: LL-COVER-01) <i>Note: Consists of portable cover (31341) with lifting handle (32204), Anton-Bauer Bracket Kit (31414), and bumpers (32297) installed.</i>		\$303.00	
<b>Portable Cover</b> (Order Code: 31341) <i>Note: Does not include lifting handle, battery bracket, bumpers, or hardware.</i>		\$150.00	
<b>Lifting Handle Kit (black lifting handle and set of 6 6-32x1/4" screws)</b> (Order Code: 32204)		\$ 26.00	
<b>Anton-Bauer Battery Bracket Kit (battery bracket w/insulator and 15" cable assembly)</b> (Order Code: 31414)		\$115.00	
<b>Back of Cover Bumper Kit (set of 4 each 3/4" dia. by 5/8" tall bumpers, 10-24x3/4" screws, and 10-24 nylock nuts)</b> (Order Code: 32297) <i>Note: Used for back of portable enclosure.</i>		\$ 12.00	
<b>Live-Link Sr. Cover for Special Installations</b> (Order Code: LL-COVER-02) <i>Note: Consists only of protective cover (31351) with no provision for attaching lifting handle, battery bracket, or bumpers.</i>		\$150.00	
<b>Live-Link Sr. Portable Cover Assembly for V-Mount Battery</b> (Order Code: LL-COVER-03) <i>Note: Consists of portable cover (modified 31341) with lifting handle (32204), V-Mount Bracket (14301), and bumpers (32297) installed.</i>		\$303.00	
<b>Chassis Bumper Kit (set of 4 each 1.5" dia. by 3/4" tall bumpers, 80918-708 screws, and 1/4-20 Keps nuts)</b> (Order Code: 32203) <i>Note: Used for bottom of portable enclosure.</i>		\$ 16.00	
<b>12 Vdc, 5 A Power Supply (output terminated onto 4-pin female XLR connector)</b> (Order Code: PS-DC-01)		\$110.00	
<b>Audio Cable (XLR5M to XLR3F/XLR3M)</b> (Order Code: 13662)		\$ 42.00	
<b>10/100/1000 Ethernet Media Converter Upgrade Kit</b> (Order Code: M432-KIT)		\$240.00	
<b>Live-Link Jr. Remote Camera Interface Systems (all Serial Numbers)</b>			
<b>Pushbutton Switch (momentary) – Auto Null</b> (Order Code: 12056)		\$ 4.00	
<b>Pushbutton Cap – Truck End Auto Null (gray)</b> (Order Code: 14207)		\$ 3.00	
<b>Chassis Bumper Kit (set of 4 each 3/4" dia. by 3/8" tall bumpers and 6-32x3/8" screws)</b> (Order Code: 32202) <i>Note: Used for bottom of portable enclosure.</i>		\$ 12.00	
<b>Lifting Handle Kit (black lifting handle and set of 6 6-32x1/4" screws)</b> (Order Code: 32204)		\$ 26.00	
<b>12 Vdc, 1.55 A Power Supply (output terminated onto 4-pin female XLR connector)</b> (Order Code: PS-DC-02)		\$ 88.00	
<b>Live-Link Mini Remote Camera Interface Systems (all Serial Numbers)</b>			
<b>Pushbutton Switch (momentary) – Auto Null</b> (Order Code: 12056)		\$ 4.00	
<b>Pushbutton Cap – Camera End and Truck End Auto Null (gray)</b> (Order Code: 14207)		\$ 3.00	
<b>Chassis Bumper Kit (set of 4 each 5/8" dia. by 3/4" tall bumpers and 6-32x5/8" screws)</b> (Order Code: 32205) <i>Note: Used for bottom of portable enclosure.</i>		\$ 12.00	
<b>Lifting Handle Kit (black lifting handle and set of 6 6-32x1/4" screws)</b> (Order Code: 32204)		\$ 26.00	
<b>12 Vdc, 1.55 A Power Supply (output terminated onto 4-pin female XLR connector)</b> (Order Code: PS-DC-02)		\$ 88.00	
<b>Audio Cable (XLR5F to Dual XLR3M)</b> (Order Code: 13684)		\$ 42.00	

	Qty	US List Price	Total
<b>Live-Link Miscellaneous Parts (contact factory for part identification assistance)</b>			
<b>BNC-BNC Bulkhead Connector (with nut and lockwasher)</b> (Order Code: 1243)	_____	\$ 10.00	_____
<b>ST-ST Optical Barrel Connector (with nut and lockwasher)</b> (Order Code: 1260)	_____	\$ 6.00	_____
<b>SFP Optical Module (video, transceiver)</b> (Order Code: 6406) <i>Note: 1310 nm FP Laser; MSA, supports 3G SDI video.</i>	_____	\$184.00	_____
<b>SFP Optical Module (video, transceiver)</b> (Order Code: 6412) <i>Note: 1550 nm CWDM Laser; MSA, supports 3G SDI video.</i>	_____	\$290.00	_____
<b>SFP Optical Module (video, single-channel receiver)</b> (Order Code: 6411) <i>Note: Non-MSA, supports 3G SDI video.</i>	_____	\$156.00	_____
<b>SFP Optical Module (video, single-channel transmitter)</b> (Order Code: 6413) <i>Note: 1530 nm CWDM Laser; non-MSA, supports 3G SDI video.</i>	_____	\$210.00	_____
<b>SFP Optical Module (Ethernet, transceiver)</b> (Order Code: 6418) <i>Note: 1490 nm CWDM laser; MSA, supports 10/100/1000 Ethernet.</i>	_____	\$ 85.00	_____
<b>Optical Multiplexer (“mux”) (3 inputs/1 output)</b> (Order Code: 10826) <i>Note: 1310, 1490, and 1550 nm inputs use LC optical connectors; output uses ST optical connector.</i>	_____	\$ 70.00	_____
<b>Optical Demultiplexer (“demux”) (1 input/3 outputs)</b> (Order Code: 10827) <i>Note: Input uses ST optical connector; 1310, 1490, and 1550 nm outputs use LC optical connectors.</i>	_____	\$ 95.00	_____
<b>Optical Multiplexer (“mux”) (3 inputs/1 output)</b> (Order Code: 10833) <i>Note: 1310, 1490, and 1550 nm inputs use LC connectors; output uses LC optical connector.</i>	_____	\$ 70.00	_____
<b>Optical Demultiplexer (“demux”) (1 input/3 outputs)</b> (Order Code: 10834) <i>Note: Input uses LC optical connector, 1310, 1490, and 1550 nm outputs use LC optical connectors.</i>	_____	\$ 95.00	_____
<b>Optical Multiplexer (“mux”) (4 inputs/1 output)</b> (Order Code: 10831) <i>Note: 1310, 1490, 1530, and 1550 nm inputs use LC optical connectors; output uses ST optical connector.</i>	_____	\$105.00	_____
<b>Optical Demultiplexer (“demux”) (1 input/4 outputs)</b> (Order Code: 10832) <i>Note: Input uses ST optical connector; 1310, 1490, 1530, and 1550 nm outputs use LC optical connectors.</i>	_____	\$120.00	_____
<b>Optical Jumper Cable (single-mode, length 280 mm overall)</b> (Order Code: 10845) <i>Note: LC optical connectors on both ends.</i>	_____	\$ 9.00	_____
<b>Optical Jumper Cable (single-mode, length 300 mm overall)</b> (Order Code: 10846) <i>Note: LC optical connector on one end, ST optical connector on other end.</i>	_____	\$ 9.00	_____

	Qty	US List Price	Total
<b>Miscellaneous Parts</b>			
<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
<b>Knob (blue w/no line, 9 mm)</b> (Order Code: 14310) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
<b>Knob (green w/no line, 9 mm)</b> (Order Code: 14311) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
<b>Knob (gold w/no line, 9 mm)</b> (Order Code: 14312) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately.</i>	_____	\$ 0.50	_____

**Notes:**

Prices effective January 25, 2023. Subject to change without notice. All shipments FOB Skokie, IL 60077 USA.