






Models 204/205/206 Announcer's Consoles Example Screen Images

STcontroller: Example Pages



Models 204/205/206 Announcer's Consoles Example Screen Images

Dante Controller: Example Routing Menus

The screenshot shows the Dante Controller interface for model 204. At the top left is the Dante logo. Below it, there are two filter boxes: "Filter Transmitters" containing "204" and "Filter Receivers" containing "204". To the right of these filters is a vertical list of transmitters labeled "Transmitters (1)", with "ST-M204-906fe0" selected. Below the transmitters is a section for "Receivers (1)", which is expanded to show "ST-M204-906fe0" with four sub-items: "Headphone Ch1", "Headphone Ch2", "Headphone Ch3", and "Headphone Ch4". On the far right, there are two circular icons labeled "Main" and "Talkback".

The screenshot shows the Dante Controller interface for model 205. It follows the same layout as the model 204 screenshot. The "Filter Transmitters" and "Filter Receivers" boxes both contain "205". The transmitter list "Transmitters (1)" shows "ST-M205-906fe0" selected. The receiver list "Receivers (1)" is expanded to show "ST-M205-906fe0" with sub-items "Headphone Ch1" through "Headphone Ch4". On the far right, there are three circular icons labeled "Main", "Talkback 1", and "Talkback 2".

The screenshot shows the Dante Controller interface for model 206. The "Filter Transmitters" and "Filter Receivers" boxes both contain "206". The transmitter list "Transmitters (1)" shows "ST-M206-906fe0" selected. The receiver list "Receivers (1)" is expanded to show "ST-M206-906fe0" with sub-items "Headphone Ch1" through "Headphone Ch4". On the far right, there are four circular icons labeled "Main", "Talkback 1", "Talkback 2", and "Talkback 3".

Models 204/205/206 Announcer's Consoles Example Screen Images

VenueView: Example Menus

