




# Models 214A/215A/216A Announcer's Consoles Example Screen Images

## **STcontroller: Example Pages**










# Models 214A/215A/216A Announcer's Consoles Example Screen Images

### **Dante Controller: Example Routing Menus**







# Models 214A/215A/216A Announcer's Consoles Example Screen Images

#### M21xA × File Venue Help ST-M216A-97be3a ST-M214A-97be1a ST-M215A-97be7e Τx Tx Tx 0 0 0 Main Main Main dBFS dBFS dBFS TB1 TB1 TB2 TB2 TB3 -20 -20 -20 Rx: Rx-Rx-HP1 HP1 HP1 HP2 HP2 HP3 HP3 HP3 HP4 HP4 HP4 40 dB 40 dB 40 dB

# **VenueView: Example Menus**