



# Replacement Parts List

All prices effective January 15, 2025. Subject to change without notice. Parts availability subject to factory stock levels. Certain parts may become obsolete without notice.

## Table of Contents

Page	Product	Page	Product
3	Model 2 Central Controller	11	Model 76 Central Controller
3	Model 2A Central Controller	11	Model 76B Central Controller
3	Model 22 Access Station	11	Model 76D Central Controller
3	Model 24 Access Station	11	Model 76DA Central Controller
4	Model 32 Talent Amplifier	11	Model 77 Control Console
4	Model 32A Talent Amplifier	11	Model 77B Control Console
4	Model 33 Talent Amplifier	11	Model 79 Control Console
5	Model 33A Talent Amplifier	12	Model 92 DT12 Cable Assembly Test Unit
5	Model 34 Talent Amplifier	12	Model 93 W1 Cable Assembly Test Unit
5	Model 35 Talent Amplifier	12	Model 201 Interpreter's Console
6	Model 36 Talent Interface	12	Models 203, 204, 205, and 206 Announcer's Consoles
6	Model 37 Intercom Beltpack	12	Model 207 eSports Console
6	Model 41 Interface	13	Model 207A eSports Console
7	Model 42A Interface	13	Model 208 Announcer's Console
7	Model 43D IFB Interface	13	Model 209 Talent Console
7	Model 44D Audio Interface	14	Models 210, 211, 212, 220, 230, and 233 Announcer's Consoles
7	Model 45 Interface	14	Models 214, 215, and 216 Announcer's Consoles
7	Model 45A Interface	15	Models 214A, 215A, and 216A Announcer's Consoles
7	Model 45DC Intercom Interface	15	Models 232, 234, and 236 Announcer's Consoles
7	Model 45DR Intercom Interface	16	Model 240 Producer's Console
7	Model 46 Interface	16	Model 342 Intercom Station
7	Model 46A Interface	16	Model 348 Intercom Station
8	Model 47 Interface	17	Model 352A Talk Station
8	Model 47A Interface	17	Model 354 Talk Station
8	Model 48D Dante Bridge	17	Model 354A Talk Station
8	Model 51 Control Console	17	GME-3-12 Gooseneck Microphone
8	Model 56 Control Console	18	Model 362 Listen-Only Beltpack
8	Models 59 and 591 Control Consoles	18	Model 362A Listen-Only Beltpack
9	Model 60 Central Controller	18	Model 370 Intercom Beltpack
9	Model 60A Central Controller	19	Model 370A Intercom Beltpack
9	Model 61 Control Console	19	Model 371 Intercom Beltpack
10	Model 69 Control Console	19	Model 371A Intercom Beltpack
10	Model 69A Control Console	20	Model 372A Intercom Beltpack
10	Model 71 Control Console	20	Model 373A Intercom Beltpack
10	Model 72 Level Meter / Interface	20	Model 374 Intercom Beltpack
10	Model 74 Central Controller	20	Model 374A Intercom Beltpack
10	Model 75 Control Console		

## Table of Contents

<b>Page</b>	<b>Product</b>	<b>Page</b>	<b>Product</b>
21	Model 380 On-Air Beltpack	30	Model 5422-Series Dante Intercom Audio Engines
21	Model 381 On-Air Beltpack	30	Model 5422A-Series Dante Intercom Audio Engines
21	Model 391 Dante Alerting Unit	30	Model 5482-Series Dante Bridges
21	Model 392 Visual Indicator Unit	30	Model 5512-Series Audio Interfaces
22	Model 400 SDI-Over-Fiber Transport Systems	30	Model 5512A-Series Audio Interfaces
22	Model 400A SDI-Over-Fiber Transport Systems	30	Model 5518 Mic/Line Interface
23	Model 410 SDI-Over-Fiber Transport Systems	30	Model 5518A Mic/Line Interface
23	Model 412 Fiber Transport Systems	30	Model 5682-Series ST 2110 to Dante Bridges
24	Model 543D IFB Interface	31	Live-Link Sr. Remote Camera Interface Systems
24	Model 544D Audio Interface	31	Live-Link Jr. Remote Camera Interface Systems
24	Model 545AC Intercom Interface	31	Live-Link Mini Remote Camera Interface Systems
24	Model 545AR Intercom Interface	32	Live-Link Miscellaneous Parts
24	Model 545DC Intercom Interface	32	Miscellaneous Parts
24	Model 545DR Intercom Interface		
24	Model 742 Audio Mixer		
25	Model 742A Audio Mixer		
25	Model 750 Audio Mixer		
26	Model 760-Series Central Controllers		
26	Model 761 Central Controller		
26	Model 780-Series Central Controllers		
26	Model 790 Control Console		
26	Model 792 Central Controller		
26	Model 793 Control Console		
26	Model 794-Series Central Controllers		
27	Model 795 Control Console		
27	Model 5100-Series Broadcast Support Modules		
27	Model 5202 Dante to Phones & Line Output Interface		
27	Model 5204 Dual Line Input to Dante Interface		
27	Model 5304 Intercom Station		
28	Model 5312 Intercom Station		
28	Model 5330 Flex-Use Dante Audio Interface		
28	Model 5364 Headset Interface		
28	Model 5365 Headset Interface		
28	Model 5401 Dante Master Clock		
28	Model 5401A Dante Leader Clock		
28	Model 5402 Dante Leader Clock with GNSS Synchronization		
28	Model 5412-Series Audio Interfaces		
29	Model 5414 Mic/Line Input & Line Output Interface		
29	MD-4 Mic/Line Input & Line Output Interface		
29	Model 5418 Mic/Line Interface		
29	Model 5421 Dante Intercom Audio Engine		

	Qty	US List	Total
<b>Model 2 Central Controller (all Serial Numbers)</b>			
<b>Knob – Program and Monitor Output (black, push-on, 15 mm)</b> (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
<b>Knob Cap – Program and Monitor Output (black w/white line, 15 mm)</b> (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
<b>Pushbutton Cap (gray)</b> (Order Code: 12050) <i>Mfg. No.: E-Switch TACGRY; Digi-Key No.: EG1082-ND</i>	_____	\$ 4.00	_____
<b>Potentiometer – Program 1, Program 2, Monitor Output</b> (Order Code: 2126)	_____	\$ 4.00	_____
<b>Pushbutton Switch (momentary) – IFB 1, IFB 2</b> (Order Code: 12064)	_____	\$ 4.00	_____
<b>Pushbutton Switch Assembly (6-position, interlock) – Program Select</b> (Order Code: 12036)	_____	\$12.00	_____
<b>Toggle Switch – VOX IFB Input Select</b> (Order Code: 12054)	_____	\$26.00	_____
<b>Toggle Switch – VOX IFB Output Select</b> (Order Code: 12052)	_____	\$22.00	_____
<b>Toggle Switch (momentary) – Telco 1, Telco 2, Manual Off-Hook/Hang-Up Select</b> (Order Code: 12053)	_____	\$22.00	_____
<b>Toggle Switch – Telco 2 Send/Rcv and Monitor Source Select</b> (Order Code: 12051)	_____	\$22.00	_____
<b>Pushbutton Switch (push-push) – Telco Std/Wet 1, Telco Std/Wet 2</b> (Order Code: 12016)	_____	\$ 3.00	_____
<b>Model 2A Central Controller (all Serial Numbers)</b>			
<b>Knob – Program and Monitor Output (black, push-on, 15 mm)</b> (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
<b>Knob Cap – Program and Monitor Output (black w/white line, 15 mm)</b> (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
<b>Pushbutton Cap (gray)</b> (Order Code: 12050) <i>Mfg. No.: E-Switch TACGRY; Digi-Key No.: EG1082-ND</i>	_____	\$ 4.00	_____
<b>Potentiometer – Program 1, Program 2, Monitor Output</b> (Order Code: 2126)	_____	\$ 4.00	_____
<b>Pushbutton Switch (momentary) – IFB 1, IFB 2</b> (Order Code: 12064)	_____	\$ 4.00	_____
<b>Pushbutton Switch Assembly (6-position, interlock) – Program Select</b> Order Code: 12036)	_____	\$12.00	_____
<b>Toggle Switch (momentary) – Telco 1, Telco 2, Manual Off-Hook/Hang Up Select</b> (Order Code: 12093)	_____	\$ 9.00	_____
<b>Toggle Switch – VOX IFB, Telco 2 Send/Rcv, Monitor Source Select</b> (Order Code: 12091)	_____	\$ 9.00	_____
<b>Pushbutton Switch (push-push) – Telco Std/Wet 1, Telco Std/Wet 2</b> (Order Code: 12016)	_____	\$ 3.00	_____
<b>Power Supply (universal AC mains input/12 V, 3.34 A (40 watts) output)</b> (Order Code: 10303) <i>Mfg. No.: Cincon CFM40S120; Digi-Key No.: 2034-3674-ND; Mouser No.: 418-CFM40S120</i>	_____	\$45.00	_____
<b>Model 22 Access Station (all Serial Numbers)</b>			
<b>Pushbutton Switch (momentary, Mfg. by EAO)</b> (Order Code: 12028) <i>Note: Does not include button cap, lens, or label. See 31069.</i>	_____	\$14.00	_____
<b>Button Cap, Lenses, and Label Kit (includes five each button cap, clear lens, frosted lens, and one button function label sheet (15154))</b> (Order Code: 31069)	_____	\$40.00	_____
<b>Backlight Lamp (T1, 18 V, incandescent)</b> (Order Code: 12030)	_____	\$ 4.00	_____
<b>Model 24 Access Station (all Serial Numbers)</b>			
<b>Pushbutton Switch (momentary, Mfg. by EAO)</b> (Order Code: 12028) <i>Note: Does not include button cap, lens, or label. See 31069.</i>	_____	\$14.00	_____
<b>Button Cap, Lenses, and Label Kit (includes five each button cap, clear lens, frosted lens, and one button function label sheet (15154))</b> (Order Code: 31069)	_____	\$40.00	_____
<b>Backlight Lamp (T1, 18 V, incandescent)</b> (Order Code: 12030)	_____	\$ 4.00	_____

	Qty	US List	Total
<b>Model 32 Talent Amplifier (Serial Numbers 00001 – 00299)</b>			
<b>Knob (black, push-on, 15 mm)</b> (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
<b>Knob Cap (black w/white line, 15 mm)</b> (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
<b>Potentiometer</b> (Order Code: 2148)	_____	\$ 4.00	_____
<b>Toggle Switch – Ch 1/2 Select</b> (Order Code: 12021)	_____	\$ 6.00	_____
<b>3-Pin Male XLR Connector</b> (Order Code: 1093)	_____	\$ 7.00	_____
<b>3-Pin Female XLR Connector</b> (Order Code: 1094)	_____	\$ 8.00	_____
<b>1/4" Phone Jack</b> (Order Code: 1053)	_____	\$ 7.00	_____
<b>Belt Clip (black, steel)</b> (Order Code: 30247)	_____	\$ 5.00	_____
<b>Pop-Rivet – for Belt Clip (black, aluminum, 0.125" grip)</b> (Order Code: 8201-.125)	_____	\$ 1.00	_____

<b>Model 32 Talent Amplifier (Serial Numbers 00300 – later)</b>			
<b>Knob (black, push-on, 15 mm)</b> (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
<b>Knob Cap (black w/white line, 15 mm)</b> (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
<b>Potentiometer</b> (Order Code: 2148)	_____	\$ 4.00	_____
<b>Toggle Switch – Ch 1/2 Select</b> (Order Code: 12021)	_____	\$ 6.00	_____
<b>3-Pin Male XLR Connector</b> (Order Code: 1093)	_____	\$ 7.00	_____
<b>3-Pin Female XLR Connector</b> (Order Code: 1094)	_____	\$ 8.00	_____
<b>1/4" Phone Jack</b> (Order Code: 1086)	_____	\$ 4.00	_____
<b>Belt Clip (black, steel)</b> (Order Code: 30247)	_____	\$ 5.00	_____
<b>Pop-Rivet – for Belt Clip (black, aluminum, 0.125" grip)</b> (Order Code: 8201-.125)	_____	\$ 1.00	_____

<b>Model 32A Talent Amplifier (all Serial Numbers)</b>			
<b>Knob (black, push-on, 15 mm)</b> (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
<b>Knob Cap (black w/white line, 15 mm)</b> (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
<b>Potentiometer</b> (Order Code: 2148)	_____	\$ 4.00	_____
<b>Toggle Switch – Ch 1/2 Select</b> (Order Code: 12021)	_____	\$ 6.00	_____
<b>3-Pin Male XLR Connector</b> (Order Code: 1093)	_____	\$ 7.00	_____
<b>3-Pin Female XLR Connector</b> (Order Code: 1094)	_____	\$ 8.00	_____
<b>1/4" Phone Jack</b> (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
<b>Nut (plastic)</b> (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
<b>3.5 mm Stereo Jack</b> (Order Code: 1198)	_____	\$ 3.00	_____
<b>Belt Clip (black, steel)</b> (Order Code: 30247)	_____	\$ 5.00	_____
<b>Pop-Rivet – for Belt Clip (black, aluminum, 0.125" grip)</b> (Order Code: 8201-.125)	_____	\$ 1.00	_____

<b>Model 33 Talent Amplifier (all Serial Numbers)</b>			
<b>Knob – Ch 1 and Ch 2 (black, push-on, 15 mm)</b> (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
<b>Knob Cap – Ch 1 and Ch 2 (black w/white line, 15 mm)</b> (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
<b>Potentiometer – Ch 1 and Ch 2</b> (Order Code: 2148)	_____	\$ 4.00	_____
<b>Toggle Switch – Ch 1/2 Select</b> (Order Code: 12063)	_____	\$ 9.00	_____
<b>3-Pin Male XLR Connector</b> (Order Code: 1093)	_____	\$ 7.00	_____
<b>3-Pin Female XLR Connector</b> (Order Code: 1094)	_____	\$ 8.00	_____
<b>1/4" Phone Jack</b> (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
<b>Nut (plastic)</b> (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
<b>Belt Clip (black, steel)</b> (Order Code: 30247)	_____	\$ 5.00	_____
<b>Pop-Rivet – for Belt Clip (black, aluminum, 0.125" grip)</b> (Order Code: 8201-.125)	_____	\$ 1.00	_____

	Qty	US List	Total
<b>Model 33A Talent Amplifier (all Serial Numbers)</b>			
<b>Knob – Ch 1 and Ch 2 (black, push-on, 15 mm)</b> (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
<b>Knob Cap – Ch 1 and Ch 2 (black w/white line, 15 mm)</b> (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
<b>Potentiometer – Ch 1 and Ch 2</b> (Order Code: 2148)	_____	\$ 4.00	_____
<b>Toggle Switch – Ch 1/2 Select</b> (Order Code: 12063)	_____	\$ 9.00	_____
<b>3-Pin Male XLR Connector</b> (Order Code: 1093)	_____	\$ 7.00	_____
<b>3-Pin Female XLR Connector</b> (Order Code: 1094)	_____	\$ 8.00	_____
<b>1/4" Phone Jack</b> (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
<b>Nut (plastic)</b> (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
<b>3.5 mm Stereo Jack</b> (Order Code: 1198)	_____	\$ 3.00	_____
<b>Belt Clip (black, steel)</b> (Order Code: 30247)	_____	\$ 5.00	_____
<b>Pop-Rivet – for Belt Clip (black, aluminum, 0.125" grip)</b> (Order Code: 8201-.125)	_____	\$ 1.00	_____
<b>Model 34 Talent Amplifier (all Serial Numbers)</b>			
<b>Knob – Ch 1/Left and Ch 2/Right (black, push-on, 15 mm)</b> (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
<b>Knob Cap – Ch 1/Left and Ch 2/Right (black w/white line, 15 mm)</b> (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
<b>Potentiometer – Ch 1/Left and Ch 2/Right</b> (Order Code: 2148)	_____	\$ 4.00	_____
<b>Toggle Switch – Output Mic/Stereo Select</b> (Order Code: 12021)	_____	\$ 6.00	_____
<b>3-Pin Female XLR Connector</b> (Order Code: 1094)	_____	\$ 8.00	_____
<b>1/4" Phone Jack</b> (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
<b>Nut (plastic)</b> (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
<b>3.5 mm Stereo Jack</b> (Order Code: 1198)	_____	\$ 3.00	_____
<b>Belt Clip (black, steel)</b> (Order Code: 30247)	_____	\$ 5.00	_____
<b>Pop-Rivet – for Belt Clip (black, aluminum, 0.125" grip)</b> (Order Code: 8201-.125)	_____	\$ 1.00	_____
<b>Model 35 Talent Amplifier (Serial Numbers 00001 – 00385)</b>			
<b>Knob (black, push-on, 15 mm)</b> (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
<b>Knob Cap (black w/white line, 15 mm)</b> (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
<b>Potentiometer</b> (Order Code: 2124)	_____	\$ 5.00	_____
<b>Pushbutton Switch (push-push) – Stereo/Mono</b> (Order Code: 12016)	_____	\$ 3.00	_____
<b>Pushbutton Cap (gray)</b> (Order Code: 12015)	_____	\$ 3.00	_____
<b>3-Pin Male XLR Connector</b> (Order Code: 1093)	_____	\$ 7.00	_____
<b>3-Pin Female XLR Connector</b> (Order Code: 1094)	_____	\$ 8.00	_____
<b>Dual 1/4" Phone Jack</b> (Order Code: 1087)	_____	\$ 6.00	_____
<b>Self-Adhesive Rubber Bumpons (black, set of 4, 1/2" dia. by 0.138" tall)</b> (Order Code: 14028)	_____	\$ 2.00	_____
<b>Model 35 Talent Amplifier (Serial Numbers 00386 – later)</b>			
<b>Knob (black, push-on, 15 mm)</b> (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
<b>Knob Cap (black w/white line, 15 mm)</b> (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
<b>Potentiometer</b> (Order Code: 2124)	_____	\$ 5.00	_____
<b>Pushbutton Switch (push-push) – Stereo/Mono</b> (Order Code: 12016)	_____	\$ 3.00	_____
<b>Pushbutton Cap (gray)</b> (Order Code: 12015)	_____	\$ 3.00	_____
<b>3-Pin Male XLR Connector</b> (Order Code: 1093)	_____	\$ 7.00	_____
<b>3-Pin Female XLR Connector</b> (Order Code: 1094)	_____	\$ 8.00	_____
<b>Dual 1/4" Phone Jack</b> (Order Code: 1113)	_____	\$ 7.00	_____
<b>Self-Adhesive Rubber Bumpons (black, set of 4, 1/2" dia. by 0.138" tall)</b> (Order Code: 14028)	_____	\$ 2.00	_____

	Qty	US List	Total
<b>Model 36 Talent Interface (all Serial Numbers)</b>			
<b>Knob (black, push-on, 15 mm)</b> (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
<b>Knob Cap (black w/white line, 15 mm)</b> (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
<b>Potentiometer</b> (Order Code: 2148)	_____	\$ 4.00	_____
<b>1/4" Phone Jack</b> (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
<b>Nut (plastic)</b> (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
<b>3.5 mm Stereo Jack</b> (Order Code: 1198)	_____	\$ 3.00	_____
<b>5-Pin Headset Connector Assembly</b> (Order Code: 13579)	_____	\$56.00	_____
<b>6-Pin Headset Connector Assembly</b> (Order Code: 13595)	_____	\$56.00	_____
<b>7-Pin Headset Connector Assembly</b> (Order Code: 13561)	_____	\$56.00	_____
<b>Belt Clip (black, steel)</b> (Order Code: 30247)	_____	\$ 5.00	_____
<b>Pop-Rivet – for Belt Clip (black, aluminum, 0.125" grip)</b> (Order Code: 8201-.125)	_____	\$ 1.00	_____
<b>Model 37 Intercom Beltpack (all Serial Numbers)</b>			
<b>Knob – Main and Aux (black, push-on, 15 mm)</b> (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
<b>Knob Cap – Main and Aux (black w/white line, 15 mm)</b> (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
<b>Potentiometer – Main and Aux</b> (Order Code: 2148)	_____	\$ 4.00	_____
<b>Toggle Switch – Mic On Select (on/off/mom)</b> (Order Code: 12088)	_____	\$ 6.00	_____
<b>Power Entry &amp; Aux Audio Input Kit</b> (Order Code: M37-MK-01)	_____	\$84.00	_____
<b>Belt Clip (black, steel)</b> (Order Code: 30247)	_____	\$ 5.00	_____
<b>Pop-Rivet – for Belt Clip (black, aluminum, 0.125" grip)</b> (Order Code: 8201-.125)	_____	\$ 1.00	_____
<b>Model 41 Interface (Serial Numbers 00151 – 01050)</b>			
<b>Knob (black, push-on, 15 mm)</b> (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
<b>Knob Cap (black, w/white line, 15 mm)</b> (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
<b>Potentiometer</b> (Order Code: 2166)	_____	\$ 4.00	_____
<b>1/4" Phone Jack</b> (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
<b>Nut (plastic)</b> (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
<b>Pushbutton Cap (gray)</b> (Order Code: 14229)	_____	\$ 1.50	_____
<b>Model 41 Interface (Serial Numbers 01051 – later)</b>			
<b>Knob (black, push-on, 15 mm)</b> (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
<b>Knob Cap (black w/white line, 15 mm)</b> (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
<b>Potentiometer</b> (Order Code: 2166)	_____	\$ 4.00	_____
<b>1/4" Phone Jack</b> (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
<b>Nut (plastic)</b> (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
<b>Pushbutton Cap (gray)</b> (Order Code: 14229)	_____	\$ 1.50	_____

	Qty	US List	Total
<b>Model 42A Interface (all Serial Numbers)</b>			
Knob (black, push-on, 15 mm) (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
Knob Cap (black w/white line, 15 mm) (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
Potentiometer (Order Code: 2166)	_____	\$ 4.00	_____
1/4" Phone Jack (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
Nut (plastic) (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
Pushbutton Cap (gray) (Order Code: 14229)	_____	\$ 1.50	_____
<b>Model 43D IFB Interface (all Serial Numbers)</b>			
4-Position DIP Switch (Order Code: 12071)	_____	\$ 5.00	_____
Screw-On Bumper Kit (black, set of 8) (Order Code: 31064)	_____	\$10.00	_____
<b>Model 44D Audio Interface (all Serial Numbers)</b>			
4-Position DIP Switch (Order Code: 12071)	_____	\$ 5.00	_____
Screw-On Bumper Kit (black, set of 8) (Order Code: 31064)	_____	\$10.00	_____
<b>Model 45 Interface (all Serial Numbers)</b>			
5-Position DIP Switch (Order Code: 12069)	_____	\$ 6.00	_____
Pushbutton Switch (momentary) – Auto Null (Order Code: 12056)	_____	\$ 4.00	_____
Pushbutton Cap (gray) (Order Code: 14207)	_____	\$ 3.00	_____
Screw-On Bumper Kit (black, set of 8) (Order Code: 31064)	_____	\$10.00	_____
24 Vdc, 0.75 A Power Supply (output terminated onto 2.1 x 5.5 mm locking coaxial jack) (Order Code: PS-DC-03)	_____	\$46.00	_____
<b>Model 45A Interface (all Serial Numbers)</b>			
5-Position DIP Switch (Order Code: 12069)	_____	\$ 6.00	_____
Pushbutton Switch (momentary) – Auto Null (Order Code: 12056)	_____	\$ 4.00	_____
Pushbutton Cap (gray) (Order Code: 14207)	_____	\$ 3.00	_____
Screw-On Bumper Kit (black, set of 8) (Order Code: 31064)	_____	\$10.00	_____
24 Vdc, 0.75 A Power Supply (output terminated onto 2.1 x 5.5 mm locking coaxial jack) (Order Code: PS-DC-03)	_____	\$46.00	_____
<b>Model 45DC Intercom Interface (all Serial Numbers)</b>			
4-Position DIP Switch (Order Code: 12071)	_____	\$ 5.00	_____
Pushbutton Switch (momentary) – Auto Null (Order Code: 12056)	_____	\$ 4.00	_____
Pushbutton Cap (gray) (Order Code: 14207)	_____	\$ 3.00	_____
Screw-On Bumper Kit (black, set of 8) (Order Code: 31064)	_____	\$10.00	_____
<b>Model 45DR Intercom Interface (all Serial Numbers)</b>			
4-Position DIP Switch (Order Code: 12071)	_____	\$ 5.00	_____
Pushbutton Switch (momentary) – Auto Null (Order Code: 12056)	_____	\$ 4.00	_____
Pushbutton Cap (gray) (Order Code: 14207)	_____	\$ 3.00	_____
Screw-On Bumper Kit (black, set of 8) (Order Code: 31064)	_____	\$10.00	_____
<b>Model 46 Interface (all Serial Numbers)</b>			
4-Position DIP Switch (Order Code: 12071)	_____	\$ 5.00	_____
Pushbutton Switch (momentary) – Auto Null (Order Code: 12056)	_____	\$ 4.00	_____
Pushbutton Cap (gray) (Order Code: 14207)	_____	\$ 3.00	_____
<b>Model 46A Interface (all Serial Numbers)</b>			
4-Position DIP Switch (Order Code: 12071)	_____	\$ 5.00	_____
Pushbutton Switch (momentary) – Auto Null (Order Code: 12056)	_____	\$ 4.00	_____
Pushbutton Cap (gray) (Order Code: 14207)	_____	\$ 3.00	_____

	Qty	US List	Total
<b>Model 47 Interface (all Serial Numbers)</b>			
4-Position DIP Switch (Order Code: 12071)	_____	\$ 5.00	_____
Pushbutton Switch (momentary) – Auto Null (Order Code: 12056)	_____	\$ 4.00	_____
Pushbutton Cap (gray) (Order Code: 14207)	_____	\$ 3.00	_____
<b>Model 47A Interface (all Serial Numbers)</b>			
4-Position DIP Switch (Order Code: 12071)	_____	\$ 5.00	_____
Pushbutton Switch (momentary) – Auto Null (Order Code: 12056)	_____	\$ 4.00	_____
Pushbutton Cap (gray) (Order Code: 14207)	_____	\$ 3.00	_____
<b>Model 48D Dante Bridge (all Serial Numbers)</b>			
Screw-On Bumper Kit (black, set of 8) (Order Code: 31064)	_____	\$10.00	_____
<b>Model 51 Control Console (all Serial Numbers)</b>			
Pushbutton Switch (momentary) (Order Code: 12055) Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND	_____	\$ 4.00	_____
Knob – Studio Level (black, push-on, 15 mm) (Order Code: 2056) Note: Knob and knob cap are sold separately. See 2057 for knob cap.	_____	\$ 3.00	_____
Knob Cap – Studio Level (black w/white line, 15 mm) (Order Code: 2057) Note: Knob and knob cap are sold separately. See 2056 for knob.	_____	\$ 1.50	_____
Potentiometer – Studio Level (Order Code: 2054)	_____	\$12.00	_____
Knob – Control Room Level (black, collet, 47 mm) (Order Code: 14205) Note: Knob and knob cap are sold separately. See 14206 for knob cap.	_____	\$18.00	_____
Knob Cap – Control Room Level (black w/white line, 47 mm) (Order Code: 14206) Note: Knob and knob cap are sold separately. See 14205 for knob.	_____	\$ 4.00	_____
Potentiometer – Control Room Level (Order Code: 2122)	_____	\$12.00	_____
Self-Adhesive Rubber Bumpons (black, set of 4, 1/2" dia. by 0.138" tall) (Order Code: 14028)	_____	\$ 2.00	_____
<b>Model 56 Control Console (all Serial Numbers)</b>			
Pushbutton Switch (momentary) (Order Code: 12055) Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND	_____	\$ 4.00	_____
Knob – Control Room Level (black, collet, 38 mm) (Order Code: 14209) Note: Knob and knob cap are sold separately. See 14210 for knob cap.	_____	\$14.00	_____
Knob Cap – Control Room Level (black w/white line, 38 mm) (Order Code: 14210) Note: Knob and knob cap are sold separately. See 14209 for knob.	_____	\$ 3.00	_____
Potentiometer – Control Room Level (Order Code: 2123)	_____	\$ 5.00	_____
Self-Adhesive Rubber Bumpons (black, set of 4, 1/2" dia. by 0.138" tall) (Order Code: 14028)	_____	\$ 2.00	_____
<b>Model 59 and Model 591 Control Consoles (all Serial Numbers)</b>			
Pushbutton Switch (momentary) (Order Code: 12055) Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND	_____	\$ 4.00	_____
Knob – Control Room Level (black, collet, 38 mm) (Order Code: 14209) Note: Knob and knob cap are sold separately. See 14210 for knob cap.	_____	\$14.00	_____
Knob Cap – Control Room Level (black w/white line, 38 mm) (Order Code: 14210) Note: Knob and knob cap are sold separately. See 14209 for knob.	_____	\$ 3.00	_____
Potentiometer – Control Room Level (Order Code: 2123)	_____	\$ 5.00	_____
Self-Adhesive Rubber Bumpons (black, set of 4, 1/2" dia. by 0.138" tall) (Order Code: 14028)	_____	\$ 2.00	_____



	Qty	US List	Total
<b>Model 60 Central Controller (Serial Numbers 00200 – 00300)</b>			
1/4" Phone Jack (Order Code: 1086)	_____	\$ 4.00	_____
Dual 1/4" Phone Jack (Order Code: 1087)	_____	\$ 6.00	_____
Knob – Level (black, push-on, 15 mm) (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
Knob Cap – Level (black w/white line, 15 mm) (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
Potentiometer – Phones Level and Dub Level (Order Code: 2128)	_____	\$ 8.00	_____
Pushbutton Switch (push-push) (Order Code: 12016)	_____	\$ 3.00	_____
Pushbutton Switch Assembly (4-station) – Source (Order Code: 12061)	_____	\$16.00	_____
Pushbutton Cap (gray) (Order Code: 12050) <i>Mfg. No.: E-Switch TACGRY; Digi-Key No.: EG1082-ND</i>	_____	\$ 4.00	_____
<b>Model 60 Central Controller (Serial Numbers 00301 – later)</b>			
1/4" Phone Jack (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
Nut (plastic) (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
Dual 1/4" Phone Jack (Order Code: 1113)	_____	\$ 7.00	_____
Knob – Level (black, push-on, 15 mm) (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
Knob Cap – Level (black w/white line, 15 mm) (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
Potentiometer – Phones Level and Dub Level (Order Code: 2128)	_____	\$ 8.00	_____
Pushbutton Switch (push-push) (Order Code: 12016)	_____	\$ 3.00	_____
Pushbutton Switch Assembly (4-station) – Source (Order Code: 12061)	_____	\$16.00	_____
Pushbutton Cap (gray) (Order Code: 12050) <i>Mfg. No.: E-Switch TACGRY; Digi-Key No.: EG1082-ND</i>	_____	\$ 4.00	_____
<b>Model 60A Central Controller (all Serial Numbers)</b>			
1/4" Phone Jack (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
Nut (plastic) (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
Dual 1/4" Phone Jack (Order Code: 1168)	_____	\$ 7.00	_____
Knob – Level (black, push-on, 15 mm) (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
Knob Cap – Level (black w/white line, 15 mm) (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
Potentiometer – Phones Level and Dub Level (Order Code: 2128)	_____	\$ 8.00	_____
Pushbutton Switch (push-push) (Order Code: 12016)	_____	\$ 3.00	_____
Pushbutton Switch Assembly (4-station) – Source (Order Code: 12061)	_____	\$16.00	_____
Pushbutton Switch Assembly (3-station) – Switcher (Order Code: 12074)	_____	\$12.00	_____
Pushbutton Cap (gray) (Order Code: 12050) <i>Mfg. No.: E-Switch TACGRY; Digi-Key No.: EG1082-ND</i>	_____	\$ 4.00	_____
<b>Model 61 Control Console (all Serial Numbers)</b>			
Pushbutton Switch (momentary) (Order Code: 12055) <i>Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND</i>	_____	\$ 4.00	_____
Knob – Level (black, collet, 29 mm) (Order Code: 14214) <i>Note: Knob and knob cap are sold separately. See 14215 for knob cap.</i>	_____	\$ 7.00	_____
Knob Cap – Level (black w/white line, 29 mm) (Order Code: 14215) <i>Note: Knob and knob cap are sold separately. See 14209 for knob.</i>	_____	\$ 3.00	_____
Potentiometer – Level (Order Code: 2123)	_____	\$ 5.00	_____
Self-Adhesive Rubber Bumpons (black, set of 4, 1/2" dia. by 0.138" tall) (Order Code: 14028)	_____	\$ 2.00	_____
9-Pin Male D-Sub/9-Pin Male D-Sub Cable Assembly (overall length 25 feet/7.7 m) (Order Code: 13179-20)	_____	\$26.00	_____

	Qty	US List	Total
<b>Model 69 Control Console (all Serial Numbers)</b>			
<b>Pushbutton Switch (momentary)</b> (Order Code: 12055) <i>Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND</i>	_____	\$ 4.00	_____
<b>Knob – Level (black, collet, 38 mm)</b> (Order Code: 14209) <i>Note: Knob and knob cap are sold separately. See 14210 for knob cap.</i>	_____	\$14.00	_____
<b>Knob Cap – Level (black w/white line, 38 mm)</b> (Order Code: 14210) <i>Note: Knob and knob cap are sold separately. See 14209 for knob.</i>	_____	\$ 3.00	_____
<b>Potentiometer – Level</b> (Order Code: 2123)	_____	\$ 5.00	_____
<b>Self-Adhesive Rubber Bumpers (black, set of 4, 1/2" dia. by 0.138" tall)</b> (Order Code: 14028)	_____	\$ 2.00	_____
<b>9-Pin Male D-Sub/9-Pin Male D-Sub Cable Assembly (overall length 25 feet/7.7 m)</b> (Order Code: 13179-20)	_____	\$26.00	_____
<b>Model 69A Control Console (all Serial Numbers)</b>			
<b>Pushbutton Switch (momentary)</b> (Order Code: 12055) <i>Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND</i>	_____	\$ 4.00	_____
<b>Knob – Level (black, collet, 38 mm)</b> (Order Code: 14209) <i>Note: Knob and knob cap are sold separately. See 14210 for knob cap.</i>	_____	\$14.00	_____
<b>Knob Cap – Level (black w/white line, 38 mm)</b> (Order Code: 14210) <i>Note: Knob and knob cap are sold separately. See 14209 for knob.</i>	_____	\$ 3.00	_____
<b>Potentiometer – Level</b> (Order Code: 2123)	_____	\$ 5.00	_____
<b>Self-Adhesive Rubber Bumpers (black, set of 4, 1/2" dia. by 0.138" tall)</b> (Order Code: 14028)	_____	\$ 2.00	_____
<b>9-Pin Male D-Sub/9-Pin Male D-Sub Cable Assembly (overall length 25 feet/7.7 m)</b> (Order Code: 13179-20)	_____	\$26.00	_____
<b>Model 71 Control Console (all Serial Numbers)</b>			
<b>Pushbutton Switch (momentary)</b> (Order Code: 12055) <i>Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND</i>	_____	\$ 4.00	_____
<b>Knob – Level (black, collet, 29 mm)</b> (Order Code: 14214) <i>Note: Knob and knob cap are sold separately. See 14260 for knob cap.</i>	_____	\$ 7.00	_____
<b>Knob Cap – Level (black, 29 mm)</b> (Order Code: 14260) <i>Note: Knob and knob cap are sold separately. See 14214 for knob.</i>	_____	\$ 2.00	_____
<b>Rotary Encoder – Level</b> (Order Code: 12034)	_____	\$ 4.00	_____
<b>Self-Adhesive Rubber Bumpers (black, set of 4, 1/2" dia. by 0.138" tall)</b> (Order Code: 14028)	_____	\$ 2.00	_____
<b>9-Pin Male D-Sub/9-Pin Male D-Sub Cable Assembly (overall length 25 feet/7.7 m)</b> (Order Code: 13179-20)	_____	\$26.00	_____
<b>Model 72 Level Meter / Interface (all Serial Numbers)</b>			
<b>Self-Adhesive Rubber Bumpers (black, set of 4, 1/2" dia. by 0.138" tall)</b> (Order Code: 14028)	_____	\$ 2.00	_____
<b>Model 74 Central Controller (all Serial Numbers)</b>			
<b>3.5 mm Jack</b> (Order Code: 1315)	_____	\$ 4.00	_____
<b>Model 75 Control Console (all Serial Numbers)</b>			
<b>Pushbutton Switch (momentary)</b> (Order Code: 12055) <i>Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND</i>	_____	\$ 4.00	_____
<b>Knob – Level (black, collet, 38 mm)</b> (Order Code: 14209) <i>Note: Knob and knob cap are sold separately. See 14210 for knob cap.</i>	_____	\$14.00	_____
<b>Knob Cap – Level (black w/white line, 38 mm)</b> (Order Code: 14210) <i>Note: Knob and knob cap are sold separately. See 14209 for knob.</i>	_____	\$ 3.00	_____
<b>Potentiometer Assembly – Level</b> (Order Code: 32089)	_____	\$12.00	_____
<b>Self-Adhesive Rubber Bumpers (black, set of 4, 1/2" dia. by 0.138" tall)</b> (Order Code: 14028)	_____	\$ 2.00	_____
<b>9-Pin Male D-Sub/9-Pin Male D-Sub Cable Assembly (overall length 25 feet/7.7 m)</b> (Order Code: 13179-20)	_____	\$26.00	_____

	Qty	US List	Total
<b>Model 76 Central Controller (all serial numbers)</b>			
<b>Capacitor (surface mount, aluminum electrolytic, 47 uF, 25 V) (Order Code: 4975)</b>		\$ 2.00	
<i>Mfg. No.: Panasonic FK-Series, EEE-FK1E470P; Digi-Key No.: PCE3804, Mouser No. 667-EEE-FK1E470P</i>			
<i>Alternate, Mfg. No.: Nichicon UUD-Series, UUD1E470MCL1GS; Digi-Key No. 493-2273-2, Mouser No. 647-UUD1E470MCL</i>			
<i>Notes: For revision B circuit boards: C36, C73, C178, C193 (C193 is bypass for -15 volt DC rail and is most critical)</i>			
<i>For revision C circuit boards: C39, C76, C181, C196 (C196 is bypass for -15 volt DC rail and is most critical)</i>			
<hr/>			
<b>Model 76B Central Controller (all serial numbers)</b>			
<b>Capacitor (surface mount, aluminum electrolytic, 47 uF, 25 V) (Order Code: 4975)</b>		\$ 2.00	
<i>Mfg. No.: Panasonic FK-Series, EEE-FK1E470P; Digi-Key No.: PCE3804, Mouser No. 667-EEE-FK1E470P</i>			
<i>Alternate, Mfg. No.: Nichicon UUD-Series, UUD1E470MCL1GS; Digi-Key No. 493-2273-2, Mouser No. 647-UUD1E470MCL</i>			
<i>Notes: For revision B circuit boards: C36, C73, C178, C193 (C193 is bypass for -15 volt DC rail and is most critical)</i>			
<i>For revision C circuit boards: C39, C76, C181, C196 (C196 is bypass for -15 volt DC rail and is most critical)</i>			
<hr/>			
<b>Model 76D Central Controller (all serial numbers)</b>			
<b>Power Supply Assembly (universal AC mains input/12 V, 1.25 A (15 watts) output)</b>			
<i>(Order Code: 32226)</i>			
<i>Note: Replaces discontinued Pihong PSA15LN3-120-R power supply.</i>			
<hr/>			
<b>Model 76DA Central Controller (all serial numbers)</b>			
<b>Power Supply Assembly (universal AC mains input/12 V, 1.25 A (15 watts) output)</b>			
<i>(Order Code: 32226)</i>			
<i>Note: Replaces discontinued Pihong PSA15LN3-120-R power supply.</i>			
<hr/>			
<b>Model 77 Control Console (all Serial Numbers)</b>			
<b>Pushbutton Switch (momentary) (Order Code: 12055)</b>		\$ 4.00	
<i>Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND</i>			
<b>Knob – Level (black, collet, 29 mm) (Order Code: 14214)</b>		\$ 7.00	
<i>Note: Knob and knob cap are sold separately. See 14260 for knob cap.</i>			
<b>Knob Cap – Level (black, 29 mm) (Order Code: 14260)</b>		\$ 2.00	
<i>Note: Knob and knob cap are sold separately. See 14214 for knob.</i>			
<b>Rotary Encoder Assembly – Level (Order Code: 31378)</b>		\$ 9.00	
<b>Self-Adhesive Rubber Bumpons (black, set of 4, 1/2" dia. by 0.138" tall) (Order Code: 14028)</b>		\$ 2.00	
<b>9-Pin Male D-Sub/9-Pin Male D-Sub Cable Assembly (overall length 25 feet/7.7 m)</b>			
<i>(Order Code: 13179-20)</i>			
<hr/>			
<b>Model 77B Control Console (all Serial Numbers)</b>			
<b>Pushbutton Switch (momentary) (Order Code: 12055)</b>		\$ 4.00	
<i>Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND</i>			
<b>Knob – Level (black, collet, 29 mm) (Order Code: 14214)</b>		\$ 7.00	
<i>Note: Knob and knob cap are sold separately. See 14260 for knob cap.</i>			
<b>Knob Cap – Level (black, 29 mm) (Order Code: 14260)</b>		\$ 2.00	
<i>Note: Knob and knob cap are sold separately. See 14214 for knob.</i>			
<b>Rotary Encoder Assembly – Level (Order Code: 31378)</b>		\$ 9.00	
<b>Self-Adhesive Rubber Bumpons (black, set of 4, 1/2" dia. by 0.138" tall) (Order Code: 14028)</b>		\$ 2.00	
<b>9-Pin Male D-Sub/9-Pin Male D-Sub Cable Assembly (overall length 25 feet/7.7 m)</b>			
<i>(Order Code: 13179-20)</i>			
<hr/>			
<b>Model 79 Control Console (all Serial Numbers)</b>			
<b>Pushbutton Switch (momentary) (Order Code: 12055)</b>		\$ 4.00	
<i>Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND</i>			
<b>Knob – Level (black, collet, 29 mm) (Order Code: 14214)</b>		\$14.00	
<i>Note: Knob and knob cap are sold separately. See 14215 for knob cap.</i>			
<b>Knob Cap – Level (black w/white line, 29 mm) (Order Code: 14215)</b>		\$ 3.00	
<i>Note: Knob and knob cap are sold separately. See 14209 for knob.</i>			
<b>Potentiometer – Level (Order Code: 2123)</b>		\$ 5.00	
<b>Self-Adhesive Rubber Bumpons (black, set of 4, 1/2" dia. by 0.138" tall) (Order Code: 14028)</b>		\$ 2.00	
<b>9-Pin Male D-Sub/9-Pin Male D-Sub Cable Assembly (overall length 25 feet/7.7 m)</b>			
<i>(Order Code: 13179-20)</i>			

	Qty	US List	Total
<b>Model 92 DT12 Cable Assembly Test Unit (all Serial Numbers)</b>			
Rechargeable Battery, 12 V, 1.3 Ah (Order Code: 10335) Mfg. No.: Panasonic LC-R121R3P; Digi-Key No.: P264-ND			Not available from factory
<b>Model 93 W1 Cable Assembly Test Unit (all Serial Numbers)</b>			
Rechargeable Battery, 12 V, 1.3 Ah (Order Code: 10335) Mfg. No.: Panasonic LC-R121R3P; Digi-Key No.: P264-ND			Not available from factory
<b>Model 201 Interpreter's Console (all Serial Numbers)</b>			
Knob (black w/white line, 9 mm) (Order Code: 14287) Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.	_____	\$ 3.00	_____
Set Screw (Order Code: 8210-1/8) Note: Set screw and knob are sold separately. See 14287 for knob.	_____	\$ 0.50	_____
Push-Pot Potentiometer Assembly (dual-section) (Order Code: 32298) Note: Includes push-pot (2171) and sleeve (14297).	_____	\$ 9.00	_____
Pushbutton Switch (momentary, 17 mm x 17 mm) (Order Code: 12106) Note: Includes button cap and lens. See 32649 for replacement button cap and lens kit.	_____	\$ 6.00	_____
Button Cap and Lens Kit (includes four each button cap and frosted lens) (Order Code: 32649)	_____	\$24.00	_____
1/4" Phone Jack (Order Code: 1084) Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.	_____	\$ 4.00	_____
Nut (plastic) (Order Code: 1090) Note: Nut is required for installation of 1/4" phone jack.	_____	\$ 1.50	_____
3.5 mm Stereo Jack (Order Code: 1198)	_____	\$ 3.00	_____
Self-Adhesive Rubber Bumpons (black, set of 4, 1/2" dia. by 0.138" tall) (Order Code: 14028)	_____	\$ 2.00	_____
<b>Model 203, Model 204, Model 205, and Model 206 Announcer's Consoles (all Serial Numbers)</b>			
Knob (black w/white line, 9 mm) (Order Code: 14287) Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.	_____	\$ 3.00	_____
Set Screw (Order Code: 8210-1/8) Note: Set screw and knob are sold separately. See 14287 for knob.	_____	\$ 0.50	_____
Push-Pot Potentiometer Assembly (dual-section) (Order Code: 32298) Note: Includes push-pot (2171) and sleeve (14297).	_____	\$ 9.00	_____
Pushbutton Switch (momentary, 17 mm x 17 mm) (Order Code: 12106) Note: Includes button cap and lens. See 32649 for replacement button cap and lens kit.	_____	\$ 6.00	_____
Button Cap and Lens Kit (includes four each button cap and frosted lens) (Order Code: 32649)	_____	\$24.00	_____
1/4" Phone Jack (Order Code: 1084) Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.	_____	\$ 4.00	_____
Nut (plastic) (Order Code: 1090) Note: Nut is required for installation of 1/4" phone jack.	_____	\$ 1.50	_____
3.5 mm Stereo Jack (Order Code: 1198)	_____	\$ 3.00	_____
Self-Adhesive Rubber Bumpons (black, set of 4, 1/2" dia. by 0.138" tall) (Order Code: 14028)	_____	\$ 2.00	_____
<b>Model 207 eSports Console (all Serial Numbers)</b>			
Knob (black w/white line, 9 mm) (Order Code: 14287) Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.	_____	\$ 3.00	_____
Set Screw (Order Code: 8210-1/8) Note: Set screw and knob are sold separately. See 14287 for knob.	_____	\$ 0.50	_____
Push-Pot Potentiometer Assembly (dual-section) (Order Code: 32298) Note: Includes push-pot (2171) and sleeve (14297).	_____	\$ 9.00	_____
Pushbutton Switch (momentary, 17 mm x 17 mm) (Order Code: 12106) Note: Includes button cap and lens. See 32649 for replacement button cap and lens kit.	_____	\$ 6.00	_____
Button Cap and Lens Kit (includes four each button cap and frosted lens) (Order Code: 32649)	_____	\$24.00	_____
3.5 mm 4-Conductor (TRRS) Jack (Order Code: 1410)	_____	\$ 5.00	_____
Self-Adhesive Rubber Bumpons (black, set of 4, 1/2" dia. by 1/4" tall) (Order Code: 14326)	_____	\$ 3.00	_____

	Qty	US List	Total
<b>Model 207A eSports Console (all Serial Numbers)</b>			
<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
<b>Push-Pot Potentiometer Assembly (dual-section)</b> (Order Code: 32298) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
<b>Pushbutton Switch (momentary, 17 mm x 17 mm)</b> (Order Code: 12106) <i>Note: Includes button cap and lens. See 32649 for replacement button cap and lens kit.</i>	_____	\$ 6.00	_____
<b>Button Cap and Lens Kit (includes four each button cap and frosted lens)</b> (Order Code: 32649)	_____	\$24.00	_____
<b>3.5 mm 4-Conductor (TRRS) Jack</b> (Order Code: 1410)	_____	\$ 5.00	_____
<b>Self-Adhesive Rubber Bumpers (black, set of 4, 1/2" dia. by 1/4" tall)</b> (Order Code: 14326)	_____	\$ 3.00	_____
<b>Model 208 Announcer's Console (all Serial Numbers)</b>			
<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
<b>Push-Pot Potentiometer Assembly (dual-section)</b> (Order Code: 32298) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
<b>Switch Cap Adapter</b> (Order Code: 14294) <i>Note: Switch cap and switch cap adapter are sold separately. See 14295 for 12 mm switch cap.</i>	_____	\$ 1.50	_____
<b>Switch Cap (12 mm)</b> (Order Code: 14295) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____
<b>1/4" Phone Jack</b> (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
<b>Nut (plastic)</b> (Order Code: 1090) <i>Note: For use with 1/4" phone jack.</i>	_____	\$ 1.50	_____
<b>3.5 mm Stereo Jack</b> (Order Code: 1198)	_____	\$ 3.00	_____
<b>Model 209 Talent Console (all Serial Numbers)</b>			
<b>Knob – Glow (black w/clear center, 13 mm dia. x 13.8 mm tall)</b> (Order Code: 14340)	_____	\$ 5.00	_____
<b>Rotary Encoder (24-step w/switch, 21 mm overall length)</b> (Order Code: 12109)	_____	\$ 8.00	_____
<b>Pushbutton Switch (momentary, 17 mm x 17 mm)</b> (Order Code: 12106) <i>Note: Includes button cap and lens. See 32649 for replacement button cap and lens kit.</i>	_____	\$ 6.00	_____
<b>Button Cap and Lens Kit (includes four each button cap and frosted lens)</b> (Order Code: 32649)	_____	\$24.00	_____
<b>1/4" Phone Jack</b> (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
<b>Nut (plastic)</b> (Order Code: 1090) <i>Note: For use with 1/4" phone jack.</i>	_____	\$ 1.50	_____
<b>3.5 mm Stereo Jack</b> (Order Code: 1198)	_____	\$ 3.00	_____

	Qty	US List	Total
<b>Model 210, Model 211, Model 212, Model 220, Model 230, and Model 233</b>			
<b>Announcer's Consoles (all Serial Numbers)</b>			
Pushbutton Switch (momentary, Mfg. by EAO) (Order Code: 12028) <i>Note: Does not include button cap, lens, or label. See 31069.</i>	_____	\$14.00	_____
Button Cap, Lenses, and Label Kit (includes five each button cap, clear lens, frosted lens, and one button function label sheet (15154)) (Order Code: 31069)	_____	\$40.00	_____
Knob – Phones Level (black, push-on, 15 mm) (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
Knob Cap – Phones Level (black w/white line, 15 mm) (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
Potentiometer – Phones Level (Order Code: 2127)	_____	\$ 5.00	_____
1/4" Phone Jack (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
Nut (plastic) (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
DC Power Entry Jack Assembly (includes PCB, washer, and nut) (Order Code: 32135) <i>Note: Requires cable assembly, sold separately. See 13690.</i>	_____	\$12.00	_____
Cable Assembly for DC Power Entry Jack Assembly (2-conductor, 5") (Order Code: 13690)	_____	\$ 4.00	_____
Blank Plate – XLR (black) (Order Code: 1073)	_____	\$ 3.00	_____
Model 210 Security Plate (Order Code: SP-M210)	_____	\$15.00	_____
Model 211 Security Plate (Order Code: SP-M211)	_____	\$15.00	_____
Model 212 Security Plate (Order Code: SP-M212)	_____	\$15.00	_____
Model 220 Security Plate (Order Code: SP-M220)	_____	\$18.00	_____
Model 230 Security Plate (Order Code: SP-M230)	_____	\$18.00	_____
Model 233 Security Plate (Order Code: SP-M233)	_____	\$18.00	_____
Screw-On Bumper Kit (black, set of 8) (Order Code: 31064)	_____	\$10.00	_____
24 Vdc, 0.75 A Power Supply (output terminated onto 2.1 x 5.5 mm locking coaxial jack) (Order Code: PS-DC-03)	_____	\$46.00	_____
<hr/>			
<b>Model 214, Model 215, and Model 216 Announcer's Consoles (all Serial Numbers)</b>			
Pushbutton Switch Backlight LED (Order Code: 3154)	_____	\$ 3.00	_____
Pushbutton Switch (momentary, Mfg. by EAO) (Order Code: 12028) <i>Note: Does not include button cap, lens, or label. See 31069.</i>	_____	\$14.00	_____
Button Cap, Lenses, and Label Kit (includes five each button cap, clear lens, frosted lens, and one button function label sheet (15154)) (Order Code: 31069)	_____	\$40.00	_____
Knob – Phones Level (black, push-on, 15 mm) (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>	_____	\$ 3.00	_____
Knob Cap – Phones Level (black w/white line, 15 mm) (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>	_____	\$ 1.50	_____
Potentiometer – Phones Level (Order Code: 2127)	_____	\$ 5.00	_____
1/4" Phone Jack (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
Nut (plastic) (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
Screw-On Bumper Kit (black, set of 8) (Order Code: 31064)	_____	\$10.00	_____
Blank Plate – XLR (black) (Order Code: 1073)	_____	\$ 3.00	_____
Model 214 Security Plate (Order Code: SP-M214)	_____	\$15.00	_____
Model 215 Security Plate (Order Code: SP-M215)	_____	\$15.00	_____
Model 216 Security Plate (Order Code: SP-M216)	_____	\$15.00	_____
Screw-On Bumper Kit (black, set of 8) (Order Code: 31064)	_____	\$10.00	_____

	Qty	US List	Total
<b>Model 214A, Model 215A, and Model 216A Announcer's Consoles (all Serial Numbers)</b>			
<b>Pushbutton Switch Backlight LED</b> (Order Code: 3154)		\$ 3.00	
<b>Pushbutton Switch (momentary, Mfg. by EAO)</b> (Order Code: 12028) <i>Note: Does not include button cap, lens, or label. See 31069.</i>		\$14.00	
<b>Button Cap, Lenses, and Label Kit (includes five each button cap, clear lens, frosted lens, and one button function label sheet (15154))</b> (Order Code: 31069)		\$40.00	
<b>Knob – Phones Level (black, push-on, 15 mm)</b> (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>		\$ 3.00	
<b>Knob Cap – Phones Level (black w/white line, 15 mm)</b> (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>		\$ 1.50	
<b>Potentiometer – Phones Level</b> (Order Code: 2127)		\$ 5.00	
<b>1/4" Phone Jack</b> (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>		\$ 4.00	
<b>Nut (plastic)</b> (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>		\$ 1.50	
<b>Screw-On Bumper Kit (black, set of 8)</b> (Order Code: 31064)		\$10.00	
<b>Blank Plate – XLR (black)</b> (Order Code: 1073)		\$ 3.00	
<b>Screw-On Bumper Kit (black, set of 8)</b> (Order Code: 31064)		\$10.00	
<b>Model 232, Model 234, and Model 236 Announcer's Consoles</b>			
<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>		\$ 3.00	
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>		\$ 0.50	
<b>Push-Pot Potentiometer Assembly (dual-section)</b> (Order Code: 32298) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>		\$ 9.00	
<b>Pushbutton Switch (momentary, 17 mm x 17 mm)</b> (Order Code: 12106) <i>Note: Includes button cap and lens. See 32649 for replacement button cap and lens kit.</i>		\$ 6.00	
<b>Button Cap and Lens Kit (includes four each button cap and frosted lens)</b> (Order Code: 32649)		\$24.00	
<b>1/4" Phone Jack</b> (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>		\$ 4.00	
<b>Nut (plastic)</b> (Order Code: 1090) <i>Note: For use with 1/4" phone jack.</i>		\$ 1.50	
<b>Self-Adhesive Rubber Bumpers (black, set of 4, 1/2" dia. by 1/4" tall)</b> (Order Code: 14326)		\$ 3.00	
<b>Blank Plate – XLR (black)</b> (Order Code: 1073)		\$ 3.00	
<b>For Serial Numbers 00151-00274</b>			
<b>Knob – Glow (black w/clear center, 13 mm dia. x 17.8 mm tall)</b> (Order Code: 14321)		\$ 5.00	
<b>Rotary Encoder (24-step w/switch, 25 mm overall length)</b> (Order Code: 12103)		\$ 8.00	
<b>For Serial Numbers 00275-later</b>			
<b>Knob – Glow (black w/clear center, 13 mm dia. x 13.8 mm tall)</b> (Order Code: 14340)		\$ 5.00	
<b>Rotary Encoder (24-step w/switch, 21 mm overall length)</b> (Order Code: 12109)		\$ 8.00	

	Qty	US List	Total
<b>Model 240 Producer's Console (all Serial Numbers)</b>			
<b>Button Backlight LED</b> (Order Code: 3154)		\$ 3.00	
<b>Pushbutton Switch (momentary, Mfg. by EAO)</b> (Order Code: 12028) <i>Note: Does not include button cap, lens, or label. See 31069.</i>		\$14.00	
<b>Button Cap, Lenses, and Label Kit (includes five each button cap, clear lens, frosted lens, and one button function label sheet (15154))</b> (Order Code: 31069)		\$40.00	
<b>Knob – Phones Level (black, push-on, 15 mm)</b> (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>		\$ 3.00	
<b>Knob Cap – Phones Level (black w/white line, 15 mm)</b> (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>		\$ 1.50	
<b>Potentiometer – Phones Level</b> (Order Code: 2127)		\$ 5.00	
<b>1/4" Phone Jack</b> (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>		\$ 4.00	
<b>Nut (plastic)</b> (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>		\$ 1.50	
<b>DC Power Entry Jack Assembly (includes PCB, washer, and nut)</b> (Order Code: 32135) <i>Note: Requires cable assembly, sold separately. See 13690.</i>		\$12.00	
<b>Cable Assembly for DC Power Entry Jack Assembly (2-conductor, 5")</b> (Order Code: 13690)		\$ 4.00	
<b>Blank Plate – XLR (black)</b> (Order Code: 1073)		\$ 3.00	
<b>Model 240 Security Plate</b> (Order Code: SP-M240)		\$18.00	
<b>Screw-On Bumper Kit (black, set of 8)</b> (Order Code: 31064)		\$10.00	
<b>24 Vdc, 0.75 A Power Supply (output terminated onto 2.1 x 5.5 mm locking coaxial jack)</b> (Order Code: PS-DC-03)		\$46.00	
<b>Model 342 Intercom Station</b>			
<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>		\$ 3.00	
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>		\$ 0.50	
<b>Push-Pot Potentiometer Assembly (dual-section)</b> (Order Code: 32298) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>		\$ 9.00	
<b>Pushbutton Switch (momentary, 17 mm x 17 mm)</b> (Order Code: 12106) <i>Note: Includes button cap and lens. See 32649 for replacement button cap and lens kit.</i>		\$ 6.00	
<b>Button Cap and Lens Kit (includes four each button cap and frosted lens)</b> (Order Code: 32649)		\$24.00	
<b>Self-Adhesive Rubber Bumpons (black, set of 4, 1/2" dia. by 0.138" tall)</b> (Order Code: 14028)		\$ 2.00	
<b>Model 348 Intercom Station</b>			
<b>Pushbutton Switch (momentary, 17 mm x 17 mm)</b> (Order Code: 12106) <i>Note: Includes button cap and lens. See 32649 for replacement button cap and lens kit.</i>		\$ 6.00	
<b>Button Cap and Lens Kit (includes four each button cap and frosted lens)</b> (Order Code: 32649)		\$24.00	
<b>3.5 mm 4-Conductor (TRRS) Jack</b> (Order Code: 1410)		\$ 5.00	
<b>Loudspeaker (37 mm dia., 8 ohm)</b> (Order Code: 10702) <i>Mfg. No.: Visaton: BF37/2261; Parts Express No.: 292-655</i>		\$22.00	
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: For use with microphone bushing.</i>		\$ 0.50	
<b>Self-Adhesive Rubber Bumpons (black, set of 4, 1/2" dia. by 1/4" tall)</b> (Order Code: 14326)		\$ 3.00	
<b>Blank Plate – XLR (black)</b> (Order Code: 1073)		\$ 3.00	
<b>For Serial Numbers 00151-00381</b>			
<b>Knob – Glow (black w/clear center, 13 mm dia. x 17.8 mm tall)</b> (Order Code: 14321)		\$ 5.00	
<b>Rotary Encoder (24-step w/switch, 25 mm overall length)</b> (Order Code: 12103)		\$ 8.00	
<b>For Serial Numbers 00382-later</b>			
<b>Knob – Glow (black w/clear center, 13 mm dia. x 13.8 mm tall)</b> (Order Code: 14340)		\$ 5.00	
<b>Rotary Encoder (24-step w/switch, 21 mm overall length)</b> (Order Code: 12109)		\$ 8.00	



	Qty	US List	Total
<b>Model 352A Talk Station (all Serial Numbers)</b>			
<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
<b>Push-Pot Potentiometer Assembly (dual-section)</b> (Order Code: 32298) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
<b>Pushbutton Switch (momentary, 17 mm x 17 mm)</b> (Order Code: 12106) <i>Note: Includes button cap and lens. See 32649 for replacement button cap and lens kit.</i>	_____	\$ 6.00	_____
<b>Button Cap and Lens Kit (includes four each button cap and frosted lens)</b> (Order Code: 32649)	_____	\$24.00	_____
<b>Pushbutton Switch (momentary) – Monitor Source</b> (Order Code: 12056)	_____	\$ 4.00	_____
<b>Pushbutton Cap (gray)</b> (Order Code: 14207)	_____	\$ 3.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: For use with microphone bushing.</i>	_____	\$ 0.50	_____
<b>Rubber Bumper (black, set of 4, 1/2" dia. by 7/32" tall)</b> (Order Code: 14339) <i>Note: Bumpers and machine screws are sold separately. See 8032-5/16 for screws.</i>	_____	\$ 6.00	_____
<b>Machine Screw (SEMS, 4-40x5/16")</b> (Order Code: 8032-5/16) <i>Note: Machine screws and bumpers are sold separately. See 14339 for bumpers.</i>	_____	\$ 0.50	_____
<hr/>			
<b>Model 354 Talk Station (all Serial Numbers)</b>			
<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
<b>Push-Pot Potentiometer Assembly (dual-section)</b> (Order Code: 32298) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
<b>Pushbutton Switch (momentary, 17 mm x 17 mm)</b> (Order Code: 12106) <i>Note: Includes button cap and lens. See 32649 for replacement button cap and lens kit.</i>	_____	\$ 6.00	_____
<b>Button Cap and Lens Kit (includes four each button cap and frosted lens)</b> (Order Code: 32649)	_____	\$24.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: For use with microphone bushing.</i>	_____	\$ 0.50	_____
<b>Rubber Bumper (black, set of 4, 1/2" dia. by 7/32" tall)</b> (Order Code: 14339) <i>Note: Bumpers and machine screws are sold separately. See 8032-5/16 for screws.</i>	_____	\$ 6.00	_____
<b>Machine Screw (SEMS, 4-40x5/16")</b> (Order Code: 8032-5/16) <i>Note: Machine screws and bumpers are sold separately. See 14339 for bumpers.</i>	_____	\$ 0.50	_____
<hr/>			
<b>Model 354A Talk Station (all Serial Numbers)</b>			
<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
<b>Push-Pot Potentiometer Assembly (dual-section)</b> (Order Code: 32298) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
<b>Pushbutton Switch (momentary, 17 mm x 17 mm)</b> (Order Code: 12106) <i>Note: Includes button cap and lens. See 32649 for replacement button cap and lens kit.</i>	_____	\$ 6.00	_____
<b>Button Cap and Lens Kit (includes four each button cap and frosted lens)</b> (Order Code: 32649)	_____	\$24.00	_____
<b>Pushbutton Switch (momentary) – Monitor Source</b> (Order Code: 12056)	_____	\$ 4.00	_____
<b>Pushbutton Cap (gray)</b> (Order Code: 14207)	_____	\$ 3.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: For use with microphone bushing.</i>	_____	\$ 0.50	_____
<b>Rubber Bumper (black, set of 4, 1/2" dia. by 7/32" tall)</b> (Order Code: 14339) <i>Note: Bumpers and machine screws are sold separately. See 8032-5/16 for screws.</i>	_____	\$ 6.00	_____
<b>Machine Screw (SEMS, 4-40x5/16")</b> (Order Code: 8032-5/16) <i>Note: Machine screws and bumpers are sold separately. See 14339 for bumpers.</i>	_____	\$ 0.50	_____
<hr/>			
<b>GME-3-12 Gooseneck Microphone</b>			
<b>Foam Windscreen – for GME-3-12 Gooseneck Microphone</b> (Order Code: 14331) <i>Note: Also included with Model 11B Gooseneck Microphone Assembly.</i>	_____	\$ 6.00	_____

	Qty	US List	Total
<b>Model 362 Listen-Only Beltpack (all Serial Numbers)</b>			
<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
<b>Push-Pot Potentiometer Assembly (dual-section)</b> (Order Code: 32298) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
<b>1/4" Phone Jack</b> (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
<b>Nut (plastic)</b> (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
<b>3.5 mm Stereo Jack</b> (Order Code: 1198)	_____	\$ 3.00	_____
<b>Belt Clip (black, steel)</b> (Order Code: 30247)	_____	\$ 5.00	_____
<b>Pop-Rivet – for Belt Clip (black, aluminum, 0.125" grip)</b> (Order Code: 8201-.125)	_____	\$ 1.00	_____
<b>Phillips Machine Screw – for Belt Clip (black, 6-32x1/4")</b> (Order Code: 8056-1/4)	_____	\$ 0.50	_____
<hr/>			
<b>Model 362A Listen-Only Beltpack (all Serial Numbers)</b>			
<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
<b>Push-Pot Potentiometer Assembly (dual-section)</b> (Order Code: 32298) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
<b>1/4" Phone Jack</b> (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
<b>Nut (plastic)</b> (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
<b>3.5 mm Stereo Jack</b> (Order Code: 1198)	_____	\$ 3.00	_____
<b>Belt Clip (black, steel)</b> (Order Code: 30247)	_____	\$ 5.00	_____
<b>Pop-Rivet – for Belt Clip (black, aluminum, 0.125" grip)</b> (Order Code: 8201-.125)	_____	\$ 1.00	_____
<b>Phillips Machine Screw – for Belt Clip (black, 6-32x1/4")</b> (Order Code: 8056-1/4)	_____	\$ 0.50	_____
<hr/>			
<b>Model 370 Intercom Beltpack</b>			
<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
<b>Trim Potentiometer (for sidetone)</b> (Order Code: 2119) <i>Note: Plastic shaft sold separately. See 14307.</i>	_____	\$ 4.00	_____
<b>Plastic Shaft (gray, for sidetone trim pot)</b> (Order Code: 14307)	_____	\$ 3.00	_____
<b>Switch Cap – Talk (12 mm square)</b> (Order Code: 14295) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____
<b>Switch Cap – Call (10 mm square)</b> (Order Code: 14296) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____
<b>Switch Cap Adapter</b> (Order Code: 14294) <i>Note: Switch cap and switch cap adapter are sold separately. See 14295 for 12 mm switch cap and 14296 for 10 mm switch cap.</i>	_____	\$ 1.50	_____
<b>Belt Clip (black, steel)</b> (Order Code: 30247)	_____	\$ 5.00	_____
<b>Pop-Rivet – for Belt Clip (black, aluminum, 0.125" grip)</b> (Order Code: 8201-.125)	_____	\$ 1.00	_____
<b>Phillips Machine Screw – for Belt Clip (black, 6-32x1/4")</b> (Order Code: 8056-1/4)	_____	\$ 0.50	_____
<hr/>			
<b>For Serial Numbers 00151-02000</b>			
<b>Push-Pot Potentiometer Assembly (dual-section)</b> (Order Code: 32298) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
<hr/>			
<b>For Serial Numbers 02001-later</b>			
<b>Push-Pot Potentiometer Assembly (single-section)</b> (Order Code: 32299) <i>Note: Includes push-pot (2172) and sleeve (14297).</i>	_____	\$ 9.00	_____

	Qty	US List	Total
<b>Model 370A Intercom Beltpack (all Serial Numbers)</b>			
<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
<b>Push-Pot Potentiometer Assembly (dual-section)</b> (Order Code: 32298) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
<b>Switch Cap – Talk (12 mm square)</b> (Order Code: 14295) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____
<b>Switch Cap – Call (10 mm square)</b> (Order Code: 14296) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____
<b>Switch Cap Adapter</b> (Order Code: 14294) <i>Note: Switch cap and switch cap adapter are sold separately. See 14295 for 12 mm switch cap and 14296 for 10 mm switch cap.</i>	_____	\$ 1.50	_____
<b>Belt Clip (black, steel)</b> (Order Code: 30247)	_____	\$ 5.00	_____
<b>Hex Machine Screw – for Belt Clip (black, 6-32x1/4")</b> (Order Code: 8054-1/4)	_____	\$ 0.50	_____

<b>Model 371 Intercom Beltpack (all Serial Numbers)</b>			
<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
<b>Push-Pot Potentiometer Assembly (single-section)</b> (Order Code: 32299) <i>Note: Includes push-pot (2172) and sleeve (14297).</i>	_____	\$ 9.00	_____
<b>Trim Potentiometer (for sidetone)</b> (Order Code: 2119) <i>Note: Plastic shaft sold separately. See 14307.</i>	_____	\$ 4.00	_____
<b>Plastic Shaft (gray, for sidetone trim pot)</b> (Order Code: 14307)	_____	\$ 3.00	_____
<b>Switch Cap – Talk (12 mm square)</b> (Order Code: 14295) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____
<b>Switch Cap – Call (10 mm square)</b> (Order Code: 14296) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____
<b>Switch Cap Adapter</b> (Order Code: 14294) <i>Note: Switch cap and switch cap adapter are sold separately. See 14295 for 12 mm switch cap and 14296 for 10 mm switch cap.</i>	_____	\$ 1.50	_____
<b>Belt Clip (black, steel)</b> (Order Code: 30247)	_____	\$ 5.00	_____
<b>Pop-Rivet – for Belt Clip (black, aluminum, 0.125" grip)</b> (Order Code: 8201-.125)	_____	\$ 1.00	_____
<b>Phillips Machine Screw – for Belt Clip (black, 6-32x1/4")</b> (Order Code: 8056-1/4)	_____	\$ 0.50	_____

<b>Model 371A Intercom Beltpack (all Serial Numbers)</b>			
<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
<b>Push-Pot Potentiometer Assembly (dual-section)</b> (Order Code: 32298) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
<b>Switch Cap – Talk (12 mm square)</b> (Order Code: 14295) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____
<b>Switch Cap – Call (10 mm square)</b> (Order Code: 14296) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____
<b>Switch Cap Adapter</b> (Order Code: 14294) <i>Note: Switch cap and switch cap adapter are sold separately. See 14295 for 12 mm switch cap and 14296 for 10 mm switch cap.</i>	_____	\$ 1.50	_____
<b>Belt Clip (black, steel)</b> (Order Code: 30247)	_____	\$ 5.00	_____
<b>Hex Machine Screw – for Belt Clip (black, 6-32x1/4")</b> (Order Code: 8054-1/4)	_____	\$ 0.50	_____

	Qty	US List	Total
<b>Model 372A Intercom Beltpack (all Serial Numbers)</b>			
<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
<b>Push-Pot Potentiometer Assembly (dual-section)</b> (Order Code: 32298) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
<b>Switch Cap – Talk (12 mm square)</b> (Order Code: 14295) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____
<b>Switch Cap Adapter</b> (Order Code: 14294) <i>Note: Switch cap and switch cap adapter are sold separately. See 14295 for 12 mm switch cap.</i>	_____	\$ 1.50	_____
<b>Belt Clip (black, steel)</b> (Order Code: 30247)	_____	\$ 5.00	_____
<b>Pop-Rivet – for Belt Clip (black, aluminum, 0.125" grip)</b> (Order Code: 8201-.125)	_____	\$ 1.00	_____

<b>Model 373A Intercom Beltpack (all Serial Numbers)</b>			
<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
<b>Push-Pot Potentiometer Assembly (dual-section)</b> (Order Code: 32298) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
<b>Switch Cap – Talk (12 mm square)</b> (Order Code: 14295) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____
<b>Switch Cap Adapter</b> (Order Code: 14294) <i>Note: Switch cap and switch cap adapter are sold separately. See 14295 for 12 mm switch cap.</i>	_____	\$ 1.50	_____
<b>Belt Clip (black, steel)</b> (Order Code: 30247)	_____	\$ 5.00	_____
<b>Pop-Rivet – for Belt Clip (black, aluminum, 0.125" grip)</b> (Order Code: 8201-.125)	_____	\$ 1.00	_____

<b>Model 374 Intercom Beltpack (all Serial Numbers)</b>			
<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
<b>Push-Pot Potentiometer Assembly (dual-section)</b> (Order Code: 32298) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
<b>Trim Potentiometer (for sidetone)</b> (Order Code: 2119) <i>Note: Plastic shaft sold separately. See 14307.</i>	_____	\$ 4.00	_____
<b>Plastic Shaft (gray, for sidetone trim pot)</b> (Order Code: 14307)	_____	\$ 3.00	_____
<b>Switch Cap (10 mm square)</b> (Order Code: 14296) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____
<b>Switch Cap Adapter</b> (Order Code: 14294) <i>Note: Switch cap and switch cap adapter are sold separately. See 14296 for 10 mm switch cap.</i>	_____	\$ 1.50	_____
<b>Belt Clip (black, steel)</b> (Order Code: 30247)	_____	\$ 5.00	_____
<b>Pop-Rivet – for Belt Clip (black, aluminum, 0.125" grip)</b> (Order Code: 8201-.125)	_____	\$ 1.00	_____
<b>Phillips Machine Screw – for Belt Clip (black, 6-32x1/4")</b> (Order Code: 8056-1/4)	_____	\$ 0.50	_____

<b>Model 374A Intercom Beltpack (all Serial Numbers)</b>			
<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
<b>Push-Pot Potentiometer Assembly (dual-section)</b> (Order Code: 32298) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
<b>Switch Cap (10 mm square)</b> (Order Code: 14296) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____
<b>Switch Cap Adapter</b> (Order Code: 14294) <i>Note: Switch cap and switch cap adapter are sold separately. See 14296 for 10 mm switch cap.</i>	_____	\$ 1.50	_____
<b>Belt Clip (black, steel)</b> (Order Code: 30247)	_____	\$ 5.00	_____
<b>Hex Machine Screw – for Belt Clip (black, 6-32x1/4")</b> (Order Code: 8054-1/4)	_____	\$ 0.50	_____

	Qty	US List	Total
<b>Model 380 On-Air Beltpack</b>			
<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
<b>1/4" Phone Jack</b> (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
<b>Nut (plastic)</b> (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
<b>Switch Cap Adapter</b> (Order Code: 14294) <i>Note: Switch cap and switch cap adapter are sold separately. See 14295 for 12 mm switch cap.</i>	_____	\$ 1.50	_____
<b>Switch Cap (12 mm)</b> (Order Code: 14295) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____
<b>Belt Clip (black, steel)</b> (Order Code: 30247)	_____	\$ 5.00	_____
<b>Pop-Rivet – for Belt Clip (black, aluminum, 0.125" grip)</b> (Order Code: 8201-.125)	_____	\$ 1.00	_____
<b>Phillips Machine Screw – for Belt Clip (black, 6-32x1/4")</b> (Order Code: 8056-1/4)	_____	\$ 0.50	_____
<b>For Serial Numbers 00151-01000</b>			
<b>Push-Pot Potentiometer Assembly (dual-section)</b> (Order Code: 32298) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
<b>For Serial Numbers 01001-later</b>			
<b>Push-Pot Potentiometer Assembly (single-section)</b> (Order Code: 32299) <i>Note: Includes push-pot (2172) and sleeve (14297).</i>	_____	\$ 9.00	_____
<hr/>			
<b>Model 381 On-Air Beltpack (all Serial Numbers)</b>			
<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
<b>Push-Pot Potentiometer Assembly (dual-section)</b> (Order Code: 32298) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
<b>1/4" Phone Jack</b> (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
<b>Nut (plastic)</b> (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
<b>Switch Cap Adapter</b> (Order Code: 14294) <i>Note: Switch cap and switch cap adapter are sold separately. See 14295 for 12 mm switch cap.</i>	_____	\$ 1.50	_____
<b>Switch Cap (12 mm)</b> (Order Code: 14295) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____
<b>Belt Clip (black, steel)</b> (Order Code: 30247)	_____	\$ 5.00	_____
<b>Pop-Rivet – for Belt Clip (black, aluminum, 0.125" grip)</b> (Order Code: 8201-.125)	_____	\$ 1.00	_____
<hr/>			
<b>Model 391 Dante Alerting Unit (all Serial Numbers)</b>			
<b>Pushbutton Switch (momentary) – Mode</b> (Order Code: 12056)	_____	\$ 4.00	_____
<b>Pushbutton Cap (gray)</b> (Order Code: 14207)	_____	\$ 3.00	_____
<b>Screw-On Bumper Kit (black, set of 8)</b> (Order Code: 31064)	_____	\$10.00	_____
<b>Trim Potentiometer</b> (Order Code: 2119) <i>Note: Plastic shaft sold separately. See 14307.</i>	_____	\$ 4.00	_____
<b>Plastic Shaft (gray, for trim pot)</b> (Order Code: 14307)	_____	\$ 3.00	_____
<hr/>			
<b>Model 392 Visual Indicator Unit (all Serial Numbers)</b>			
<b>Metal Plate</b> (Order Code: 32248) <i>Mfg. No.: Leviton® S746-N, 2-gang, 1-Decora® opening, centered, 302 stainless steel. Available from online and electrical supply sources.</i>			Not available from factory

	Qty	US List	Total
<b>Model 400 SDI-Over-Fiber Transport Systems (all Serial Numbers)</b>			
<b>Pushbutton Switch (momentary)</b> (Order Code: 12055) Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND		\$ 4.00	
<b>Display Lens</b> (Order Code: 15203)		\$ 4.00	
<b>Power Supply (universal AC mains input/12 V, 3.34 A (40 watts) output)</b> (Order Code: 10303) Mfg. No.: Cincon CFM40S120; Digi-Key No.: 2034-3674-ND; Mouser No.: 418-CFM40S120		\$ 45.00	
<b>Model 403-03 Triple Optical to Electrical Interface Card</b> (Order Code: M403-03) Note: Does not include SFP optical modules (card uses one each 6411 and 6407).		\$450.00	
<b>Model 403-30 Triple Electrical to Optical Interface Card</b> (Order Code: M403-30) Note: Does not include SFP optical modules (card uses one each 6410 and 6408).		\$550.00	
<b>SFP Optical Module (video, single-channel receiver)</b> (Order Code: 6411) Note: Non-MSA, supports 3G SDI video. Mfg. No.: Eoptolink EOLS-30R-DN.		\$156.00	
<b>SFP Optical Module (video, dual-channel receiver)</b> (Order Code: 6407) Note: Non-MSA, supports 3G SDI video. Mfg. No.: Eoptolink EOLS-30DR-DN.		\$185.00	
<b>SFP Optical Module (video, single-channel transmitter)</b> (Order Code: 6410) Note: 1490 nm CWDM laser; non-MSA, supports 3G SDI video. Mfg. No.: Eoptolink EOLS-1630T-DLN.		\$210.00	
<b>SFP Optical Module (video, dual-channel transmitter)</b> (Order Code: 6408) Note: 1310 nm FP laser (channel 1), 1550 nm DFB laser (channel 2), non-MSA, supports 3G SDI video. Mfg. No.: Eoptolink EOLS-1330DT-10DN-V.		\$330.00	
<b>Optical Attenuator (4 dB)</b> (Order Code: 6437) Note: LC UPC-M/F.		\$ 15.00	
<b>ST-ST Optical Barrel Connector (with nut and lockwasher)</b> (Order Code: 1260)		\$ 6.00	
<b>Optical Multiplexer ("mux") (3 inputs/1 output)</b> (Order Code: 10826) Note: 1310, 1490, and 1550 nm inputs use LC optical connectors; output uses ST optical connector.		\$ 70.00	
<b>Optical Demultiplexer ("demux") (1 input/3 outputs)</b> (Order Code: 10827) Note: Input uses ST optical connector; 1310, 1490, and 1550 nm outputs use LC optical connectors.		\$ 95.00	
<hr/>			
<b>Model 400A SDI-Over-Fiber Transport Systems (all Serial Numbers)</b>			
<b>Pushbutton Switch (momentary)</b> (Order Code: 12055) Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND		\$ 4.00	
<b>Field-Service Display Replacement Kit (includes a VFD display (10609) with attached ribbon cable (13707))</b> (Order Code: 32638)		\$122.00	
<b>Display Lens</b> (Order Code: 15203)		\$ 4.00	
<b>Power Supply (universal AC mains input/12 V, 3.34 A (40 watts) output)</b> (Order Code: 10303) Mfg. No.: Cincon CFM40S120; Digi-Key No.: 2034-3674-ND; Mouser No.: 418-CFM40S120		\$ 45.00	
<b>Model 403-03 Triple Optical to Electrical Interface Card</b> (Order Code: M403-03) Note: Does not include SFP optical modules (card uses one each 6411 and 6407).		\$450.00	
<b>Model 403-30 Triple Electrical to Optical Interface Card</b> (Order Code: M403-30) Note: Does not include SFP optical modules (card uses one each 6410 and 6408).		\$550.00	
<b>SFP Optical Module (video, single-channel receiver)</b> (Order Code: 6411) Note: Non-MSA, supports 3G SDI video. Mfg. No.: Eoptolink EOLS-30R-DN.		\$156.00	
<b>SFP Optical Module (video, dual-channel receiver)</b> (Order Code: 6407) Note: Non-MSA, supports 3G SDI video. Mfg. No.: Eoptolink EOLS-30DR-DN.		\$185.00	
<b>SFP Optical Module (video, single-channel transmitter)</b> (Order Code: 6410) Note: 1490 nm CWDM laser; non-MSA, supports 3G SDI video. Mfg. No.: Eoptolink EOLS-1630T-DLN.		\$210.00	
<b>SFP Optical Module (video, dual-channel transmitter)</b> (Order Code: 6408) Note: 1310 nm FP laser (channel 1), 1550 nm DFB laser (channel 2), non-MSA, supports 3G SDI video. Mfg. No.: Eoptolink EOLS-1330DT-10DN-V.		\$330.00	
<b>Optical Attenuator (4 dB)</b> (Order Code: 6437) Note: LC UPC-M/F.		\$ 15.00	
<b>ST-ST Optical Barrel Connector (with nut and lockwasher)</b> (Order Code: 1260)		\$ 6.00	
<b>Optical Multiplexer ("mux") (3 inputs/1 output)</b> (Order Code: 10826) Note: 1310, 1490, and 1550 nm inputs use LC optical connectors; output uses ST optical connector.		\$ 70.00	
<b>Optical Demultiplexer ("demux") (1 input/3 outputs)</b> (Order Code: 10827) Note: Input uses ST optical connector; 1310, 1490, and 1550 nm outputs use LC optical connectors.		\$ 95.00	

	Qty	US List	Total
<b>Model 410 SDI-Over-Fiber Transport Systems (all Serial Numbers)</b>			
<b>Pushbutton Switch (momentary)</b> (Order Code: 12055) Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND		\$ 4.00	
<b>Display Lens</b> (Order Code: 15203)		\$ 4.00	
<b>Screw-On Bumper Kit (black, set of 8)</b> (Order Code: 31064)		\$ 10.00	
<b>12 Vdc, 1.5 A Power Supply (output terminated onto 4-pin female XLR connector)</b> (Order Code: PS-DC-02)		\$ 88.00	
<b>Model 403-03 Triple Optical to Electrical Interface Card</b> (Order Code: M403-03) Note: Does not include SFP optical modules (card uses one each 6411 and 6407).		\$450.00	
<b>Model 403-30 Triple Electrical to Optical Interface Card</b> (Order Code: M403-30) Note: Does not include SFP optical modules (card uses one each 6410 and 6408).		\$550.00	
<b>Model 403-33M Triple Electrical to Optical / Triple Optical to Electrical Interface Card</b> (Order Code: M403-33) Notes: Does not include SFP optical modules. Used as a replacement for both 403-33M and 403-33 cards (card uses one each 6410, 6408, 6411, and 6407).		\$550.00	
<b>SFP Optical Module (video, single-channel receiver)</b> (Order Code: 6411) Note: Non-MSA, supports 3G SDI video. Mfg. No.: Eoptolink EOLS-30R-DN.		\$156.00	
<b>SFP Optical Module (video, dual-channel receiver)</b> (Order Code: 6407) Note: Non-MSA, supports 3G SDI video. Mfg. No.: Eoptolink EOLS-30DR-DN.		\$185.00	
<b>SFP Optical Module (video, single-channel transmitter)</b> (Order Code: 6410) Note: 1490 nm CWDM laser; non-MSA, supports 3G SDI video. Mfg. No.: Eoptolink EOLS-1630T-DLN.		\$210.00	
<b>SFP Optical Module (video, dual-channel transmitter)</b> (Order Code: 6408) Note: 1310 nm FP laser (channel 1), 1550 nm DFB laser (channel 2), non-MSA, supports 3G SDI video. Mfg. No.: Eoptolink EOLS-1330DT-10DN-V.		\$330.00	
<b>Optical Attenuator (4 dB)</b> (Order Code: 6437) Note: LC UPC-M/F.		\$ 15.00	
<b>ST-ST Optical Barrel Connector (with nut and lockwasher)</b> (Order Code: 1260)		\$ 6.00	
<b>Optical Multiplexer ("mux") (3 inputs/1 output)</b> (Order Code: 10826) Notes: 1310, 1490, and 1550 nm inputs use LC optical connectors; output uses ST optical connector. Applicable to M410-3T and M410-3R.		\$ 70.00	
<b>Optical Demultiplexer ("demux") (1 input/3 outputs)</b> (Order Code: 10827) Notes: Input uses ST optical connector; 1310, 1490, and 1550 nm outputs use LC optical connectors. Applicable to M410-3T and M410-3R.		\$ 95.00	
<b>Optical Demultiplexer ("demux") (1 input/3 outputs)</b> (Order Code: 10828) Notes: Input uses ST optical connector; 1310, 1490, and 1550 nm outputs use LC optical connectors. Applicable to M410-3T/3R.		\$ 95.00	
<hr/>			
<b>Model 412 Fiber Transport Systems (all Serial Numbers)</b>			
<b>Pushbutton Switch (momentary)</b> (Order Code: 12055) Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND		\$ 4.00	
<b>Display Lens</b> (Order Code: 15203)		\$ 4.00	
<b>Screw-On Bumper Kit (black, set of 8)</b> (Order Code: 31064)		\$ 10.00	
<b>12 Vdc, 1.5 A Power Supply (output terminated onto 4-pin female XLR connector)</b> (Order Code: PS-DC-02)		\$ 88.00	
<b>SFP Optical Module (video, single-channel receiver)</b> (Order Code: 6411) Note: Non-MSA, supports 3G SDI video. Mfg. No.: Eoptolink EOLS-30R-DN.		\$156.00	
<b>SFP Optical Module (video, dual-channel receiver)</b> (Order Code: 6407) Note: Non-MSA, supports 3G SDI video. Mfg. No.: Eoptolink EOLS-30DR-DN.		\$185.00	
<b>SFP Optical Module (video, single-channel transmitter)</b> (Order Code: 6410) Note: 1490 nm CWDM laser; non-MSA, supports 3G SDI video. Mfg. No.: Eoptolink EOLS-1630T-DLN.		\$210.00	
<b>SFP Optical Module (video, dual-channel transmitter)</b> (Order Code: 6408) Note: 1310 nm FP laser (channel 1), 1550 nm DFB laser (channel 2), non-MSA, supports 3G SDI video. Mfg. No.: Eoptolink EOLS-1330DT-10DN-V.		\$330.00	
<b>SFP Optical Module (Ethernet, transceiver)</b> (Order Code: 6433) Note: 1310 nm FP laser, MSA, supports 10/100/1000 Ethernet. Mfg. No.: ATOP APS31123CDL20.		\$ 55.00	
<b>Optical Attenuator (4 dB)</b> (Order Code: 6437) Note: LC UPC-M/F.		\$ 15.00	
<b>ST-ST Optical Barrel Connector (with nut and lockwasher)</b> (Order Code: 1260)		\$ 6.00	

	Qty	US List	Total
<b>Model 543D IFB Interface (all Serial Numbers)</b>			
Screw-On Bumper Kit (black, set of 8) (Order Code: 31064)	_____	\$10.00	_____
<b>Model 544D Audio Interface (all Serial Numbers)</b>			
Screw-On Bumper Kit (black, set of 8) (Order Code: 31064)	_____	\$10.00	_____
<b>Model 545AC Intercom Interface (all Serial Numbers)</b>			
Pushbutton Switch (momentary) – Auto Null (Order Code: 12056)	_____	\$ 4.00	_____
Pushbutton Cap (gray) (Order Code: 14207)	_____	\$ 3.00	_____
Screw-On Bumper Kit (black, set of 8) (Order Code: 31064)	_____	\$10.00	_____
<b>Model 545AR Intercom Interface (all Serial Numbers)</b>			
Pushbutton Switch (momentary) – Auto Null (Order Code: 12056)	_____	\$ 4.00	_____
Pushbutton Cap (gray) (Order Code: 14207)	_____	\$ 3.00	_____
Screw-On Bumper Kit (black, set of 8) (Order Code: 31064)	_____	\$10.00	_____
<b>Model 545DC Intercom Interface (all Serial Numbers)</b>			
Pushbutton Switch (momentary) – Auto Null (Order Code: 12056)	_____	\$ 4.00	_____
Pushbutton Cap (gray) (Order Code: 14207)	_____	\$ 3.00	_____
Screw-On Bumper Kit (black, set of 8) (Order Code: 31064)	_____	\$10.00	_____
<b>Model 545DR Intercom Interface (all Serial Numbers)</b>			
Pushbutton Switch (momentary) – Auto Null (Order Code: 12056)	_____	\$ 4.00	_____
Pushbutton Cap (gray) (Order Code: 14207)	_____	\$ 3.00	_____
Screw-On Bumper Kit (black, set of 8) (Order Code: 31064)	_____	\$10.00	_____
<b>Model 742 Audio Mixer (all Serial Numbers)</b>			
Knob – Inputs 1-8 (black, push-on, 15 mm) (Order Code: 2056)	_____	\$ 3.00	_____
<i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>			
Knob Cap – Inputs 1-8 (black w/white line, 15 mm) (Order Code: 2057)	_____	\$ 1.50	_____
<i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>			
Potentiometer – Inputs 1-4 (Order Code: 2145)	_____	\$ 4.00	_____
Potentiometer – Inputs 5-8 (Order Code: 2166)	_____	\$ 4.00	_____
Potentiometer – Master and Monitor (dual-shaft) (Order Code: 2167)	_____	\$12.00	_____
Knob (Top) – Master and Monitor (black w/white line, 11 mm) (Order Code: 14253)	_____	\$ 3.00	_____
<i>Note: Knob (top), knob cap (top), and knob (bottom) are sold separately. See 14255 for knob cap (top) and 14254 for knob (bottom).</i>			
Knob Cap (Top) – Master and Monitor (black w/white line, 11 mm) (Order Code: 14255)	_____	\$ 3.00	_____
<i>Note: Knob (top), knob cap (top), and knob (bottom) are sold separately. See 14253 for knob (top) and 14254 for knob (bottom).</i>			
Knob (Bottom) – Master and Monitor (black w/white line, 15 mm) (Order Code: 14254)	_____	\$ 4.00	_____
<i>Note: Knob (top), knob cap (top), and knob (bottom) are sold separately. See 14253 for knob (top) and 14255 for knob cap (top).</i>			



	Qty	US List	Total
<b>Model 742A Audio Mixer (all Serial Numbers)</b>			
<b>4-Position DIP Switch</b> (Order Code: 12071)		\$ 5.00	
<b>Knob – Inputs 1-8 (black, push-on, 15 mm)</b> (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 2057 for knob cap.</i>		\$ 3.00	
<b>Knob Cap – Inputs 1-8 (black w/white line, 15 mm)</b> (Order Code: 2057) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>		\$ 1.50	
<b>Potentiometer – Inputs 1-4</b> (Order Code: 2145)		\$ 4.00	
<b>Potentiometer – Inputs 5-8</b> (Order Code: 2166)		\$ 4.00	
<b>Potentiometer – Master and Monitor (dual-shaft)</b> (Order Code: 2167)		\$12.00	
<b>Knob (Top) – Master and Monitor (black w/white line, 11 mm)</b> (Order Code: 14253) <i>Note: Knob (top), knob cap (top), and knob (bottom) are sold separately. See 14255 for knob cap (top) and 14254 for knob (bottom).</i>		\$ 3.00	
<b>Knob Cap (Top) – Master and Monitor (black w/white line, 11 mm)</b> (Order Code: 14255) <i>Note: Knob (top), knob cap (top), and knob (bottom) are sold separately. See 14253 for knob (top) and 14254 for knob (bottom).</i>		\$ 3.00	
<b>Knob (Bottom) – Master and Monitor (black w/white line, 15 mm)</b> (Order Code: 14254) <i>Note: Knob (top), knob cap (top), and knob (bottom) are sold separately. See 14253 for knob (top) and 14255 for knob cap (top).</i>		\$ 4.00	
<b>Power Supply (universal AC mains input/12 V, 1.25 A (15 watts) output)</b> (Order Code: 10354) <i>Mfg. No.: Cincon CFM1502S; Digi-Key No.: 2034-3555-ND; Mouser No.: 418-CFM1502S</i>		\$35.00	
<hr/>			
<b>Model 750 Audio Mixer (Serial Numbers 00151 – 00400)</b>			
<b>Potentiometer – Mic/Line Input (dual-shaft, 3-section 10KB//50KA/50KA)</b> (Order Code: 2130)		\$16.00	
<b>Potentiometer – Stereo Line Input, Main, and Aux Outputs (dual-shaft 50KA/50KA)</b> (Order Code: 2131)		\$12.00	
<b>Potentiometer – Speaker and Phones (single-shaft, dual-section 10KA/10KA)</b> (Order Code: 2128)		\$ 8.00	
<b>Pushbutton Switch (push-push)</b> (Order Code: 12016)		\$ 3.00	
<b>Pushbutton Cap (illuminated, gray, 12.5 mm x 6.8 mm)</b> (Order Code: 14228)		\$ 3.00	
<b>Pushbutton Cap (gray, 5.5 mm square)</b> (Order Code: 14229)		\$ 1.50	
<b>Knob – Speaker and Phones (black w/white line, 16 mm)</b> (Order Code: 14231)		\$ 3.00	
<b>Knob Base– Inputs and Master (black w/white line, 16 mm)</b> (Order Code: 14233) <i>Note: Knob base and knob top are sold separately. See 14232 for knob top.</i>		\$ 3.00	
<b>Knob Top– Inputs and Master (black w/white line, 10.5 mm)</b> (Order Code: 14232) <i>Note: Knob base and knob top are sold separately. See 14233 for knob base.</i>		\$ 3.00	
<hr/>			
<b>Model 750 Audio Mixer (Serial Numbers 00401 – later)</b>			
<b>Potentiometer – Mic/Line Input (dual-shaft, 3-section 10KB//50KA/50KA)</b> (Order Code: 2130)		\$16.00	
<b>Potentiometer – Stereo Line Input, Main, and Aux Outputs (dual-shaft 50KA/50KA)</b> (Order Code: 2131)		\$12.00	
<b>Potentiometer – Speaker and Phones (single-shaft, dual-section 10KA/10KA)</b> (Order Code: 2128)		\$ 8.00	
<b>Pushbutton Switch (push-push)</b> (Order Code: 12016)		\$ 3.00	
<b>Pushbutton Cap (illuminated, gray, 12.5 mm x 6.8 mm)</b> (Order Code: 14228)		\$ 3.00	
<b>Pushbutton Cap (gray, 5.5 mm square)</b> (Order Code: 14229)		\$ 1.50	
<b>Knob – Speaker and Phones (black, 15 mm)</b> (Order Code: 2056) <i>Note: Knob and knob cap are sold separately. See 14252 for knob cap.</i>		\$ 3.00	
<b>Knob Cap – Speaker and Phones (gray w/black line, 15 mm)</b> (Order Code: 14252) <i>Note: Knob and knob cap are sold separately. See 2056 for knob.</i>		\$ 1.50	
<b>Knob Base – Inputs and Master (black w/white line, 15 mm)</b> (Order Code: 14249) <i>Note: Knob base, knob top, and knob cap are sold separately. See 14250 for knob top and 14251 for knob cap.</i>		\$ 3.00	
<b>Knob Top – Inputs and Master (black w/white line, push-on, 11 mm)</b> (Order Code: 14250) <i>Note: Knob base, knob top, and knob cap are sold separately. See 14249 for knob base and 14251 for knob cap.</i>		\$ 3.00	
<b>Knob Cap – Inputs and Master (gray w/black line, 11 mm)</b> (Order Code: 14251) <i>Note: Knob base, knob top, and knob cap are sold separately. See 14249 for knob base and 14250 for knob top.</i>		\$ 3.00	

	Qty	US List	Total
<b>Model 760-Series Central Controllers (all serial numbers)</b>			
<b>Power Supply Assembly (universal AC mains input/12 V, 1.25 A (15 watts) output)</b> (Order Code: 32226)		\$65.00	
Note: Replaces discontinued Pihong PSA15LN3-120-R power supply.			
<b>Model 761 Central Controller (all serial numbers)</b>			
<b>Capacitor (surface mount, aluminum electrolytic, 47 uF, 25 V)</b> (Order Code: 4975)		\$ 2.00	
Mfg. No.: Panasonic FK-Series, EEE-FK1E470P; Digi-Key No.: PCE3804, Mouser No. 667-EEE-FK1E470P Alternate, Mfg. No.: Nichicon UUD-Series, UUD1E470MCL1GS; Digi-Key No. 493-2273-2, Mouser No. 647-UUD1E470MCL Notes: For revision B circuit boards: C36, C73, C178, C193 (C193 is bypass for -15 volt DC rail and is most critical) For revision C circuit boards: C39, C76, C181, C196 (C196 is bypass for -15 volt DC rail and is most critical)			
<b>Model 780-Series Central Controllers (all serial numbers)</b>			
<b>Power Supply Assembly (universal AC mains input/12 V, 1.25 A (15 watts) output)</b> (Order Code: 32226)		\$65.00	
Note: Replaces discontinued Pihong PSA15LN3-120-R power supply.			
<b>Model 790 Control Console (all Serial Numbers)</b>			
<b>Pushbutton Switch (momentary)</b> (Order Code: 12055)		\$ 4.00	
Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND			
<b>Knob – Level (black, collet, 29 mm)</b> (Order Code: 14214)		\$ 7.00	
Note: Knob and knob cap are sold separately. See 14260 for knob cap.			
<b>Knob Cap – Level (black, 29 mm)</b> (Order Code: 14260)		\$ 2.00	
Note: Knob and knob cap are sold separately. See 14214 for knob.			
<b>Rotary Encoder Assembly – Level</b> (Order Code: 31378)		\$ 9.00	
<b>Self-Adhesive Rubber Bumpons (black, set of 4, 1/2" dia. by 0.138" tall)</b> (Order Code: 14028)		\$ 2.00	
<b>9-Pin Male D-Sub/9-Pin Male D-Sub Cable Assembly (overall length 25 feet/7.7 m)</b> (Order Code: 13179-20)		\$26.00	
<b>Model 792 Central Controller (all Serial Numbers)</b>			
<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287)		\$ 3.00	
Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.			
<b>Set Screw</b> (Order Code: 8210-1/8)		\$ 0.50	
Note: Set screw and knob are sold separately. See 14287 for knob.			
<b>Push-Pot Potentiometer Assembly (dual-section)</b> (Order Code: 32298)		\$ 9.00	
Note: Includes push-pot (2171) and sleeve (14297).			
<b>Power Supply (universal AC mains input/12 V, 1.8 A (20 watts) output)</b> (Order Code: 10355)		\$32.00	
Mfg. No.: Cincon CFM2002S; Digi-Key No.: 2034-3589-ND; Mouser No.: 418-CFM2002S			
<b>Model 793 Control Console (all Serial Numbers)</b>			
<b>Pushbutton Switch (momentary)</b> (Order Code: 12055)		\$ 4.00	
Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND			
<b>Knob – Level (black, collet, 29 mm)</b> (Order Code: 14214)		\$ 7.00	
Note: Knob and knob cap are sold separately. See 14260 for knob cap.			
<b>Knob Cap – Level (black, 29 mm)</b> (Order Code: 14260)		\$ 2.00	
Note: Knob and knob cap are sold separately. See 14214 for knob.			
<b>Rotary Encoder Assembly – Level</b> (Order Code: 12110)		\$ 9.00	
<b>Self-Adhesive Rubber Bumpons (black, set of 4, 1/2" dia. by 0.138" tall)</b> (Order Code: 14028)		\$ 2.00	
<b>9-Pin Male D-Sub/9-Pin Male D-Sub Cable Assembly (overall length 25 feet/7.7 m)</b> (Order Code: 13179-20)		\$26.00	
<b>Model 794-Series Central Controllers (all Serial Numbers)</b>			
<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287)		\$ 3.00	
Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.			
<b>Set Screw</b> (Order Code: 8210-1/8)		\$ 0.50	
Note: Set screw and knob are sold separately. See 14287 for knob.			
<b>Push-Pot Potentiometer Assembly (dual-section)</b> (Order Code: 32298)		\$ 9.00	
Note: Includes push-pot (2171) and sleeve (14297).			
<b>Power Supply (universal AC mains input/12 V, 1.8 A (20 watts) output)</b> (Order Code: 10355)		\$32.00	
Mfg. No.: Cincon CFM2002S; Digi-Key No.: 2034-3589-ND; Mouser No.: 418-CFM2002S			

	Qty	US List	Total
<b>Model 795 Control Console (all Serial Numbers)</b>			
<b>Pushbutton Switch (momentary)</b> (Order Code: 12055) <i>Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND</i>	_____	\$ 4.00	_____
<b>Knob – Level (black, collet, 29 mm)</b> (Order Code: 14214) <i>Note: Knob and knob cap are sold separately. See 14260 for knob cap.</i>	_____	\$ 7.00	_____
<b>Knob Cap – Level (black, 29 mm)</b> (Order Code: 14260) <i>Note: Knob and knob cap are sold separately. See 14214 for knob.</i>	_____	\$ 2.00	_____
<b>Rotary Encoder Assembly – Level</b> (Order Code: 12110)	_____	\$ 9.00	_____
<b>Self-Adhesive Rubber Bumpers (black, set of 4, 1/2" dia. by 0.138" tall)</b> (Order Code: 14028)	_____	\$ 2.00	_____
<b>9-Pin Male D-Sub/9-Pin Male D-Sub Cable Assembly (overall length 25 feet/7.7 m)</b> (Order Code: 13179-20)	_____	\$26.00	_____

---

**Model 5100-Series Broadcast Support Modules (all Serial Numbers)**

Contact Factory as Required

---

**Model 5202 Dante to Phones and Line Output Interface (all Serial Numbers)**

<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
<b>Push-Pot Potentiometer Assembly (dual-section)</b> (Order Code: 32298) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
<b>1/4" Phone Jack</b> (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
<b>Nut (plastic)</b> (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____

---

**Model 5204 Dual Line Input to Dante Interface (all Serial Numbers)**

<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
<b>Push-Pot Potentiometer Assembly (dual-section)</b> (Order Code: 32298) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
<b>3.5 mm Stereo Jack</b> (Order Code: 1198)	_____	\$ 3.00	_____

---

**Model 5304 Intercom Station (all Serial Numbers)**

<b>Knob – Glow (black w/clear center, 13 mm dia. x 13.8 mm tall)</b> (Order Code: 14340)	_____	\$ 5.00	_____
<b>Rotary Encoder (24-step w/switch, 21 mm overall length)</b> (Order Code: 12109)	_____	\$ 8.00	_____
<b>Pushbutton Switch (momentary, 17 mm x 17 mm)</b> (Order Code: 12106) <i>Note: Includes button cap and lens. See 32649 for replacement button cap and lens kit.</i>	_____	\$ 6.00	_____
<b>Button Cap and Lens Kit (includes four each button cap and frosted lens)</b> (Order Code: 32649)	_____	\$24.00	_____
<b>3.5 mm Stereo Jack</b> (Order Code: 1198)	_____	\$ 3.00	_____
<b>Rubber Bumper (black, set of 4, 1/2" dia. by 7/32" tall)</b> (Order Code: 14339) <i>Note: Bumpers and machine screws are sold separately. See 8032-5/16 for screws.</i>	_____	\$ 6.00	_____
<b>Machine Screw (SEMS, 4-40x5/16")</b> (Order Code: 8032-5/16) <i>Note: Machine screws and bumpers are sold separately. See 14339 for bumpers.</i>	_____	\$ 0.50	_____

---

	Qty	US List	Total
<b>Model 5312 Intercom Station (all Serial Numbers)</b>			
Knob – Glow (black w/clear center, 13 mm dia. x 13.8 mm tall) (Order Code: 14340)	_____	\$ 5.00	_____
Rotary Encoder (24-step w/switch, 21 mm overall length) (Order Code: 12109)	_____	\$ 8.00	_____
Pushbutton Switch (momentary, 17 mm x 17 mm) (Order Code: 12106)	_____	\$ 6.00	_____
<i>Note: Includes button cap and lens. See 32649 for replacement button cap and lens kit.</i>			
Button Cap and Lens Kit (includes four each button cap and frosted lens) (Order Code: 32649)	_____	\$24.00	_____
Loudspeaker (37 mm dia., 8 ohm) (Order Code: 10702)	_____	\$22.00	_____
<i>Mfg. No.: Visaton: BF37/2261; Parts Express No.: 292-655</i>			
Set Screw (Order Code: 8210-1/8)	_____	\$ 0.50	_____
<i>Note: For use with microphone bushing.</i>			
Power Supply (universal AC mains input/12 V, 2.5 A (30 watts) output) (Order Code: 10362)	_____	\$32.00	_____
<i>Mfg. No.: Mean Well MFM-30-12; Digi-Key No.: 1866-3418-ND; Mouser No.: 709-MFM30-12</i>			
<hr/>			
<b>Model 5330 Flex-Use Dante Audio Interface (all Serial Numbers)</b>			
Knob (black w/white line, 9 mm) (Order Code: 14287)	_____	\$ 3.00	_____
<i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>			
Set Screw (Order Code: 8210-1/8)	_____	\$ 0.50	_____
<i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>			
Push-Pot Potentiometer Assembly (dual-section) (Order Code: 32298)	_____	\$ 9.00	_____
<i>Note: Includes push-pot (2171) and sleeve (14297).</i>			
1/4" Phone Jack (Order Code: 1084)	_____	\$ 4.00	_____
<i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>			
Nut (plastic) (Order Code: 1090)	_____	\$ 1.50	_____
<i>Note: Nut is required for installation of 1/4" phone jack.</i>			
Power Supply (universal AC mains input/12 V, 1.25 A (15 watts) output) (Order Code: 10354)	_____	\$35.00	_____
<i>Mfg. No.: Cincon CFM1502S; Digi-Key No.: 2034-3555-ND; Mouser No.: 418-CFM1502S</i>			
3.5 mm Stereo Jack (Order Code: 1198)	_____	\$ 3.00	_____
<hr/>			
<b>Model 5364 Headset Interface (all Serial Numbers)</b>			
Rubber Bumper (black, set of 4, 1/2" dia. by 7/32" tall) (Order Code: 14339)	_____	\$ 6.00	_____
<i>Note: Bumpers and machine screws are sold separately. See 8032-5/16 for screws.</i>			
Machine Screw (SEMS, 4-40x5/16") (Order Code: 8032-5/16)	_____	\$ 0.50	_____
<i>Note: Machine screws and bumpers are sold separately. See 14339 for bumpers.</i>			
<hr/>			
<b>Model 5365 Headset Interface (all Serial Numbers)</b>			
Rubber Bumper (black, set of 4, 1/2" dia. by 7/32" tall) (Order Code: 14339)	_____	\$ 6.00	_____
<i>Note: Bumpers and machine screws are sold separately. See 8032-5/16 for screws.</i>			
Machine Screw (SEMS, 4-40x5/16") (Order Code: 8032-5/16)	_____	\$ 0.50	_____
<i>Note: Machine screws and bumpers are sold separately. See 14339 for bumpers.</i>			
<hr/>			
<b>Model 5401 Dante Master Clock (all Serial Numbers)</b>			
Power Supply (universal AC mains input/12 V, 1.25 A (15 watts) output) (Order Code: 10354)	_____	\$35.00	_____
<i>Mfg. No.: Cincon CFM1502S; Digi-Key No.: 2034-3555-ND; Mouser No.: 418-CFM1502S</i>			
<hr/>			
<b>Model 5401A Dante Leader Clock (all Serial Numbers)</b>			
Power Supply (universal AC mains input/12 V, 1.25 A (15 watts) output) (Order Code: 10354)	_____	\$35.00	_____
<i>Mfg. No.: Cincon CFM1502S; Digi-Key No.: 2034-3555-ND; Mouser No.: 418-CFM1502S</i>			
<hr/>			
<b>Model 5402 Dante Leader Clock with GNSS Synchronization (all Serial Numbers)</b>			
Power Supply (universal AC mains input/12 V, 1.25 A (15 watts) output) (Order Code: 10354)	_____	\$35.00	_____
<i>Mfg. No.: Cincon CFM1502S; Digi-Key No.: 2034-3555-ND; Mouser No.: 418-CFM1502S</i>			
GNSS Antenna (Order Code: ANT-GNSS-01)	_____	\$92.00	_____
<i>Mfg. No.: U-Blox ANN-MB-00-00; Digi-Key No.: 672-ANN-MB-00-00-ND</i>			
<hr/>			
<b>Model 5412-Series Audio Interfaces (all Serial Numbers)</b>			
Power Supply (universal AC mains input/12 V, 1.8 A (20 watts) output) (Order Code: 10355)	_____	\$32.00	_____
<i>Mfg. No.: Cincon CFM2002S; Digi-Key No.: 2034-3589-ND; Mouser No.: 418-CFM2002S</i>			

	Qty	US List	Total
<b>Model 5414 Mic/Line Input &amp; Line Output Interface</b>			
<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
<b>Pushbutton Switch (momentary) – Channel Select</b> (Order Code: 12056)	_____	\$ 4.00	_____
<b>Pushbutton Cap (gray)</b> (Order Code: 14207)	_____	\$ 3.00	_____
<b>1/4" Phone Jack</b> (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
<b>Nut (plastic)</b> (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
<b>Power Supply (universal AC mains input/12 V, 1.25 A (15 watts) output)</b> (Order Code: 10354) <i>Mfg. No.: Cincon CFM1502S; Digi-Key No.: 2034-3555-ND; Mouser No.: 418-CFM1502S</i>	_____	\$35.00	_____
<b>For Serial Numbers 00151-01150</b>			
<b>Push-Pot Potentiometer Assembly (dual-section)</b> (Order Code: 32298) <i>Note: Includes push-pot (2171) and sleeve (14297).</i>	_____	\$ 9.00	_____
<b>For Serial Numbers 01151-later</b>			
<b>Push-Pot Potentiometer Assembly (single-section)</b> (Order Code: 32299) <i>Note: Includes push-pot (2172) and sleeve (14297).</i>	_____	\$ 9.00	_____
<hr/>			
<b>MD-4 Mic/Line Input &amp; Line Output Interface (all Serial Numbers)</b>			
<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>	_____	\$ 3.00	_____
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
<b>Push-Pot Potentiometer Assembly (single-section)</b> (Order Code: 32299) <i>Note: Includes push-pot (2172) and sleeve (14297).</i>	_____	\$ 9.00	_____
<b>Pushbutton Switch (momentary) – Channel Select</b> (Order Code: 12056)	_____	\$ 4.00	_____
<b>Pushbutton Cap (gray)</b> (Order Code: 14207)	_____	\$ 3.00	_____
<b>1/4" Phone Jack</b> (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
<b>Nut (plastic)</b> (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
<b>Power Supply (universal AC mains input/12 V, 1.25 A (15 watts) output)</b> (Order Code: 10354) <i>Mfg. No.: Cincon CFM1502S; Digi-Key No.: 2034-3555-ND; Mouser No.: 418-CFM1502S</i>	_____	\$35.00	_____
<hr/>			
<b>Model 5418 Mic/Line Interface (Serial Numbers 00151 – 00500)</b>			
<b>Pushbutton Cap (gray)</b> (Order Code: 14207)	_____	\$ 3.00	_____
<b>1/4" Phone Jack</b> (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
<b>Nut (plastic)</b> (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
<b>Power Supply (universal AC mains input/12 V, 1.8 A (20 watts) output)</b> (Order Code: 10355) <i>Mfg. No.: Cincon CFM2002S; Digi-Key No.: 2034-3589-ND; Mouser No.: 418-CFM2002S</i>	_____	\$32.00	_____
<hr/>			
<b>Model 5418 Mic/Line Interface (Serial Numbers 00501 – later)</b>			
<b>Pushbutton Cap (gray)</b> (Order Code: 14207)	_____	\$ 3.00	_____
<b>1/4" Phone Jack</b> (Order Code: 1084) <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
<b>Nut (plastic)</b> (Order Code: 1090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
<b>Power Supply (universal AC mains input/12 V, 2.5 A (30 watts) output)</b> (Order Code: 10362) <i>Mfg. No.: Mean Well MFM-30-12; Digi-Key No.: 1866-3418-ND; Mouser No.: 709-MFM30-12</i>	_____	\$32.00	_____
<hr/>			
<b>Model 5421 Dante Intercom Audio Engine (all Serial Numbers)</b>			
<b>Screw-On Bumper Kit (black, set of 8)</b> (Order Code: 31064)	_____	\$10.00	_____

	Qty	US List	Total
<b>Model 5422-Series Dante Audio Intercom Engines (all Serial Numbers)</b>			
<b>Power Supply (universal AC mains input/12 V, 1.25 A (15 watts) output) (Order Code: 10354)</b> <i>Mfg. No.: Cincon CFM1502S; Digi-Key No.: 2034-3555-ND; Mouser No.: 418-CFM1502S</i>	_____	\$35.00	_____
<b>Model 5422A-Series Dante Audio Intercom Engines (all Serial Numbers)</b>			
<b>Power Supply (universal AC mains input/12 V, 1.25 A (15 watts) output) (Order Code: 10354)</b> <i>Mfg. No.: Cincon CFM1502S; Digi-Key No.: 2034-3555-ND; Mouser No.: 418-CFM1502S</i>	_____	\$35.00	_____
<b>Model 5482-Series Dante Bridges (Serial Numbers 00151 – 00400)</b>			
<b>Power Supply (universal AC mains input/12 V, 1.25 A (15 watts) output) (Order Code: 10354)</b> <i>Mfg. No.: Cincon CFM1502S; Digi-Key No.: 2034-3555-ND; Mouser No.: 418-CFM1502S</i>	_____	\$35.00	_____
<b>Model 5482-Series Dante Bridges (Serial Numbers 00401 – later)</b>			
<b>Power Supply (universal AC mains input/12 V, 2.5 A (30 watts) output) (Order Code: 10362)</b> <i>Mfg. No.: Mean Well MFM-30-12; Digi-Key No.: 1866-3418-ND; Mouser No.: 709-MFM30-12</i>	_____	\$32.00	_____
<b>Model 5512-Series Audio Interfaces (all Serial Numbers)</b>			
<b>Power Supply (universal AC mains input/12 V, 1.8 A (20 watts) output) (Order Code: 10355)</b> <i>Mfg. No.: Cincon CFM2002S; Digi-Key No.: 2034-3589-ND; Mouser No.: 418-CFM2002S</i>	_____	\$32.00	_____
<b>Model 5512A-Series Audio Interfaces (all Serial Numbers)</b>			
<b>Power Supply (universal AC mains input/12 V, 1.8 A (20 watts) output) (Order Code: 10355)</b> <i>Mfg. No.: Cincon CFM2002S; Digi-Key No.: 2034-3589-ND; Mouser No.: 418-CFM2002S</i>	_____	\$32.00	_____
<b>Model 5518 Mic/Line Interface (Serial Numbers 00151 – 00500)</b>			
<b>Pushbutton Cap (gray) (Order Code: 14207)</b>	_____	\$ 3.00	_____
<b>1/4" Phone Jack (Order Code: 1084)</b> <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
<b>Nut (plastic) (Order Code: 1090)</b> <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
<b>Power Supply (universal AC mains input/12 V, 1.8 A (20 watts) output) (Order Code: 10355)</b> <i>Mfg. No.: Cincon CFM2002S; Digi-Key No.: 2034-3589-ND; Mouser No.: 418-CFM2002S</i>	_____	\$32.00	_____
<b>Model 5518 Mic/Line Interface (Serial Numbers 00501 – later)</b>			
<b>Pushbutton Cap (gray) (Order Code: 14207)</b>	_____	\$ 3.00	_____
<b>1/4" Phone Jack (Order Code: 1084)</b> <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
<b>Nut (plastic) (Order Code: 1090)</b> <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
<b>Power Supply (universal AC mains input/12 V, 2.5 A (30 watts) output) (Order Code: 10362)</b> <i>Mfg. No.: Mean Well MFM-30-12; Digi-Key No.: 1866-3418-ND; Mouser No.: 709-MFM30-12</i>	_____	\$32.00	_____
<b>Model 5518A Mic/Line Interface (all Serial Numbers)</b>			
<b>Pushbutton Cap (gray) (Order Code: 14207)</b>	_____	\$ 3.00	_____
<b>1/4" Phone Jack (Order Code: 1084)</b> <i>Note: Nut is required for installation of 1/4" phone jack. See 1090 for nut.</i>	_____	\$ 4.00	_____
<b>Nut (plastic) (Order Code: 1090)</b> <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
<b>Power Supply (universal AC mains input/12 V, 2.5 A (30 watts) output) (Order Code: 10362)</b> <i>Mfg. No.: Mean Well MFM-30-12; Digi-Key No.: 1866-3418-ND; Mouser No.: 709-MFM30-12</i>	_____	\$32.00	_____
<b>Model 5682-Series ST 2110 to Dante Bridges (All Serial Numbers)</b>			
<b>Power Supply (universal AC mains input/12 V, 2.5 A (30 watts) output) (Order Code: 10362)</b> <i>Mfg. No.: Mean Well MFM-30-12; Digi-Key No.: 1866-3418-ND; Mouser No.: 709-MFM30-12</i>	_____	\$32.00	_____

	Qty	US List	Total
<b>Live-Link Sr. Remote Camera Interface Systems (all Serial Numbers)</b>			
<b>Live-Link Sr. Portable Cover Assembly for Anton-Bauer Battery</b> (Order Code: LL-COVER-01) <i>Note: Consists of portable cover (31341) with lifting handle (32204), Anton-Bauer Bracket Kit (31414), and bumpers (32297) installed.</i>	_____	\$303.00	_____
<b>Portable Cover</b> (Order Code: 31341) <i>Note: Does not include lifting handle, battery bracket, bumpers, or hardware.</i>	_____	\$150.00	_____
<b>Lifting Handle Kit (black lifting handle and set of 6 6-32x1/4" screws)</b> (Order Code: 32204)	_____	\$ 26.00	_____
<b>Anton-Bauer Battery Bracket Kit (battery bracket w/insulator and 15" cable assembly)</b> (Order Code: 31414)	_____	\$115.00	_____
<b>Back of Cover Bumper Kit (set of 4 each 3/4" dia. by 5/8" tall bumpers, 10-24x3/4" screws, and 10-24 nylock nuts)</b> (Order Code: 32297) <i>Note: Used for back of portable enclosure.</i>	_____	\$ 12.00	_____
<b>Live-Link Sr. Cover for Special Installations</b> (Order Code: LL-COVER-02) <i>Note: Consists only of protective cover (31351) with no provision for attaching lifting handle, battery bracket, or bumpers.</i>	_____	\$150.00	_____
<b>Live-Link Sr. Portable Cover Assembly for V-Mount Battery</b> (Order Code: LL-COVER-03) <i>Note: Consists of portable cover (modified 31341) with lifting handle (32204), V-Mount Bracket (14301), and bumpers (32297) installed.</i>	_____	\$303.00	_____
<b>Chassis Bumper Kit (set of 4 each 1.5" dia. by 3/4" tall bumpers, 80918-.708 screws, and 1/4-20 Keps nuts)</b> (Order Code: 32203) <i>Note: Used for bottom of portable enclosure.</i>	_____	\$ 16.00	_____
<b>12 Vdc, 5 A Power Supply (output terminated onto 4-pin female XLR connector)</b> (Order Code: PS-DC-01)	_____	\$110.00	_____
<b>Audio Cable (XLR5M to XLR3F/XLR3M)</b> (Order Code: 13662)	_____	\$ 42.00	_____
<b>10/100/1000 Ethernet Media Converter Upgrade Kit</b> (Order Code: M432-KIT)	_____	\$240.00	_____
<b>Live-Link Jr. Remote Camera Interface Systems (all Serial Numbers)</b>			
<b>Pushbutton Switch (momentary) – Auto Null</b> (Order Code: 12056)	_____	\$ 4.00	_____
<b>Pushbutton Cap – Truck End Auto Null (gray)</b> (Order Code: 14207)	_____	\$ 3.00	_____
<b>Chassis Bumper Kit (set of 4 each 3/4" dia. by 3/8" tall bumpers and 6-32x3/8" screws)</b> (Order Code: 32202) <i>Note: Used for bottom of portable enclosure.</i>	_____	\$ 12.00	_____
<b>Lifting Handle Kit (black lifting handle and set of 6 6-32x1/4" screws)</b> (Order Code: 32204)	_____	\$ 26.00	_____
<b>12 Vdc, 1.55 A Power Supply (output terminated onto 4-pin female XLR connector)</b> (Order Code: PS-DC-02)	_____	\$ 88.00	_____
<b>Live-Link Mini Remote Camera Interface Systems (all Serial Numbers)</b>			
<b>Pushbutton Switch (momentary) – Auto Null</b> (Order Code: 12056)	_____	\$ 4.00	_____
<b>Pushbutton Cap – Camera End and Truck End Auto Null (gray)</b> (Order Code: 14207)	_____	\$ 3.00	_____
<b>Chassis Bumper Kit (set of 4 each 5/8" dia. by 3/4" tall bumpers and 6-32x5/8" screws)</b> (Order Code: 32205) <i>Note: Used for bottom of portable enclosure.</i>	_____	\$ 12.00	_____
<b>Lifting Handle Kit (black lifting handle and set of 6 6-32x1/4" screws)</b> (Order Code: 32204)	_____	\$ 26.00	_____
<b>12 Vdc, 1.55 A Power Supply (output terminated onto 4-pin female XLR connector)</b> (Order Code: PS-DC-02)	_____	\$ 88.00	_____
<b>Audio Cable (XLR5F to Dual XLR3M)</b> (Order Code: 13684)	_____	\$ 42.00	_____

	Qty	US List	Total
<b>Live-Link Miscellaneous Parts (contact factory for part identification assistance)</b>			
<b>BNC-BNC Bulkhead Connector (with nut and lockwasher)</b> (Order Code: 1243) <i>Note: 1310 nm FP Laser; MSA, supports 3G SDI video. Mfg. No.: Eoptolink EOLS-1330-10D.</i>		\$ 10.00	
<b>ST-ST Optical Barrel Connector (with nut and lockwasher)</b> (Order Code: 1260)		\$ 6.00	
<b>SFP Optical Module (video, transceiver)</b> (Order Code: 6406)		\$184.00	
<b>SFP Optical Module (video, transceiver)</b> (Order Code: 6412) <i>Note: 1550 nm CWDM Laser; MSA, supports 3G SDI video. Mfg. No.: Eoptolink EOLS-1630-18D0.</i>		\$290.00	
<b>SFP Optical Module (video, single-channel receiver)</b> (Order Code: 6411) <i>Note: Non-MSA, supports 3G SDI video. Mfg. No.: Eoptolink EOLS-30R-DN.</i>		\$156.00	
<b>SFP Optical Module (video, single-channel transmitter)</b> (Order Code: 6413) <i>Note: 1530 nm CWDM Laser; non-MSA, supports 3G SDI video. Mfg. No.: Eoptolink EOLS-1630T-DNN.</i>		\$210.00	
<b>SFP Optical Module (Ethernet, transceiver)</b> (Order Code: 6418) <i>Note: 1490 nm CWDM laser, MSA, supports 10/100/1000 Ethernet. Mfg. No.: ATOP APSC49123CXL40.</i>		\$ 85.00	
<b>Optical Multiplexer ("mux") (3 inputs/1 output)</b> (Order Code: 10826) <i>Note: 1310, 1490, and 1550 nm inputs use LC optical connectors; output uses ST optical connector.</i>		\$ 70.00	
<b>Optical Demultiplexer ("demux") (1 input/3 outputs)</b> (Order Code: 10827) <i>Note: Input uses ST optical connector; 1310, 1490, and 1550 nm outputs use LC optical connectors.</i>		\$ 95.00	
<b>Optical Multiplexer ("mux") (3 inputs/1 output)</b> (Order Code: 10833) <i>Note: 1310, 1490, and 1550 nm inputs use LC connectors; output uses LC optical connector.</i>		\$ 70.00	
<b>Optical Demultiplexer ("demux") (1 input/3 outputs)</b> (Order Code: 10834) <i>Note: Input uses LC optical connector, 1310, 1490, and 1550 nm outputs use LC optical connectors.</i>		\$ 95.00	
<b>Optical Multiplexer ("mux") (4 inputs/1 output)</b> (Order Code: 10831) <i>Note: 1310, 1490, 1530, and 1550 nm inputs use LC optical connectors; output uses ST optical connector.</i>		\$105.00	
<b>Optical Demultiplexer ("demux") (1 input/4 outputs)</b> (Order Code: 10832) <i>Note: Input uses ST optical connector; 1310, 1490, 1530, and 1550 nm outputs use LC optical connectors.</i>		\$120.00	
<b>Optical Demultiplexer ("demux") (1 input/6 outputs)</b> (Order Code: 10853) <i>Note: Input uses ST optical connector; 1310, 1470, 1490, 1510, 1530, and 1550 nm outputs use LC optical connectors.</i>		\$160.00	
<b>Optical Jumper Cable (single-mode, length 280 mm overall)</b> (Order Code: 10845) <i>Note: LC optical connectors on both ends.</i>		\$ 9.00	
<b>Optical Jumper Cable (single-mode, length 300 mm overall)</b> (Order Code: 10846) <i>Note: LC optical connector on one end, ST optical connector on other end.</i>		\$ 9.00	
<b>Miscellaneous Parts</b>			
<b>Knob (black w/white line, 9 mm)</b> (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>		\$ 3.00	
<b>Knob (blue w/no line, 9 mm)</b> (Order Code: 14310) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>		\$ 3.00	
<b>Knob (green w/no line, 9 mm)</b> (Order Code: 14311) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>		\$ 3.00	
<b>Knob (gold w/no line, 9 mm)</b> (Order Code: 14312) <i>Note: Knob and set screw are sold separately. See 8210-1/8 for set screw.</i>		\$ 3.00	
<b>Set Screw</b> (Order Code: 8210-1/8) <i>Note: Set screw and knob are sold separately.</i>		\$ 0.50	

**Notes:**

Prices effective January 15, 2025. Subject to change without notice. All shipments FOB Skokie, IL 60077 USA.