


Model 5512A-01/-02 Front-Panel Menu Structure

Button-Controlled Menus



1. For menu rows 2-5, screen saver automatically activates two minutes after last button press.
2. Press Left and Right buttons simultaneously to immediately enter screen saver mode.
3. Pressing Enter while screen saver is active goes to Current Management IP Address page.