



Replacement Parts List

All prices effective August 28, 2025. Subject to change without notice. Parts availability subject to factory stock levels. Certain parts may become obsolete without notice.

Table of Contents

Page	Product	Page	Product
3	Model 2 Central Controller	11	Model 76 Central Controller
3	Model 2A Central Controller	11	Model 76B Central Controller
3	Model 22 Access Station	11	Model 76D Central Controller
3	Model 24 Access Station	11	Model 76DA Central Controller
4	Model 32 Talent Amplifier	11	Model 77 Control Console
4	Model 32A Talent Amplifier	11	Model 77B Control Console
4	Model 33 Talent Amplifier	11	Model 79 Control Console
5	Model 33A Talent Amplifier	12	Model 92 DT12 Cable Assembly Test Unit
5	Model 34 Talent Amplifier	12	Model 93 W1 Cable Assembly Test Unit
5	Model 35 Talent Amplifier	12	Model 201 Interpreter's Console
6	Model 36 Talent Interface	12	Models 203, 204, 205, and 206 Announcer's Consoles
6	Model 37 Intercom Beltpack	12	Model 207 eSports Console
6	Model 41 Interface	13	Model 207A eSports Console
7	Model 42A Interface	13	Model 208 Announcer's Console
7	Model 43D IFB Interface	13	Model 209 Talent Console
7	Model 44D Audio Interface	14	Models 210, 211, 212, 220, 230, and 233 Announcer's Consoles
7	Model 45 Interface	14	Models 214, 215, and 216 Announcer's Consoles
7	Model 45A Interface	15	Models 214A, 215A, and 216A Announcer's Consoles
7	Model 45DC Intercom Interface	15	Models 232, 234, and 236 Announcer's Consoles
7	Model 45DR Intercom Interface	16	Model 240 Producer's Console
7	Model 46 Interface	16	Model 342 Intercom Station
7	Model 46A Interface	16	Model 348 Intercom Station
8	Model 47 Interface	17	Model 352A Talk Station
8	Model 47A Interface	17	Model 354 Talk Station
8	Model 48D Dante Bridge	17	Model 354A Talk Station
8	Model 51 Control Console	17	GME-3-12 Gooseneck Microphone
8	Model 56 Control Console	18	Model 362 Listen-Only Beltpack
8	Models 59 and 591 Control Consoles	18	Model 362A Listen-Only Beltpack
9	Model 60 Central Controller	18	Model 370 Intercom Beltpack
9	Model 60A Central Controller	19	Model 370A Intercom Beltpack
9	Model 61 Control Console	19	Model 371 Intercom Beltpack
10	Model 69 Control Console	19	Model 371A Intercom Beltpack
10	Model 69A Control Console	20	Model 372A Intercom Beltpack
10	Model 71 Control Console	20	Model 373A Intercom Beltpack
10	Model 72 Level Meter / Interface	20	Model 374 Intercom Beltpack
10	Model 74 Central Controller	20	Model 374A Intercom Beltpack
10	Model 75 Control Console		

Table of Contents

Page	Product	Page	Product
21	Model 380 On-Air Beltpack	31	Model 5414 Mic/Line Input & Line Output Interface
21	Model 381 On-Air Beltpack	31	MD-4 Mic/Line Input & Line Output Interface
21	Model 391 Dante Alerting Unit	31	Model 5418 Mic/Line Interface
21	Model 392 Visual Indicator Unit	31	Model 5421 Dante Intercom Audio Engine
22	Model 394 GPI Interface	31	Model 5421A Dante Intercom Audio Engine
22	Model 395 GPO Interface	32	Model 5422-Series Dante Intercom Audio Engines
23	Model 400 SDI-Over-Fiber Transport Systems	32	Model 5422A-Series Dante Intercom Audio Engines
23	Model 400A SDI-Over-Fiber Transport Systems	32	Model 5482-Series Dante Bridges
24	Model 410 SDI-Over-Fiber Transport Systems	32	Model 5512-Series Audio Interfaces
24	Model 412 Fiber Transport Systems	32	Model 5512A-Series Audio Interfaces
25	Model 543D IFB Interface	32	Model 5518 Mic/Line Interface
25	Model 544D Audio Interface	32	Model 5518A Mic/Line Interface
25	Model 545AC Intercom Interface	33	Models 5532, 5534, and 5536 Announcer's Consoles
25	Model 545AR Intercom Interface	33	Model 5682-Series ST 2110 to Dante Bridges
25	Model 545DC Intercom Interface	34	Live-Link Sr. Remote Camera Interface Systems
25	Model 545DR Intercom Interface	34	Live-Link Jr. Remote Camera Interface Systems
25	Model 742 Audio Mixer	34	Live-Link Mini Remote Camera Interface Systems
26	Model 742A Audio Mixer	35	Live-Link Miscellaneous Parts
26	Model 750 Audio Mixer	35	Miscellaneous Parts
27	Model 760-Series Central Controllers		
27	Model 761 Central Controller		
27	Model 780-Series Central Controllers		
27	Model 790 Control Console		
27	Model 791 Control Console		
27	Model 792 Central Controller		
28	Model 793 Control Console		
28	Model 794-Series Central Controllers		
28	Model 795 Control Console		
29	Model 5100-Series Broadcast Support Modules		
29	Model 5202 Dante to Phones & Line Output Interface		
29	Model 5204 Dual Line Input to Dante Interface		
29	Model 5304 Intercom Station		
29	Model 5312 Intercom Station		
30	Model 5330 Flex-Use Dante Audio Interface		
30	Model 5364 Headset Interface		
30	Model 5365 Headset Interface		
30	Model 5401 Dante Master Clock		
30	Model 5401A Dante Leader Clock		
30	Model 5402 Dante Leader Clock with GNSS Synchronization		
30	Model 5412-Series Audio Interfaces		

	Qty	US List	Total
Model 2 Central Controller (all Serial Numbers)			
Knob – Program and Monitor Output (black, push-on, 15 mm) (Order Code: 02056) <i>Note: Knob and knob cap are sold separately. See 02057 for knob cap.</i>	_____	\$ 3.00	_____
Knob Cap – Program and Monitor Output (black w/white line, 15 mm) (Order Code: 02057) <i>Note: Knob and knob cap are sold separately. See 02056 for knob.</i>	_____	\$ 1.50	_____
Pushbutton Cap (gray) (Order Code: 12050) <i>Mfg. No.: E-Switch TACGRY; Digi-Key No.: EG1082-ND</i>	_____	\$ 4.00	_____
Potentiometer – Program 1, Program 2, Monitor Output (Order Code: 02126)	_____	\$ 4.00	_____
Pushbutton Switch (momentary) – IFB 1, IFB 2 (Order Code: 12064)	_____	\$ 4.00	_____
Pushbutton Switch Assembly (6-position, interlock) – Program Select (Order Code: 12036)	_____	\$12.00	_____
Toggle Switch – VOX IFB Input Select (Order Code: 12054)	_____	\$26.00	_____
Toggle Switch – VOX IFB Output Select (Order Code: 12052)	_____	\$22.00	_____
Toggle Switch (momentary) – Telco 1, Telco 2, Manual Off-Hook/Hang-Up Select (Order Code: 12053)	_____	\$22.00	_____
Toggle Switch – Telco 2 Send/Rcv and Monitor Source Select (Order Code: 12051)	_____	\$22.00	_____
Pushbutton Switch (push-push) – Telco Std/Wet 1, Telco Std/Wet 2 (Order Code: 12016)	_____	\$ 3.00	_____
Model 2A Central Controller (all Serial Numbers)			
Knob – Program and Monitor Output (black, push-on, 15 mm) (Order Code: 02056) <i>Note: Knob and knob cap are sold separately. See 02057 for knob cap.</i>	_____	\$ 3.00	_____
Knob Cap – Program and Monitor Output (black w/white line, 15 mm) (Order Code: 02057) <i>Note: Knob and knob cap are sold separately. See 02056 for knob.</i>	_____	\$ 1.50	_____
Pushbutton Cap (gray) (Order Code: 12050) <i>Mfg. No.: E-Switch TACGRY; Digi-Key No.: EG1082-ND</i>	_____	\$ 4.00	_____
Potentiometer – Program 1, Program 2, Monitor Output (Order Code: 02126)	_____	\$ 4.00	_____
Pushbutton Switch (momentary) – IFB 1, IFB 2 (Order Code: 12064)	_____	\$ 4.00	_____
Pushbutton Switch Assembly (6-position, interlock) – Program Select Order Code: 12036)	_____	\$12.00	_____
Toggle Switch (momentary) – Telco 1, Telco 2, Manual Off-Hook/Hang Up Select (Order Code: 12093)	_____	\$ 9.00	_____
Toggle Switch – VOX IFB, Telco 2 Send/Rcv, Monitor Source Select (Order Code: 12091)	_____	\$ 9.00	_____
Pushbutton Switch (push-push) – Telco Std/Wet 1, Telco Std/Wet 2 (Order Code: 12016)	_____	\$ 3.00	_____
Power Supply (universal AC mains input/12 V, 3.34 A (40 watts) output) (Order Code: 10303) <i>Mfg. No.: Cincon CFM40S120; Digi-Key No.: 2034-3674-ND; Mouser No.: 418-CFM40S120</i>	_____	\$45.00	_____
Model 22 Access Station (all Serial Numbers)			
Pushbutton Switch (momentary, Mfg. by EAO) (Order Code: 12028) <i>Note: Does not include button cap, lens, or label. See 31069.</i>	_____	\$14.00	_____
Button Cap, Lenses, and Label Kit (includes five each button cap, clear lens, frosted lens, and one button function label sheet (15154)) (Order Code: 31069)	_____	\$40.00	_____
Backlight Lamp (T1, 18 V, incandescent) (Order Code: 12030)	_____	\$ 4.00	_____
Model 24 Access Station (all Serial Numbers)			
Pushbutton Switch (momentary, Mfg. by EAO) (Order Code: 12028) <i>Note: Does not include button cap, lens, or label. See 31069.</i>	_____	\$14.00	_____
Button Cap, Lenses, and Label Kit (includes five each button cap, clear lens, frosted lens, and one button function label sheet (15154)) (Order Code: 31069)	_____	\$40.00	_____
Backlight Lamp (T1, 18 V, incandescent) (Order Code: 12030)	_____	\$ 4.00	_____

	Qty	US List	Total
Model 32 Talent Amplifier (Serial Numbers 00001 – 00299)			
Knob (black, push-on, 15 mm) (Order Code: 02056)	_____	\$ 3.00	_____
<i>Note: Knob and knob cap are sold separately. See 02057 for knob cap.</i>			
Knob Cap (black w/white line, 15 mm) (Order Code: 02057)	_____	\$ 1.50	_____
<i>Note: Knob and knob cap are sold separately. See 02056 for knob.</i>			
Potentiometer (Order Code: 02148)	_____	\$ 4.00	_____
Toggle Switch – Ch 1/2 Select (Order Code: 12021)	_____	\$ 6.00	_____
3-Pin Male XLR Connector (Order Code: 01093)	_____	\$ 7.00	_____
3-Pin Female XLR Connector (Order Code: 01094)	_____	\$ 8.00	_____
1/4" Phone Jack (Order Code: 01053)	_____	\$ 7.00	_____
Belt Clip (black, steel) (Order Code: 30247)	_____	\$ 5.00	_____
Pop-Rivet – for Belt Clip (black, aluminum, 0.125" grip) (Order Code: 08201-.125)	_____	\$ 1.00	_____
Model 32 Talent Amplifier (Serial Numbers 00300 – later)			
Knob (black, push-on, 15 mm) (Order Code: 02056)	_____	\$ 3.00	_____
<i>Note: Knob and knob cap are sold separately. See 02057 for knob cap.</i>			
Knob Cap (black w/white line, 15 mm) (Order Code: 02057)	_____	\$ 1.50	_____
<i>Note: Knob and knob cap are sold separately. See 02056 for knob.</i>			
Potentiometer (Order Code: 02148)	_____	\$ 4.00	_____
Toggle Switch – Ch 1/2 Select (Order Code: 12021)	_____	\$ 6.00	_____
3-Pin Male XLR Connector (Order Code: 01093)	_____	\$ 7.00	_____
3-Pin Female XLR Connector (Order Code: 01094)	_____	\$ 8.00	_____
1/4" Phone Jack (Order Code: 01086)	_____	\$ 4.00	_____
Belt Clip (black, steel) (Order Code: 30247)	_____	\$ 5.00	_____
Pop-Rivet – for Belt Clip (black, aluminum, 0.125" grip) (Order Code: 08201-.125)	_____	\$ 1.00	_____
Model 32A Talent Amplifier (all Serial Numbers)			
Knob (black, push-on, 15 mm) (Order Code: 02056)	_____	\$ 3.00	_____
<i>Note: Knob and knob cap are sold separately. See 02057 for knob cap.</i>			
Knob Cap (black w/white line, 15 mm) (Order Code: 02057)	_____	\$ 1.50	_____
<i>Note: Knob and knob cap are sold separately. See 02056 for knob.</i>			
Potentiometer (Order Code: 02148)	_____	\$ 4.00	_____
Toggle Switch – Ch 1/2 Select (Order Code: 12021)	_____	\$ 6.00	_____
3-Pin Male XLR Connector (Order Code: 01093)	_____	\$ 7.00	_____
3-Pin Female XLR Connector (Order Code: 01094)	_____	\$ 8.00	_____
1/4" Phone Jack (Order Code: 01084)	_____	\$ 4.00	_____
<i>Note: Nut is required for installation of 1/4" phone jack. See 01090 for nut.</i>			
Nut (plastic) (Order Code: 01090)	_____	\$ 1.50	_____
<i>Note: Nut is required for installation of 1/4" phone jack.</i>			
3.5 mm Stereo Jack (Order Code: 01198)	_____	\$ 3.00	_____
Belt Clip (black, steel) (Order Code: 30247)	_____	\$ 5.00	_____
Pop-Rivet – for Belt Clip (black, aluminum, 0.125" grip) (Order Code: 08201-.125)	_____	\$ 1.00	_____
Model 33 Talent Amplifier (all Serial Numbers)			
Knob – Ch 1 and Ch 2 (black, push-on, 15 mm) (Order Code: 02056)	_____	\$ 3.00	_____
<i>Note: Knob and knob cap are sold separately. See 02057 for knob cap.</i>			
Knob Cap – Ch 1 and Ch 2 (black w/white line, 15 mm) (Order Code: 02057)	_____	\$ 1.50	_____
<i>Note: Knob and knob cap are sold separately. See 02056 for knob.</i>			
Potentiometer – Ch 1 and Ch 2 (Order Code: 02148)	_____	\$ 4.00	_____
Toggle Switch – Ch 1/2 Select (Order Code: 12063)	_____	\$ 9.00	_____
3-Pin Male XLR Connector (Order Code: 01093)	_____	\$ 7.00	_____
3-Pin Female XLR Connector (Order Code: 01094)	_____	\$ 8.00	_____
1/4" Phone Jack (Order Code: 01084)	_____	\$ 4.00	_____
<i>Note: Nut is required for installation of 1/4" phone jack. See 01090 for nut.</i>			
Nut (plastic) (Order Code: 01090)	_____	\$ 1.50	_____
<i>Note: Nut is required for installation of 1/4" phone jack.</i>			
Belt Clip (black, steel) (Order Code: 30247)	_____	\$ 5.00	_____
Pop-Rivet – for Belt Clip (black, aluminum, 0.125" grip) (Order Code: 08201-.125)	_____	\$ 1.00	_____

	Qty	US List	Total
Model 33A Talent Amplifier (all Serial Numbers)			
Knob – Ch 1 and Ch 2 (black, push-on, 15 mm) (Order Code: 02056) <i>Note: Knob and knob cap are sold separately. See 02057 for knob cap.</i>	_____	\$ 3.00	_____
Knob Cap – Ch 1 and Ch 2 (black w/white line, 15 mm) (Order Code: 02057) <i>Note: Knob and knob cap are sold separately. See 02056 for knob.</i>	_____	\$ 1.50	_____
Potentiometer – Ch 1 and Ch 2 (Order Code: 02148)	_____	\$ 4.00	_____
Toggle Switch – Ch 1/2 Select (Order Code: 12063)	_____	\$ 9.00	_____
3-Pin Male XLR Connector (Order Code: 01093)	_____	\$ 7.00	_____
3-Pin Female XLR Connector (Order Code: 01094)	_____	\$ 8.00	_____
1/4" Phone Jack (Order Code: 01084) <i>Note: Nut is required for installation of 1/4" phone jack. See 01090 for nut.</i>	_____	\$ 4.00	_____
Nut (plastic) (Order Code: 01090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
3.5 mm Stereo Jack (Order Code: 01198)	_____	\$ 3.00	_____
Belt Clip (black, steel) (Order Code: 30247)	_____	\$ 5.00	_____
Pop-Rivet – for Belt Clip (black, aluminum, 0.125" grip) (Order Code: 08201-.125)	_____	\$ 1.00	_____
Model 34 Talent Amplifier (all Serial Numbers)			
Knob – Ch 1/Left and Ch 2/Right (black, push-on, 15 mm) (Order Code: 02056) <i>Note: Knob and knob cap are sold separately. See 02057 for knob cap.</i>	_____	\$ 3.00	_____
Knob Cap – Ch 1/Left and Ch 2/Right (black w/white line, 15 mm) (Order Code: 02057) <i>Note: Knob and knob cap are sold separately. See 02056 for knob.</i>	_____	\$ 1.50	_____
Potentiometer – Ch 1/Left and Ch 2/Right (Order Code: 02148)	_____	\$ 4.00	_____
Toggle Switch – Output Mic/Stereo Select (Order Code: 12021)	_____	\$ 6.00	_____
3-Pin Female XLR Connector (Order Code: 01094)	_____	\$ 8.00	_____
1/4" Phone Jack (Order Code: 01084) <i>Note: Nut is required for installation of 1/4" phone jack. See 01090 for nut.</i>	_____	\$ 4.00	_____
Nut (plastic) (Order Code: 01090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
3.5 mm Stereo Jack (Order Code: 01198)	_____	\$ 3.00	_____
Belt Clip (black, steel) (Order Code: 30247)	_____	\$ 5.00	_____
Pop-Rivet – for Belt Clip (black, aluminum, 0.125" grip) (Order Code: 08201-.125)	_____	\$ 1.00	_____
Model 35 Talent Amplifier (Serial Numbers 00001 – 00385)			
Knob (black, push-on, 15 mm) (Order Code: 02056) <i>Note: Knob and knob cap are sold separately. See 02057 for knob cap.</i>	_____	\$ 3.00	_____
Knob Cap (black w/white line, 15 mm) (Order Code: 02057) <i>Note: Knob and knob cap are sold separately. See 02056 for knob.</i>	_____	\$ 1.50	_____
Potentiometer (Order Code: 02124)	_____	\$ 5.00	_____
Pushbutton Switch (push-push) – Stereo/Mono (Order Code: 12016)	_____	\$ 3.00	_____
Pushbutton Cap (gray) (Order Code: 12015)	_____	\$ 3.00	_____
3-Pin Male XLR Connector (Order Code: 01093)	_____	\$ 7.00	_____
3-Pin Female XLR Connector (Order Code: 01094)	_____	\$ 8.00	_____
Dual 1/4" Phone Jack (Order Code: 01087)	_____	\$ 6.00	_____
Self-Adhesive Rubber Bumpons (black, set of 4, 1/2" dia. by 0.138" tall) (Order Code: 14028)	_____	\$ 2.00	_____
Model 35 Talent Amplifier (Serial Numbers 00386 – later)			
Knob (black, push-on, 15 mm) (Order Code: 02056) <i>Note: Knob and knob cap are sold separately. See 02057 for knob cap.</i>	_____	\$ 3.00	_____
Knob Cap (black w/white line, 15 mm) (Order Code: 02057) <i>Note: Knob and knob cap are sold separately. See 02056 for knob.</i>	_____	\$ 1.50	_____
Potentiometer (Order Code: 02124)	_____	\$ 5.00	_____
Pushbutton Switch (push-push) – Stereo/Mono (Order Code: 12016)	_____	\$ 3.00	_____
Pushbutton Cap (gray) (Order Code: 12015)	_____	\$ 3.00	_____
3-Pin Male XLR Connector (Order Code: 01093)	_____	\$ 7.00	_____
3-Pin Female XLR Connector (Order Code: 01094)	_____	\$ 8.00	_____
Dual 1/4" Phone Jack (Order Code: 01113)	_____	\$ 7.00	_____
Self-Adhesive Rubber Bumpons (black, set of 4, 1/2" dia. by 0.138" tall) (Order Code: 14028)	_____	\$ 2.00	_____

	Qty	US List	Total
Model 36 Talent Interface (all Serial Numbers)			
Knob (black, push-on, 15 mm) (Order Code: 02056) <i>Note: Knob and knob cap are sold separately. See 02057 for knob cap.</i>	_____	\$ 3.00	_____
Knob Cap (black w/white line, 15 mm) (Order Code: 02057) <i>Note: Knob and knob cap are sold separately. See 02056 for knob.</i>	_____	\$ 1.50	_____
Potentiometer (Order Code: 02148)	_____	\$ 4.00	_____
1/4" Phone Jack (Order Code: 01084) <i>Note: Nut is required for installation of 1/4" phone jack. See 01090 for nut.</i>	_____	\$ 4.00	_____
Nut (plastic) (Order Code: 01090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
3.5 mm Stereo Jack (Order Code: 01198)	_____	\$ 3.00	_____
5-Pin Headset Connector Assembly (Order Code: 13579)	_____	\$56.00	_____
6-Pin Headset Connector Assembly (Order Code: 13595)	_____	\$56.00	_____
7-Pin Headset Connector Assembly (Order Code: 13561)	_____	\$56.00	_____
Belt Clip (black, steel) (Order Code: 30247)	_____	\$ 5.00	_____
Pop-Rivet – for Belt Clip (black, aluminum, 0.125" grip) (Order Code: 08201-.125)	_____	\$ 1.00	_____
Model 37 Intercom Beltpack (all Serial Numbers)			
Knob – Main and Aux (black, push-on, 15 mm) (Order Code: 02056) <i>Note: Knob and knob cap are sold separately. See 02057 for knob cap.</i>	_____	\$ 3.00	_____
Knob Cap – Main and Aux (black w/white line, 15 mm) (Order Code: 02057) <i>Note: Knob and knob cap are sold separately. See 02056 for knob.</i>	_____	\$ 1.50	_____
Potentiometer – Main and Aux (Order Code: 02148)	_____	\$ 4.00	_____
Toggle Switch – Mic On Select (on/off/mom) (Order Code: 12088)	_____	\$ 6.00	_____
Power Entry & Aux Audio Input Kit (Order Code: M37-MK-01)	_____	\$84.00	_____
Belt Clip (black, steel) (Order Code: 30247)	_____	\$ 5.00	_____
Pop-Rivet – for Belt Clip (black, aluminum, 0.125" grip) (Order Code: 08201-.125)	_____	\$ 1.00	_____
Model 41 Interface (Serial Numbers 00151 – 01050)			
Knob (black, push-on, 15 mm) (Order Code: 02056) <i>Note: Knob and knob cap are sold separately. See 02057 for knob cap.</i>	_____	\$ 3.00	_____
Knob Cap (black, w/white line, 15 mm) (Order Code: 02057) <i>Note: Knob and knob cap are sold separately. See 02056 for knob.</i>	_____	\$ 1.50	_____
Potentiometer (Order Code: 02166)	_____	\$ 4.00	_____
1/4" Phone Jack (Order Code: 01084) <i>Note: Nut is required for installation of 1/4" phone jack. See 01090 for nut.</i>	_____	\$ 4.00	_____
Nut (plastic) (Order Code: 01090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
Pushbutton Cap (gray) (Order Code: 14229)	_____	\$ 1.50	_____
Model 41 Interface (Serial Numbers 01051 – later)			
Knob (black, push-on, 15 mm) (Order Code: 02056) <i>Note: Knob and knob cap are sold separately. See 02057 for knob cap.</i>	_____	\$ 3.00	_____
Knob Cap (black w/white line, 15 mm) (Order Code: 02057) <i>Note: Knob and knob cap are sold separately. See 02056 for knob.</i>	_____	\$ 1.50	_____
Potentiometer (Order Code: 02166)	_____	\$ 4.00	_____
1/4" Phone Jack (Order Code: 01084) <i>Note: Nut is required for installation of 1/4" phone jack. See 01090 for nut.</i>	_____	\$ 4.00	_____
Nut (plastic) (Order Code: 01090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
Pushbutton Cap (gray) (Order Code: 14229)	_____	\$ 1.50	_____

	Qty	US List	Total
Model 42A Interface (all Serial Numbers)			
Knob (black, push-on, 15 mm) (Order Code: 02056)	_____	\$ 3.00	_____
<i>Note: Knob and knob cap are sold separately. See 02057 for knob cap.</i>			
Knob Cap (black w/white line, 15 mm) (Order Code: 02057)	_____	\$ 1.50	_____
<i>Note: Knob and knob cap are sold separately. See 02056 for knob.</i>			
Potentiometer (Order Code: 02166)	_____	\$ 4.00	_____
1/4" Phone Jack (Order Code: 01084)	_____	\$ 4.00	_____
<i>Note: Nut is required for installation of 1/4" phone jack. See 01090 for nut.</i>			
Nut (plastic) (Order Code: 01090)	_____	\$ 1.50	_____
<i>Note: Nut is required for installation of 1/4" phone jack.</i>			
Pushbutton Cap (gray) (Order Code: 14229)	_____	\$ 1.50	_____
Model 43D IFB Interface (all Serial Numbers)			
4-Position DIP Switch (Order Code: 12071)	_____	\$ 5.00	_____
Screw-On Bumper Kit (black, set of 8) (Order Code: 31064)	_____	\$10.00	_____
Model 44D Audio Interface (all Serial Numbers)			
4-Position DIP Switch (Order Code: 12071)	_____	\$ 5.00	_____
Screw-On Bumper Kit (black, set of 8) (Order Code: 31064)	_____	\$10.00	_____
Model 45 Interface (all Serial Numbers)			
5-Position DIP Switch (Order Code: 12069)	_____	\$ 6.00	_____
Pushbutton Switch (momentary) – Auto Null (Order Code: 12056)	_____	\$ 4.00	_____
Pushbutton Cap (gray) (Order Code: 14207)	_____	\$ 3.00	_____
Screw-On Bumper Kit (black, set of 8) (Order Code: 31064)	_____	\$10.00	_____
24 Vdc, 0.75 A Power Supply (output terminated onto 2.1 x 5.5 mm locking coaxial jack) (Order Code: PS-DC-03)	_____	\$46.00	_____
Model 45A Interface (all Serial Numbers)			
5-Position DIP Switch (Order Code: 12069)	_____	\$ 6.00	_____
Pushbutton Switch (momentary) – Auto Null (Order Code: 12056)	_____	\$ 4.00	_____
Pushbutton Cap (gray) (Order Code: 14207)	_____	\$ 3.00	_____
Screw-On Bumper Kit (black, set of 8) (Order Code: 31064)	_____	\$10.00	_____
24 Vdc, 0.75 A Power Supply (output terminated onto 2.1 x 5.5 mm locking coaxial jack) (Order Code: PS-DC-03)	_____	\$46.00	_____
Model 45DC Intercom Interface (all Serial Numbers)			
4-Position DIP Switch (Order Code: 12071)	_____	\$ 5.00	_____
Pushbutton Switch (momentary) – Auto Null (Order Code: 12056)	_____	\$ 4.00	_____
Pushbutton Cap (gray) (Order Code: 14207)	_____	\$ 3.00	_____
Screw-On Bumper Kit (black, set of 8) (Order Code: 31064)	_____	\$10.00	_____
Model 45DR Intercom Interface (all Serial Numbers)			
4-Position DIP Switch (Order Code: 12071)	_____	\$ 5.00	_____
Pushbutton Switch (momentary) – Auto Null (Order Code: 12056)	_____	\$ 4.00	_____
Pushbutton Cap (gray) (Order Code: 14207)	_____	\$ 3.00	_____
Screw-On Bumper Kit (black, set of 8) (Order Code: 31064)	_____	\$10.00	_____
Model 46 Interface (all Serial Numbers)			
4-Position DIP Switch (Order Code: 12071)	_____	\$ 5.00	_____
Pushbutton Switch (momentary) – Auto Null (Order Code: 12056)	_____	\$ 4.00	_____
Pushbutton Cap (gray) (Order Code: 14207)	_____	\$ 3.00	_____
Model 46A Interface (all Serial Numbers)			
4-Position DIP Switch (Order Code: 12071)	_____	\$ 5.00	_____
Pushbutton Switch (momentary) – Auto Null (Order Code: 12056)	_____	\$ 4.00	_____
Pushbutton Cap (gray) (Order Code: 14207)	_____	\$ 3.00	_____

	Qty	US List	Total
Model 47 Interface (all Serial Numbers)			
4-Position DIP Switch (Order Code: 12071)	_____	\$ 5.00	_____
Pushbutton Switch (momentary) – Auto Null (Order Code: 12056)	_____	\$ 4.00	_____
Pushbutton Cap (gray) (Order Code: 14207)	_____	\$ 3.00	_____
Model 47A Interface (all Serial Numbers)			
4-Position DIP Switch (Order Code: 12071)	_____	\$ 5.00	_____
Pushbutton Switch (momentary) – Auto Null (Order Code: 12056)	_____	\$ 4.00	_____
Pushbutton Cap (gray) (Order Code: 14207)	_____	\$ 3.00	_____
Model 48D Dante Bridge (all Serial Numbers)			
Screw-On Bumper Kit (black, set of 8) (Order Code: 31064)	_____	\$10.00	_____
Model 51 Control Console (all Serial Numbers)			
Pushbutton Switch (momentary) (Order Code: 12055) Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND	_____	\$ 4.00	_____
Knob – Studio Level (black, push-on, 15 mm) (Order Code: 02056) Note: Knob and knob cap are sold separately. See 02057 for knob cap.	_____	\$ 3.00	_____
Knob Cap – Studio Level (black w/white line, 15 mm) (Order Code: 02057) Note: Knob and knob cap are sold separately. See 02056 for knob.	_____	\$ 1.50	_____
Potentiometer – Studio Level (Order Code: 02054)	_____	\$12.00	_____
Knob – Control Room Level (black, collet, 47 mm) (Order Code: 14205) Note: Knob and knob cap are sold separately. See 14206 for knob cap.	_____	\$18.00	_____
Knob Cap – Control Room Level (black w/white line, 47 mm) (Order Code: 14206) Note: Knob and knob cap are sold separately. See 14205 for knob.	_____	\$ 4.00	_____
Potentiometer – Control Room Level (Order Code: 02122)	_____	\$12.00	_____
Self-Adhesive Rubber Bumpers (black, set of 4, 1/2" dia. by 0.138" tall) (Order Code: 14028)	_____	\$ 2.00	_____
Model 56 Control Console (all Serial Numbers)			
Pushbutton Switch (momentary) (Order Code: 12055) Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND	_____	\$ 4.00	_____
Knob – Control Room Level (black, collet, 38 mm) (Order Code: 14209) Note: Knob and knob cap are sold separately. See 14210 for knob cap.	_____	\$14.00	_____
Knob Cap – Control Room Level (black w/white line, 38 mm) (Order Code: 14210) Note: Knob and knob cap are sold separately. See 14209 for knob.	_____	\$ 3.00	_____
Potentiometer – Control Room Level (Order Code: 02123)	_____	\$ 5.00	_____
Self-Adhesive Rubber Bumpers (black, set of 4, 1/2" dia. by 0.138" tall) (Order Code: 14028)	_____	\$ 2.00	_____
Model 59 and Model 591 Control Consoles (all Serial Numbers)			
Pushbutton Switch (momentary) (Order Code: 12055) Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND	_____	\$ 4.00	_____
Knob – Control Room Level (black, collet, 38 mm) (Order Code: 14209) Note: Knob and knob cap are sold separately. See 14210 for knob cap.	_____	\$14.00	_____
Knob Cap – Control Room Level (black w/white line, 38 mm) (Order Code: 14210) Note: Knob and knob cap are sold separately. See 14209 for knob.	_____	\$ 3.00	_____
Potentiometer – Control Room Level (Order Code: 02123)	_____	\$ 5.00	_____
Self-Adhesive Rubber Bumpers (black, set of 4, 1/2" dia. by 0.138" tall) (Order Code: 14028)	_____	\$ 2.00	_____

	Qty	US List	Total
Model 60 Central Controller (Serial Numbers 00200 – 00300)			
1/4" Phone Jack (Order Code: 01086)	_____	\$ 4.00	_____
Dual 1/4" Phone Jack (Order Code: 01087)	_____	\$ 6.00	_____
Knob – Level (black, push-on, 15 mm) (Order Code: 02056)	_____	\$ 3.00	_____
<i>Note: Knob and knob cap are sold separately. See 02057 for knob cap.</i>			
Knob Cap – Level (black w/white line, 15 mm) (Order Code: 02057)	_____	\$ 1.50	_____
<i>Note: Knob and knob cap are sold separately. See 02056 for knob.</i>			
Potentiometer – Phones Level and Dub Level (Order Code: 02128)	_____	\$ 8.00	_____
Pushbutton Switch (push-push) (Order Code: 12016)	_____	\$ 3.00	_____
Pushbutton Switch Assembly (4-station) – Source (Order Code: 12061)	_____	\$16.00	_____
Pushbutton Cap (gray) (Order Code: 12050)	_____	\$ 4.00	_____
<i>Mfg. No.: E-Switch TACGRY; Digi-Key No.: EG1082-ND</i>			
Model 60 Central Controller (Serial Numbers 00301 – later)			
1/4" Phone Jack (Order Code: 01084)	_____	\$ 4.00	_____
<i>Note: Nut is required for installation of 1/4" phone jack. See 01090 for nut.</i>			
Nut (plastic) (Order Code: 01090)	_____	\$ 1.50	_____
<i>Note: Nut is required for installation of 1/4" phone jack.</i>			
Dual 1/4" Phone Jack (Order Code: 01113)	_____	\$ 7.00	_____
Knob – Level (black, push-on, 15 mm) (Order Code: 02056)	_____	\$ 3.00	_____
<i>Note: Knob and knob cap are sold separately. See 02057 for knob cap.</i>			
Knob Cap – Level (black w/white line, 15 mm) (Order Code: 02057)	_____	\$ 1.50	_____
<i>Note: Knob and knob cap are sold separately. See 02056 for knob.</i>			
Potentiometer – Phones Level and Dub Level (Order Code: 02128)	_____	\$ 8.00	_____
Pushbutton Switch (push-push) (Order Code: 12016)	_____	\$ 3.00	_____
Pushbutton Switch Assembly (4-station) – Source (Order Code: 12061)	_____	\$16.00	_____
Pushbutton Cap (gray) (Order Code: 12050)	_____	\$ 4.00	_____
<i>Mfg. No.: E-Switch TACGRY; Digi-Key No.: EG1082-ND</i>			
Model 60A Central Controller (all Serial Numbers)			
1/4" Phone Jack (Order Code: 01084)	_____	\$ 4.00	_____
<i>Note: Nut is required for installation of 1/4" phone jack. See 01090 for nut.</i>			
Nut (plastic) (Order Code: 01090)	_____	\$ 1.50	_____
<i>Note: Nut is required for installation of 1/4" phone jack.</i>			
Dual 1/4" Phone Jack (Order Code: 01168)	_____	\$ 7.00	_____
Knob – Level (black, push-on, 15 mm) (Order Code: 02056)	_____	\$ 3.00	_____
<i>Note: Knob and knob cap are sold separately. See 02057 for knob cap.</i>			
Knob Cap – Level (black w/white line, 15 mm) (Order Code: 02057)	_____	\$ 1.50	_____
<i>Note: Knob and knob cap are sold separately. See 02056 for knob.</i>			
Potentiometer – Phones Level and Dub Level (Order Code: 02128)	_____	\$ 8.00	_____
Pushbutton Switch (push-push) (Order Code: 12016)	_____	\$ 3.00	_____
Pushbutton Switch Assembly (4-station) – Source (Order Code: 12061)	_____	\$16.00	_____
Pushbutton Switch Assembly (3-station) – Switcher (Order Code: 12074)	_____	\$12.00	_____
Pushbutton Cap (gray) (Order Code: 12050)	_____	\$ 4.00	_____
<i>Mfg. No.: E-Switch TACGRY; Digi-Key No.: EG1082-ND</i>			
Model 61 Control Console (all Serial Numbers)			
Pushbutton Switch (momentary) (Order Code: 12055)	_____	\$ 4.00	_____
<i>Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND</i>			
Knob – Level (black, collet, 29 mm) (Order Code: 14214)	_____	\$ 7.00	_____
<i>Note: Knob and knob cap are sold separately. See 14215 for knob cap.</i>			
Knob Cap – Level (black w/white line, 29 mm) (Order Code: 14215)	_____	\$ 3.00	_____
<i>Note: Knob and knob cap are sold separately. See 14209 for knob.</i>			
Potentiometer – Level (Order Code: 02123)	_____	\$ 5.00	_____
Self-Adhesive Rubber Bumpons (black, set of 4, 1/2" dia. by 0.138" tall) (Order Code: 14028)	_____	\$ 2.00	_____
9-Pin Male D-Sub/9-Pin Male D-Sub Cable Assembly (overall length 25 feet/7.7 m)	_____	\$26.00	_____
<i>(Order Code: 13179-20)</i>			

	Qty	US List	Total
Model 69 Control Console (all Serial Numbers)			
Pushbutton Switch (momentary) (Order Code: 12055) <i>Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND</i>	_____	\$ 4.00	_____
Knob – Level (black, collet, 38 mm) (Order Code: 14209) <i>Note: Knob and knob cap are sold separately. See 14210 for knob cap.</i>	_____	\$14.00	_____
Knob Cap – Level (black w/white line, 38 mm) (Order Code: 14210) <i>Note: Knob and knob cap are sold separately. See 14209 for knob.</i>	_____	\$ 3.00	_____
Potentiometer – Level (Order Code: 02123)	_____	\$ 5.00	_____
Self-Adhesive Rubber Bumpers (black, set of 4, 1/2" dia. by 0.138" tall) (Order Code: 14028)	_____	\$ 2.00	_____
9-Pin Male D-Sub/9-Pin Male D-Sub Cable Assembly (overall length 25 feet/7.7 m) (Order Code: 13179-20)	_____	\$26.00	_____
Model 69A Control Console (all Serial Numbers)			
Pushbutton Switch (momentary) (Order Code: 12055) <i>Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND</i>	_____	\$ 4.00	_____
Knob – Level (black, collet, 38 mm) (Order Code: 14209) <i>Note: Knob and knob cap are sold separately. See 14210 for knob cap.</i>	_____	\$14.00	_____
Knob Cap – Level (black w/white line, 38 mm) (Order Code: 14210) <i>Note: Knob and knob cap are sold separately. See 14209 for knob.</i>	_____	\$ 3.00	_____
Potentiometer – Level (Order Code: 02123)	_____	\$ 5.00	_____
Self-Adhesive Rubber Bumpers (black, set of 4, 1/2" dia. by 0.138" tall) (Order Code: 14028)	_____	\$ 2.00	_____
9-Pin Male D-Sub/9-Pin Male D-Sub Cable Assembly (overall length 25 feet/7.7 m) (Order Code: 13179-20)	_____	\$26.00	_____
Model 71 Control Console (all Serial Numbers)			
Pushbutton Switch (momentary) (Order Code: 12055) <i>Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND</i>	_____	\$ 4.00	_____
Knob – Level (black, collet, 29 mm) (Order Code: 14214) <i>Note: Knob and knob cap are sold separately. See 14260 for knob cap.</i>	_____	\$ 7.00	_____
Knob Cap – Level (black, 29 mm) (Order Code: 14260) <i>Note: Knob and knob cap are sold separately. See 14214 for knob.</i>	_____	\$ 2.00	_____
Rotary Encoder – Level (Order Code: 12034)	_____	\$ 4.00	_____
Self-Adhesive Rubber Bumpers (black, set of 4, 1/2" dia. by 0.138" tall) (Order Code: 14028)	_____	\$ 2.00	_____
9-Pin Male D-Sub/9-Pin Male D-Sub Cable Assembly (overall length 25 feet/7.7 m) (Order Code: 13179-20)	_____	\$26.00	_____
Model 72 Level Meter / Interface (all Serial Numbers)			
Self-Adhesive Rubber Bumpers (black, set of 4, 1/2" dia. by 0.138" tall) (Order Code: 14028)	_____	\$ 2.00	_____
Model 74 Central Controller (all Serial Numbers)			
3.5 mm Jack (Order Code: 01315)	_____	\$ 4.00	_____
Model 75 Control Console (all Serial Numbers)			
Pushbutton Switch (momentary) (Order Code: 12055) <i>Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND</i>	_____	\$ 4.00	_____
Knob – Level (black, collet, 38 mm) (Order Code: 14209) <i>Note: Knob and knob cap are sold separately. See 14210 for knob cap.</i>	_____	\$14.00	_____
Knob Cap – Level (black w/white line, 38 mm) (Order Code: 14210) <i>Note: Knob and knob cap are sold separately. See 14209 for knob.</i>	_____	\$ 3.00	_____
Potentiometer Assembly – Level (Order Code: 32089)	_____	\$12.00	_____
Self-Adhesive Rubber Bumpers (black, set of 4, 1/2" dia. by 0.138" tall) (Order Code: 14028)	_____	\$ 2.00	_____
9-Pin Male D-Sub/9-Pin Male D-Sub Cable Assembly (overall length 25 feet/7.7 m) (Order Code: 13179-20)	_____	\$26.00	_____

	Qty	US List	Total
Model 76 Central Controller (all serial numbers)			
Capacitor (surface mount, aluminum electrolytic, 47 uF, 25 V) (Order Code: 04975)		\$ 2.00	
<i>Mfg. No.: Panasonic FK-Series, EEE-FK1E470P; Digi-Key No.: PCE3804, Mouser No. 667-EEE-FK1E470P</i>			
<i>Alternate, Mfg. No.: Nichicon UUD-Series, UUD1E470MCL1GS; Digi-Key No. 493-2273-2, Mouser No. 647-UUD1E470MCL</i>			
<i>Notes: For revision B circuit boards: C36, C73, C178, C193 (C193 is bypass for -15 volt DC rail and is most critical)</i>			
<i>For revision C circuit boards: C39, C76, C181, C196 (C196 is bypass for -15 volt DC rail and is most critical)</i>			
Model 76B Central Controller (all serial numbers)			
Capacitor (surface mount, aluminum electrolytic, 47 uF, 25 V) (Order Code: 04975)		\$ 2.00	
<i>Mfg. No.: Panasonic FK-Series, EEE-FK1E470P; Digi-Key No.: PCE3804, Mouser No. 667-EEE-FK1E470P</i>			
<i>Alternate, Mfg. No.: Nichicon UUD-Series, UUD1E470MCL1GS; Digi-Key No. 493-2273-2, Mouser No. 647-UUD1E470MCL</i>			
<i>Notes: For revision B circuit boards: C36, C73, C178, C193 (C193 is bypass for -15 volt DC rail and is most critical)</i>			
<i>For revision C circuit boards: C39, C76, C181, C196 (C196 is bypass for -15 volt DC rail and is most critical)</i>			
Model 76D Central Controller (all serial numbers)			
Power Supply Assembly (universal AC mains input/12 V, 1.25 A (15 watts) output)			
<i>(Order Code: 32226)</i>		\$65.00	
<i>Note: Replaces discontinued Phihong PSA15LN3-120-R power supply.</i>			
Model 76DA Central Controller (all serial numbers)			
Power Supply Assembly (universal AC mains input/12 V, 1.25 A (15 watts) output)			
<i>(Order Code: 32226)</i>		\$65.00	
<i>Note: Replaces discontinued Phihong PSA15LN3-120-R power supply.</i>			
Model 77 Control Console (all Serial Numbers)			
Pushbutton Switch (momentary) (Order Code: 12055)		\$ 4.00	
<i>Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND</i>			
Knob – Level (black, collet, 29 mm) (Order Code: 14214)		\$ 7.00	
<i>Note: Knob and knob cap are sold separately. See 14260 for knob cap.</i>			
Knob Cap – Level (black, 29 mm) (Order Code: 14260)		\$ 2.00	
<i>Note: Knob and knob cap are sold separately. See 14214 for knob.</i>			
Rotary Encoder Assembly – Level (Order Code: 31378)		\$ 9.00	
Self-Adhesive Rubber Bumpers (black, set of 4, 1/2" dia. by 0.138" tall) (Order Code: 14028)		\$ 2.00	
9-Pin Male D-Sub/9-Pin Male D-Sub Cable Assembly (overall length 25 feet/7.7 m)			
<i>(Order Code: 13179-20)</i>		\$26.00	
Model 77B Control Console (all Serial Numbers)			
Pushbutton Switch (momentary) (Order Code: 12055)		\$ 4.00	
<i>Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND</i>			
Knob – Level (black, collet, 29 mm) (Order Code: 14214)		\$ 7.00	
<i>Note: Knob and knob cap are sold separately. See 14260 for knob cap.</i>			
Knob Cap – Level (black, 29 mm) (Order Code: 14260)		\$ 2.00	
<i>Note: Knob and knob cap are sold separately. See 14214 for knob.</i>			
Rotary Encoder Assembly – Level (Order Code: 31378)		\$ 9.00	
Self-Adhesive Rubber Bumpers (black, set of 4, 1/2" dia. by 0.138" tall) (Order Code: 14028)		\$ 2.00	
9-Pin Male D-Sub/9-Pin Male D-Sub Cable Assembly (overall length 25 feet/7.7 m)			
<i>(Order Code: 13179-20)</i>		\$26.00	
Model 79 Control Console (all Serial Numbers)			
Pushbutton Switch (momentary) (Order Code: 12055)		\$ 4.00	
<i>Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND</i>			
Knob – Level (black, collet, 29 mm) (Order Code: 14214)		\$14.00	
<i>Note: Knob and knob cap are sold separately. See 14215 for knob cap.</i>			
Knob Cap – Level (black w/white line, 29 mm) (Order Code: 14215)		\$ 3.00	
<i>Note: Knob and knob cap are sold separately. See 14209 for knob.</i>			
Potentiometer – Level (Order Code: 02123)		\$ 5.00	
Self-Adhesive Rubber Bumpers (black, set of 4, 1/2" dia. by 0.138" tall) (Order Code: 14028)		\$ 2.00	
9-Pin Male D-Sub/9-Pin Male D-Sub Cable Assembly (overall length 25 feet/7.7 m)			
<i>(Order Code: 13179-20)</i>		\$26.00	

	Qty	US List	Total
Model 92 DT12 Cable Assembly Test Unit (all Serial Numbers)			
Rechargeable Battery, 12 V, 1.3 Ah (Order Code: 10335)			Not available from factory
Mfg. No.: Panasonic LC-R121R3P; Digi-Key No.: P264-ND			
Model 93 W1 Cable Assembly Test Unit (all Serial Numbers)			
Rechargeable Battery, 12 V, 1.3 Ah (Order Code: 10335)			Not available from factory
Mfg. No.: Panasonic LC-R121R3P; Digi-Key No.: P264-ND			
Model 201 Interpreter's Console (all Serial Numbers)			
Knob (black w/white line, 9 mm) (Order Code: 14287)		\$ 3.00	
Note: Knob and set screw are sold separately. See 08210-1/8 for set screw.			
Set Screw (Order Code: 08210-1/8)		\$ 0.50	
Note: Set screw and knob are sold separately. See 14287 for knob.			
Push-Pot Potentiometer Assembly (dual-section) (Order Code: 32298)		\$ 9.00	
Note: Includes push-pot (02171) and sleeve (14297).			
Pushbutton Switch (momentary, 17 mm x 17 mm) (Order Code: 12106)		\$ 6.00	
Note: Includes button cap and lens. See 32649 for replacement button cap and lens kit.			
Button Cap and Lens Kit (includes four each button cap and frosted lens) (Order Code: 32649)		\$24.00	
1/4" Phone Jack (Order Code: 01084)		\$ 4.00	
Note: Nut is required for installation of 1/4" phone jack. See 01090 for nut.			
Nut (plastic) (Order Code: 01090)		\$ 1.50	
Note: Nut is required for installation of 1/4" phone jack.			
3.5 mm Stereo Jack (Order Code: 01198)		\$ 3.00	
Self-Adhesive Rubber Bumpers (black, set of 4, 1/2" dia. by 0.138" tall) (Order Code: 14028)		\$ 2.00	
Model 203, Model 204, Model 205, and Model 206 Announcer's Consoles (all Serial Numbers)			
Knob (black w/white line, 9 mm) (Order Code: 14287)		\$ 3.00	
Note: Knob and set screw are sold separately. See 08210-1/8 for set screw.			
Set Screw (Order Code: 08210-1/8)		\$ 0.50	
Note: Set screw and knob are sold separately. See 14287 for knob.			
Push-Pot Potentiometer Assembly (dual-section) (Order Code: 32298)		\$ 9.00	
Note: Includes push-pot (02171) and sleeve (14297).			
Pushbutton Switch (momentary, 17 mm x 17 mm) (Order Code: 12106)		\$ 6.00	
Note: Includes button cap and lens. See 32649 for replacement button cap and lens kit.			
Button Cap and Lens Kit (includes four each button cap and frosted lens) (Order Code: 32649)		\$24.00	
1/4" Phone Jack (Order Code: 01084)		\$ 4.00	
Note: Nut is required for installation of 1/4" phone jack. See 01090 for nut.			
Nut (plastic) (Order Code: 01090)		\$ 1.50	
Note: Nut is required for installation of 1/4" phone jack.			
3.5 mm Stereo Jack (Order Code: 01198)		\$ 3.00	
Self-Adhesive Rubber Bumpers (black, set of 4, 1/2" dia. by 0.138" tall) (Order Code: 14028)		\$ 2.00	
Model 207 eSports Console (all Serial Numbers)			
Knob (black w/white line, 9 mm) (Order Code: 14287)		\$ 3.00	
Note: Knob and set screw are sold separately. See 08210-1/8 for set screw.			
Set Screw (Order Code: 08210-1/8)		\$ 0.50	
Note: Set screw and knob are sold separately. See 14287 for knob.			
Push-Pot Potentiometer Assembly (dual-section) (Order Code: 32298)		\$ 9.00	
Note: Includes push-pot (02171) and sleeve (14297).			
Pushbutton Switch (momentary, 17 mm x 17 mm) (Order Code: 12106)		\$ 6.00	
Note: Includes button cap and lens. See 32649 for replacement button cap and lens kit.			
Button Cap and Lens Kit (includes four each button cap and frosted lens) (Order Code: 32649)		\$24.00	
3.5 mm 4-Conductor (TRRS) Jack (Order Code: 01410)		\$ 5.00	
Self-Adhesive Rubber Bumpers (black, set of 4, 1/2" dia. by 1/4" tall) (Order Code: 14326)		\$ 3.00	

	Qty	US List	Total
Model 207A eSports Console (all Serial Numbers)			
Knob (black w/white line, 9 mm) (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 08210-1/8 for set screw.</i>	_____	\$ 3.00	_____
Set Screw (Order Code: 08210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
Push-Pot Potentiometer Assembly (dual-section) (Order Code: 32298) <i>Note: Includes push-pot (02171) and sleeve (14297).</i>	_____	\$ 9.00	_____
Pushbutton Switch (momentary, 17 mm x 17 mm) (Order Code: 12106) <i>Note: Includes button cap and lens. See 32649 for replacement button cap and lens kit.</i>	_____	\$ 6.00	_____
Button Cap and Lens Kit (includes four each button cap and frosted lens) (Order Code: 32649)	_____	\$24.00	_____
3.5 mm 4-Conductor (TRRS) Jack (Order Code: 01410)	_____	\$ 5.00	_____
Self-Adhesive Rubber Bumpers (black, set of 4, 1/2" dia. by 1/4" tall) (Order Code: 14326)	_____	\$ 3.00	_____
Model 208 Announcer's Console (all Serial Numbers)			
Knob (black w/white line, 9 mm) (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 08210-1/8 for set screw.</i>	_____	\$ 3.00	_____
Set Screw (Order Code: 08210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
Push-Pot Potentiometer Assembly (dual-section) (Order Code: 32298) <i>Note: Includes push-pot (02171) and sleeve (14297).</i>	_____	\$ 9.00	_____
Switch Cap Adapter (Order Code: 14294) <i>Note: Switch cap and switch cap adapter are sold separately. See 14295 for 12 mm switch cap.</i>	_____	\$ 1.50	_____
Switch Cap (12 mm) (Order Code: 14295) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____
1/4" Phone Jack (Order Code: 01084) <i>Note: Nut is required for installation of 1/4" phone jack. See 01090 for nut.</i>	_____	\$ 4.00	_____
Nut (plastic) (Order Code: 01090) <i>Note: For use with 1/4" phone jack.</i>	_____	\$ 1.50	_____
3.5 mm Stereo Jack (Order Code: 01198)	_____	\$ 3.00	_____
Model 209 Talent Console (all Serial Numbers)			
Knob – Glow (black w/clear center, 13 mm dia. x 13.8 mm tall) (Order Code: 14340)	_____	\$ 5.00	_____
Rotary Encoder (24-step w/switch, 21 mm overall length) (Order Code: 12109)	_____	\$ 8.00	_____
Pushbutton Switch (momentary, 17 mm x 17 mm) (Order Code: 12106) <i>Note: Includes button cap and lens. See 32649 for replacement button cap and lens kit.</i>	_____	\$ 6.00	_____
Button Cap and Lens Kit (includes four each button cap and frosted lens) (Order Code: 32649)	_____	\$24.00	_____
1/4" Phone Jack (Order Code: 01084) <i>Note: Nut is required for installation of 1/4" phone jack. See 01090 for nut.</i>	_____	\$ 4.00	_____
Nut (plastic) (Order Code: 01090) <i>Note: For use with 1/4" phone jack.</i>	_____	\$ 1.50	_____
3.5 mm Stereo Jack (Order Code: 01198)	_____	\$ 3.00	_____

	Qty	US List	Total
Model 210, Model 211, Model 212, Model 220, Model 230, and Model 233			
Announcer's Consoles (all Serial Numbers)			
Pushbutton Switch (momentary, Mfg. by EAO) (Order Code: 12028) <i>Note: Does not include button cap, lens, or label. See 31069.</i>	_____	\$14.00	_____
Button Cap, Lenses, and Label Kit (includes five each button cap, clear lens, frosted lens, and one button function label sheet (15154)) (Order Code: 31069)	_____	\$40.00	_____
Knob – Phones Level (black, push-on, 15 mm) (Order Code: 02056) <i>Note: Knob and knob cap are sold separately. See 02057 for knob cap.</i>	_____	\$ 3.00	_____
Knob Cap – Phones Level (black w/white line, 15 mm) (Order Code: 02057) <i>Note: Knob and knob cap are sold separately. See 02056 for knob.</i>	_____	\$ 1.50	_____
Potentiometer – Phones Level (Order Code: 02127)	_____	\$ 5.00	_____
1/4" Phone Jack (Order Code: 01084) <i>Note: Nut is required for installation of 1/4" phone jack. See 01090 for nut.</i>	_____	\$ 4.00	_____
Nut (plastic) (Order Code: 01090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
DC Power Entry Jack Assembly (includes PCB, washer, and nut) (Order Code: 32135) <i>Note: Requires cable assembly, sold separately. See 13690.</i>	_____	\$12.00	_____
Cable Assembly for DC Power Entry Jack Assembly (2-conductor, 5") (Order Code: 13690)	_____	\$ 4.00	_____
Blank Plate – XLR (black) (Order Code: 01073)	_____	\$ 3.00	_____
Model 210 Security Plate (Order Code: SP-M210)	_____	\$15.00	_____
Model 211 Security Plate (Order Code: SP-M211)	_____	\$15.00	_____
Model 212 Security Plate (Order Code: SP-M212)	_____	\$15.00	_____
Model 220 Security Plate (Order Code: SP-M220)	_____	\$18.00	_____
Model 230 Security Plate (Order Code: SP-M230)	_____	\$18.00	_____
Model 233 Security Plate (Order Code: SP-M233)	_____	\$18.00	_____
Screw-On Bumper Kit (black, set of 8) (Order Code: 31064)	_____	\$10.00	_____
24 Vdc, 0.75 A Power Supply (output terminated onto 2.1 x 5.5 mm locking coaxial jack) (Order Code: PS-DC-03)	_____	\$46.00	_____
Model 214, Model 215, and Model 216 Announcer's Consoles (all Serial Numbers)			
Pushbutton Switch Backlight LED (Order Code: 03154)	_____	\$ 3.00	_____
Pushbutton Switch (momentary, Mfg. by EAO) (Order Code: 12028) <i>Note: Does not include button cap, lens, or label. See 31069.</i>	_____	\$14.00	_____
Button Cap, Lenses, and Label Kit (includes five each button cap, clear lens, frosted lens, and one button function label sheet (15154)) (Order Code: 31069)	_____	\$40.00	_____
Knob – Phones Level (black, push-on, 15 mm) (Order Code: 02056) <i>Note: Knob and knob cap are sold separately. See 02057 for knob cap.</i>	_____	\$ 3.00	_____
Knob Cap – Phones Level (black w/white line, 15 mm) (Order Code: 02057) <i>Note: Knob and knob cap are sold separately. See 02056 for knob.</i>	_____	\$ 1.50	_____
Potentiometer – Phones Level (Order Code: 02127)	_____	\$ 5.00	_____
1/4" Phone Jack (Order Code: 01084) <i>Note: Nut is required for installation of 1/4" phone jack. See 01090 for nut.</i>	_____	\$ 4.00	_____
Nut (plastic) (Order Code: 01090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
Screw-On Bumper Kit (black, set of 8) (Order Code: 31064)	_____	\$10.00	_____
Blank Plate – XLR (black) (Order Code: 01073)	_____	\$ 3.00	_____
Model 214 Security Plate (Order Code: SP-M214)	_____	\$15.00	_____
Model 215 Security Plate (Order Code: SP-M215)	_____	\$15.00	_____
Model 216 Security Plate (Order Code: SP-M216)	_____	\$15.00	_____

	Qty	US List	Total
Model 214A, Model 215A, and Model 216A Announcer's Consoles (all Serial Numbers)			
Pushbutton Switch Backlight LED (Order Code: 03154)	_____	\$ 3.00	_____
Pushbutton Switch (momentary, Mfg. by EAO) (Order Code: 12028)	_____	\$14.00	_____
<i>Note: Does not include button cap, lens, or label. See 31069.</i>			
Button Cap, Lenses, and Label Kit (includes five each button cap, clear lens, frosted lens, and one button function label sheet (15154)) (Order Code: 31069)	_____	\$40.00	_____
Knob – Phones Level (black, push-on, 15 mm) (Order Code: 02056)	_____	\$ 3.00	_____
<i>Note: Knob and knob cap are sold separately. See 02057 for knob cap.</i>			
Knob Cap – Phones Level (black w/white line, 15 mm) (Order Code: 02057)	_____	\$ 1.50	_____
<i>Note: Knob and knob cap are sold separately. See 02056 for knob.</i>			
Potentiometer – Phones Level (Order Code: 02127)	_____	\$ 5.00	_____
1/4" Phone Jack (Order Code: 01084)	_____	\$ 4.00	_____
<i>Note: Nut is required for installation of 1/4" phone jack. See 01090 for nut.</i>			
Nut (plastic) (Order Code: 01090)	_____	\$ 1.50	_____
<i>Note: Nut is required for installation of 1/4" phone jack.</i>			
Screw-On Bumper Kit (black, set of 8) (Order Code: 31064)	_____	\$10.00	_____
Blank Plate – XLR (black) (Order Code: 01073)	_____	\$ 3.00	_____
Screw-On Bumper Kit (black, set of 8) (Order Code: 31064)	_____	\$10.00	_____
Model 232, Model 234, and Model 236 Announcer's Consoles			
Knob (black w/white line, 9 mm) (Order Code: 14287)	_____	\$ 3.00	_____
<i>Note: Knob and set screw are sold separately. See 08210-1/8 for set screw.</i>			
Set Screw (Order Code: 08210-1/8)	_____	\$ 0.50	_____
<i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>			
Push-Pot Potentiometer Assembly (dual-section) (Order Code: 32298)	_____	\$ 9.00	_____
<i>Note: Includes push-pot (02171) and sleeve (14297).</i>			
Pushbutton Switch (momentary, 17 mm x 17 mm) (Order Code: 12106)	_____	\$ 6.00	_____
<i>Note: Includes button cap and lens. See 32649 for replacement button cap and lens kit.</i>			
Button Cap and Lens Kit (includes four each button cap and frosted lens) (Order Code: 32649)	_____	\$24.00	_____
1/4" Phone Jack (Order Code: 01084)	_____	\$ 4.00	_____
<i>Note: Nut is required for installation of 1/4" phone jack. See 01090 for nut.</i>			
Nut (plastic) (Order Code: 01090) <i>Note: For use with 1/4" phone jack.</i>	_____	\$ 1.50	_____
Self-Adhesive Rubber Bumpers (black, set of 4, 1/2" dia. by 1/4" tall) (Order Code: 14326)	_____	\$ 3.00	_____
Blank Plate – XLR (black) (Order Code: 01073)	_____	\$ 3.00	_____
For Serial Numbers 00151-00274			
Knob – Glow (black w/clear center, 13 mm dia. x 17.8 mm tall) (Order Code: 14321)	_____	\$ 5.00	_____
Rotary Encoder (24-step w/switch, 25 mm overall length) (Order Code: 12103)	_____	\$ 8.00	_____
For Serial Numbers 00275-later			
Knob – Glow (black w/clear center, 13 mm dia. x 13.8 mm tall) (Order Code: 14340)	_____	\$ 5.00	_____
Rotary Encoder (24-step w/switch, 21 mm overall length) (Order Code: 12109)	_____	\$ 8.00	_____

	Qty	US List	Total
Model 240 Producer's Console (all Serial Numbers)			
Button Backlight LED (Order Code: 03154)	_____	\$ 3.00	_____
Pushbutton Switch (momentary, Mfg. by EAO) (Order Code: 12028) <i>Note: Does not include button cap, lens, or label. See 31069.</i>	_____	\$14.00	_____
Button Cap, Lenses, and Label Kit (includes five each button cap, clear lens, frosted lens, and one button function label sheet (15154)) (Order Code: 31069)	_____	\$40.00	_____
Knob – Phones Level (black, push-on, 15 mm) (Order Code: 02056) <i>Note: Knob and knob cap are sold separately. See 02057 for knob cap.</i>	_____	\$ 3.00	_____
Knob Cap – Phones Level (black w/white line, 15 mm) (Order Code: 02057) <i>Note: Knob and knob cap are sold separately. See 02056 for knob.</i>	_____	\$ 1.50	_____
Potentiometer – Phones Level (Order Code: 02127)	_____	\$ 5.00	_____
1/4" Phone Jack (Order Code: 01084) <i>Note: Nut is required for installation of 1/4" phone jack. See 01090 for nut.</i>	_____	\$ 4.00	_____
Nut (plastic) (Order Code: 01090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
DC Power Entry Jack Assembly (includes PCB, washer, and nut) (Order Code: 32135) <i>Note: Requires cable assembly, sold separately. See 13690.</i>	_____	\$12.00	_____
Cable Assembly for DC Power Entry Jack Assembly (2-conductor, 5") (Order Code: 13690)	_____	\$ 4.00	_____
Blank Plate – XLR (black) (Order Code: 01073)	_____	\$ 3.00	_____
Model 240 Security Plate (Order Code: SP-M240)	_____	\$18.00	_____
Screw-On Bumper Kit (black, set of 8) (Order Code: 31064)	_____	\$10.00	_____
24 Vdc, 0.75 A Power Supply (output terminated onto 2.1 x 5.5 mm locking coaxial jack) (Order Code: PS-DC-03)	_____	\$46.00	_____
Model 342 Intercom Station			
Knob (black w/white line, 9 mm) (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 08210-1/8 for set screw.</i>	_____	\$ 3.00	_____
Set Screw (Order Code: 08210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
Push-Pot Potentiometer Assembly (dual-section) (Order Code: 32298) <i>Note: Includes push-pot (02171) and sleeve (14297).</i>	_____	\$ 9.00	_____
Pushbutton Switch (momentary, 17 mm x 17 mm) (Order Code: 12106) <i>Note: Includes button cap and lens. See 32649 for replacement button cap and lens kit.</i>	_____	\$ 6.00	_____
Button Cap and Lens Kit (includes four each button cap and frosted lens) (Order Code: 32649)	_____	\$24.00	_____
Self-Adhesive Rubber Bumpers (black, set of 4, 1/2" dia. by 0.138" tall) (Order Code: 14028)	_____	\$ 2.00	_____
Model 348 Intercom Station			
Pushbutton Switch (momentary, 17 mm x 17 mm) (Order Code: 12106) <i>Note: Includes button cap and lens. See 32649 for replacement button cap and lens kit.</i>	_____	\$ 6.00	_____
Button Cap and Lens Kit (includes four each button cap and frosted lens) (Order Code: 32649)	_____	\$24.00	_____
3.5 mm 4-Conductor (TRRS) Jack (Order Code: 01410)	_____	\$ 5.00	_____
Loudspeaker (37 mm dia., 8 ohm) (Order Code: 10702) <i>Mfg. No.: Visaton: BF37/2261; Parts Express No.: 292-655</i>	_____	\$22.00	_____
Set Screw (Order Code: 08210-1/8) <i>Note: For use with microphone bushing.</i>	_____	\$ 0.50	_____
Self-Adhesive Rubber Bumpers (black, set of 4, 1/2" dia. by 1/4" tall) (Order Code: 14326)	_____	\$ 3.00	_____
Blank Plate – XLR (black) (Order Code: 01073)	_____	\$ 3.00	_____
For Serial Numbers 00151-00381			
Knob – Glow (black w/clear center, 13 mm dia. x 17.8 mm tall) (Order Code: 14321)	_____	\$ 5.00	_____
Rotary Encoder (24-step w/switch, 25 mm overall length) (Order Code: 12103)	_____	\$ 8.00	_____
For Serial Numbers 00382-later			
Knob – Glow (black w/clear center, 13 mm dia. x 13.8 mm tall) (Order Code: 14340)	_____	\$ 5.00	_____
Rotary Encoder (24-step w/switch, 21 mm overall length) (Order Code: 12109)	_____	\$ 8.00	_____

	Qty	US List	Total
Model 352A Talk Station (all Serial Numbers)			
Knob (black w/white line, 9 mm) (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 08210-1/8 for set screw.</i>	_____	\$ 3.00	_____
Set Screw (Order Code: 08210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
Push-Pot Potentiometer Assembly (dual-section) (Order Code: 32298) <i>Note: Includes push-pot (02171) and sleeve (14297).</i>	_____	\$ 9.00	_____
Pushbutton Switch (momentary, 17 mm x 17 mm) (Order Code: 12106) <i>Note: Includes button cap and lens. See 32649 for replacement button cap and lens kit.</i>	_____	\$ 6.00	_____
Button Cap and Lens Kit (includes four each button cap and frosted lens) (Order Code: 32649)	_____	\$24.00	_____
Pushbutton Switch (momentary) – Monitor Source (Order Code: 12056)	_____	\$ 4.00	_____
Pushbutton Cap (gray) (Order Code: 14207)	_____	\$ 3.00	_____
Set Screw (Order Code: 08210-1/8) <i>Note: For use with microphone bushing.</i>	_____	\$ 0.50	_____
Rubber Bumper (black, set of 4, 1/2" dia. by 7/32" tall) (Order Code: 14339) <i>Note: Bumpers and machine screws are sold separately. See 08032-5/16 for screws.</i>	_____	\$ 6.00	_____
Machine Screw (SEMS, 4-40x5/16") (Order Code: 08032-5/16) <i>Note: Machine screws and bumpers are sold separately. See 14339 for bumpers.</i>	_____	\$ 0.50	_____
Model 354 Talk Station (all Serial Numbers)			
Knob (black w/white line, 9 mm) (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 08210-1/8 for set screw.</i>	_____	\$ 3.00	_____
Set Screw (Order Code: 08210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
Push-Pot Potentiometer Assembly (dual-section) (Order Code: 32298) <i>Note: Includes push-pot (02171) and sleeve (14297).</i>	_____	\$ 9.00	_____
Pushbutton Switch (momentary, 17 mm x 17 mm) (Order Code: 12106) <i>Note: Includes button cap and lens. See 32649 for replacement button cap and lens kit.</i>	_____	\$ 6.00	_____
Button Cap and Lens Kit (includes four each button cap and frosted lens) (Order Code: 32649)	_____	\$24.00	_____
Set Screw (Order Code: 08210-1/8) <i>Note: For use with microphone bushing.</i>	_____	\$ 0.50	_____
Rubber Bumper (black, set of 4, 1/2" dia. by 7/32" tall) (Order Code: 14339) <i>Note: Bumpers and machine screws are sold separately. See 08032-5/16 for screws.</i>	_____	\$ 6.00	_____
Machine Screw (SEMS, 4-40x5/16") (Order Code: 08032-5/16) <i>Note: Machine screws and bumpers are sold separately. See 14339 for bumpers.</i>	_____	\$ 0.50	_____
Model 354A Talk Station (all Serial Numbers)			
Knob (black w/white line, 9 mm) (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 08210-1/8 for set screw.</i>	_____	\$ 3.00	_____
Set Screw (Order Code: 08210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
Push-Pot Potentiometer Assembly (dual-section) (Order Code: 32298) <i>Note: Includes push-pot (02171) and sleeve (14297).</i>	_____	\$ 9.00	_____
Pushbutton Switch (momentary, 17 mm x 17 mm) (Order Code: 12106) <i>Note: Includes button cap and lens. See 32649 for replacement button cap and lens kit.</i>	_____	\$ 6.00	_____
Button Cap and Lens Kit (includes four each button cap and frosted lens) (Order Code: 32649)	_____	\$24.00	_____
Pushbutton Switch (momentary) – Monitor Source (Order Code: 12056)	_____	\$ 4.00	_____
Pushbutton Cap (gray) (Order Code: 14207)	_____	\$ 3.00	_____
Set Screw (Order Code: 08210-1/8) <i>Note: For use with microphone bushing.</i>	_____	\$ 0.50	_____
Rubber Bumper (black, set of 4, 1/2" dia. by 7/32" tall) (Order Code: 14339) <i>Note: Bumpers and machine screws are sold separately. See 08032-5/16 for screws.</i>	_____	\$ 6.00	_____
Machine Screw (SEMS, 4-40x5/16") (Order Code: 08032-5/16) <i>Note: Machine screws and bumpers are sold separately. See 14339 for bumpers.</i>	_____	\$ 0.50	_____
GME-3-12 Gooseneck Microphone			
Foam Windscreen – for GME-3-12 Gooseneck Microphone (Order Code: 14331) <i>Note: Also included with Model 11B Gooseneck Microphone Assembly.</i>	_____	\$ 6.00	_____

	Qty	US List	Total
Model 362 Listen-Only Beltpack (all Serial Numbers)			
Knob (black w/white line, 9 mm) (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 08210-1/8 for set screw.</i>	_____	\$ 3.00	_____
Set Screw (Order Code: 08210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
Push-Pot Potentiometer Assembly (dual-section) (Order Code: 32298) <i>Note: Includes push-pot (02171) and sleeve (14297).</i>	_____	\$ 9.00	_____
1/4" Phone Jack (Order Code: 01084) <i>Note: Nut is required for installation of 1/4" phone jack. See 01090 for nut.</i>	_____	\$ 4.00	_____
Nut (plastic) (Order Code: 01090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
3.5 mm Stereo Jack (Order Code: 01198)	_____	\$ 3.00	_____
Belt Clip (black, steel) (Order Code: 30247)	_____	\$ 5.00	_____
Pop-Rivet – for Belt Clip (black, aluminum, 0.125" grip) (Order Code: 08201-.125)	_____	\$ 1.00	_____
Phillips Machine Screw – for Belt Clip (black, 6-32x1/4") (Order Code: 08056-1/4)	_____	\$ 0.50	_____
Model 362A Listen-Only Beltpack (all Serial Numbers)			
Knob (black w/white line, 9 mm) (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 08210-1/8 for set screw.</i>	_____	\$ 3.00	_____
Set Screw (Order Code: 08210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
Push-Pot Potentiometer Assembly (dual-section) (Order Code: 32298) <i>Note: Includes push-pot (02171) and sleeve (14297).</i>	_____	\$ 9.00	_____
1/4" Phone Jack (Order Code: 01084) <i>Note: Nut is required for installation of 1/4" phone jack. See 01090 for nut.</i>	_____	\$ 4.00	_____
Nut (plastic) (Order Code: 01090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
3.5 mm Stereo Jack (Order Code: 01198)	_____	\$ 3.00	_____
Belt Clip (black, steel) (Order Code: 30247)	_____	\$ 5.00	_____
Pop-Rivet – for Belt Clip (black, aluminum, 0.125" grip) (Order Code: 08201-.125)	_____	\$ 1.00	_____
Phillips Machine Screw – for Belt Clip (black, 6-32x1/4") (Order Code: 08056-1/4)	_____	\$ 0.50	_____
Model 370 Intercom Beltpack			
Knob (black w/white line, 9 mm) (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 08210-1/8 for set screw.</i>	_____	\$ 3.00	_____
Set Screw (Order Code: 08210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
Trim Potentiometer (for sidetone) (Order Code: 02119) <i>Note: Plastic shaft sold separately. See 14307.</i>	_____	\$ 4.00	_____
Plastic Shaft (gray, for sidetone trim pot) (Order Code: 14307)	_____	\$ 3.00	_____
Switch Cap – Talk (12 mm square) (Order Code: 14295) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____
Switch Cap – Call (10 mm square) (Order Code: 14296) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____
Switch Cap Adapter (Order Code: 14294) <i>Note: Switch cap and switch cap adapter are sold separately. See 14295 for 12 mm switch cap and 14296 for 10 mm switch cap.</i>	_____	\$ 1.50	_____
Belt Clip (black, steel) (Order Code: 30247)	_____	\$ 5.00	_____
Pop-Rivet – for Belt Clip (black, aluminum, 0.125" grip) (Order Code: 08201-.125)	_____	\$ 1.00	_____
Phillips Machine Screw – for Belt Clip (black, 6-32x1/4") (Order Code: 08056-1/4)	_____	\$ 0.50	_____
For Serial Numbers 00151-02000			
Push-Pot Potentiometer Assembly (dual-section) (Order Code: 32298) <i>Note: Includes push-pot (02171) and sleeve (14297).</i>	_____	\$ 9.00	_____
For Serial Numbers 02001-later			
Push-Pot Potentiometer Assembly (single-section) (Order Code: 32299) <i>Note: Includes push-pot (02172) and sleeve (14297).</i>	_____	\$ 9.00	_____

	Qty	US List	Total
Model 370A Intercom Beltpack (all Serial Numbers)			
Knob (black w/white line, 9 mm) (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 08210-1/8 for set screw.</i>	_____	\$ 3.00	_____
Set Screw (Order Code: 08210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
Push-Pot Potentiometer Assembly (dual-section) (Order Code: 32298) <i>Note: Includes push-pot (02171) and sleeve (14297).</i>	_____	\$ 9.00	_____
Switch Cap – Talk (12 mm square) (Order Code: 14295) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____
Switch Cap – Call (10 mm square) (Order Code: 14296) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____
Switch Cap Adapter (Order Code: 14294) <i>Note: Switch cap and switch cap adapter are sold separately. See 14295 for 12 mm switch cap and 14296 for 10 mm switch cap.</i>	_____	\$ 1.50	_____
Belt Clip (black, steel) (Order Code: 30247)	_____	\$ 5.00	_____
Hex Machine Screw – for Belt Clip (black, 6-32x1/4") (Order Code: 08054-1/4)	_____	\$ 0.50	_____
Model 371 Intercom Beltpack (all Serial Numbers)			
Knob (black w/white line, 9 mm) (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 08210-1/8 for set screw.</i>	_____	\$ 3.00	_____
Set Screw (Order Code: 08210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
Push-Pot Potentiometer Assembly (single-section) (Order Code: 32299) <i>Note: Includes push-pot (02172) and sleeve (14297).</i>	_____	\$ 9.00	_____
Trim Potentiometer (for sidetone) (Order Code: 02119) <i>Note: Plastic shaft sold separately. See 14307.</i>	_____	\$ 4.00	_____
Plastic Shaft (gray, for sidetone trim pot) (Order Code: 14307)	_____	\$ 3.00	_____
Switch Cap – Talk (12 mm square) (Order Code: 14295) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____
Switch Cap – Call (10 mm square) (Order Code: 14296) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____
Switch Cap Adapter (Order Code: 14294) <i>Note: Switch cap and switch cap adapter are sold separately. See 14295 for 12 mm switch cap and 14296 for 10 mm switch cap.</i>	_____	\$ 1.50	_____
Belt Clip (black, steel) (Order Code: 30247)	_____	\$ 5.00	_____
Pop-Rivet – for Belt Clip (black, aluminum, 0.125" grip) (Order Code: 08201-.125)	_____	\$ 1.00	_____
Phillips Machine Screw – for Belt Clip (black, 6-32x1/4") (Order Code: 08056-1/4)	_____	\$ 0.50	_____
Model 371A Intercom Beltpack (all Serial Numbers)			
Knob (black w/white line, 9 mm) (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 08210-1/8 for set screw.</i>	_____	\$ 3.00	_____
Set Screw (Order Code: 08210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
Push-Pot Potentiometer Assembly (dual-section) (Order Code: 32298) <i>Note: Includes push-pot (02171) and sleeve (14297).</i>	_____	\$ 9.00	_____
Switch Cap – Talk (12 mm square) (Order Code: 14295) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____
Switch Cap – Call (10 mm square) (Order Code: 14296) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____
Switch Cap Adapter (Order Code: 14294) <i>Note: Switch cap and switch cap adapter are sold separately. See 14295 for 12 mm switch cap and 14296 for 10 mm switch cap.</i>	_____	\$ 1.50	_____
Belt Clip (black, steel) (Order Code: 30247)	_____	\$ 5.00	_____
Hex Machine Screw – for Belt Clip (black, 6-32x1/4") (Order Code: 08054-1/4)	_____	\$ 0.50	_____

	Qty	US List	Total
Model 372A Intercom Beltpack (all Serial Numbers)			
Knob (black w/white line, 9 mm) (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 08210-1/8 for set screw.</i>	_____	\$ 3.00	_____
Set Screw (Order Code: 08210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
Push-Pot Potentiometer Assembly (dual-section) (Order Code: 32298) <i>Note: Includes push-pot (02171) and sleeve (14297).</i>	_____	\$ 9.00	_____
Switch Cap – Talk (12 mm square) (Order Code: 14295) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____
Switch Cap Adapter (Order Code: 14294) <i>Note: Switch cap and switch cap adapter are sold separately. See 14295 for 12 mm switch cap.</i>	_____	\$ 1.50	_____
Belt Clip (black, steel) (Order Code: 30247)	_____	\$ 5.00	_____
Pop-Rivet – for Belt Clip (black, aluminum, 0.125" grip) (Order Code: 08201-.125)	_____	\$ 1.00	_____
Model 373A Intercom Beltpack (all Serial Numbers)			
Knob (black w/white line, 9 mm) (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 08210-1/8 for set screw.</i>	_____	\$ 3.00	_____
Set Screw (Order Code: 08210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
Push-Pot Potentiometer Assembly (dual-section) (Order Code: 32298) <i>Note: Includes push-pot (02171) and sleeve (14297).</i>	_____	\$ 9.00	_____
Switch Cap – Talk (12 mm square) (Order Code: 14295) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____
Switch Cap Adapter (Order Code: 14294) <i>Note: Switch cap and switch cap adapter are sold separately. See 14295 for 12 mm switch cap.</i>	_____	\$ 1.50	_____
Belt Clip (black, steel) (Order Code: 30247)	_____	\$ 5.00	_____
Pop-Rivet – for Belt Clip (black, aluminum, 0.125" grip) (Order Code: 08201-.125)	_____	\$ 1.00	_____
Model 374 Intercom Beltpack (all Serial Numbers)			
Knob (black w/white line, 9 mm) (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 08210-1/8 for set screw.</i>	_____	\$ 3.00	_____
Set Screw (Order Code: 08210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
Push-Pot Potentiometer Assembly (dual-section) (Order Code: 32298) <i>Note: Includes push-pot (02171) and sleeve (14297).</i>	_____	\$ 9.00	_____
Trim Potentiometer (for sidetone) (Order Code: 02119) <i>Note: Plastic shaft sold separately. See 14307.</i>	_____	\$ 4.00	_____
Plastic Shaft (gray, for sidetone trim pot) (Order Code: 14307)	_____	\$ 3.00	_____
Switch Cap (10 mm square) (Order Code: 14296) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____
Switch Cap Adapter (Order Code: 14294) <i>Note: Switch cap and switch cap adapter are sold separately. See 14296 for 10 mm switch cap.</i>	_____	\$ 1.50	_____
Belt Clip (black, steel) (Order Code: 30247)	_____	\$ 5.00	_____
Pop-Rivet – for Belt Clip (black, aluminum, 0.125" grip) (Order Code: 08201-.125)	_____	\$ 1.00	_____
Phillips Machine Screw – for Belt Clip (black, 6-32x1/4") (Order Code: 08056-1/4)	_____	\$ 0.50	_____
Model 374A Intercom Beltpack (all Serial Numbers)			
Knob (black w/white line, 9 mm) (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 08210-1/8 for set screw.</i>	_____	\$ 3.00	_____
Set Screw (Order Code: 08210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
Push-Pot Potentiometer Assembly (dual-section) (Order Code: 32298) <i>Note: Includes push-pot (02171) and sleeve (14297).</i>	_____	\$ 9.00	_____
Switch Cap (10 mm square) (Order Code: 14296) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____
Switch Cap Adapter (Order Code: 14294) <i>Note: Switch cap and switch cap adapter are sold separately. See 14296 for 10 mm switch cap.</i>	_____	\$ 1.50	_____
Belt Clip (black, steel) (Order Code: 30247)	_____	\$ 5.00	_____
Hex Machine Screw – for Belt Clip (black, 6-32x1/4") (Order Code: 08054-1/4)	_____	\$ 0.50	_____

	Qty	US List	Total
Model 380 On-Air Beltpack			
Knob (black w/white line, 9 mm) (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 08210-1/8 for set screw.</i>	_____	\$ 3.00	_____
Set Screw (Order Code: 08210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
1/4" Phone Jack (Order Code: 01084) <i>Note: Nut is required for installation of 1/4" phone jack. See 01090 for nut.</i>	_____	\$ 4.00	_____
Nut (plastic) (Order Code: 01090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
Switch Cap Adapter (Order Code: 14294) <i>Note: Switch cap and switch cap adapter are sold separately. See 14295 for 12 mm switch cap.</i>	_____	\$ 1.50	_____
Switch Cap (12 mm) (Order Code: 14295) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____
Belt Clip (black, steel) (Order Code: 30247)	_____	\$ 5.00	_____
Pop-Rivet – for Belt Clip (black, aluminum, 0.125" grip) (Order Code: 08201-.125)	_____	\$ 1.00	_____
Phillips Machine Screw – for Belt Clip (black, 6-32x1/4") (Order Code: 08056-1/4)	_____	\$ 0.50	_____
For Serial Numbers 00151-01000			
Push-Pot Potentiometer Assembly (dual-section) (Order Code: 32298) <i>Note: Includes push-pot (02171) and sleeve (14297).</i>	_____	\$ 9.00	_____
For Serial Numbers 01001-later			
Push-Pot Potentiometer Assembly (single-section) (Order Code: 32299) <i>Note: Includes push-pot (02172) and sleeve (14297).</i>	_____	\$ 9.00	_____
Model 381 On-Air Beltpack (all Serial Numbers)			
Knob (black w/white line, 9 mm) (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 08210-1/8 for set screw.</i>	_____	\$ 3.00	_____
Set Screw (Order Code: 08210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
Push-Pot Potentiometer Assembly (dual-section) (Order Code: 32298) <i>Note: Includes push-pot (02171) and sleeve (14297).</i>	_____	\$ 9.00	_____
1/4" Phone Jack (Order Code: 01084) <i>Note: Nut is required for installation of 1/4" phone jack. See 01090 for nut.</i>	_____	\$ 4.00	_____
Nut (plastic) (Order Code: 01090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
Pushbutton Switch (momentary) (Order Code: 12095)	_____	\$ 6.00	_____
Switch Cap Adapter (Order Code: 14294) <i>Note: Switch cap and switch cap adapter are sold separately. See 14295 for 12 mm switch cap.</i>	_____	\$ 1.50	_____
Switch Cap (12 mm) (Order Code: 14295) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____
Belt Clip (black, steel) (Order Code: 30247)	_____	\$ 5.00	_____
Pop-Rivet – for Belt Clip (black, aluminum, 0.125" grip) (Order Code: 08201-.125)	_____	\$ 1.00	_____
Model 391 Dante Alerting Unit (all Serial Numbers)			
Pushbutton Switch (momentary) – Mode (Order Code: 12056)	_____	\$ 4.00	_____
Pushbutton Cap (gray) (Order Code: 14207)	_____	\$ 3.00	_____
Screw-On Bumper Kit (black, set of 8) (Order Code: 31064)	_____	\$10.00	_____
Trim Potentiometer (Order Code: 02119) <i>Note: Plastic shaft sold separately. See 14307.</i>	_____	\$ 4.00	_____
Plastic Shaft (gray, for trim pot) (Order Code: 14307)	_____	\$ 3.00	_____
Model 392 Visual Indicator Unit (all Serial Numbers)			
Metal Plate (Order Code: 32248) <i>Mfg. No.: Leviton® S746-N, 2-gang, 1-Decora® opening, centered, 302 stainless steel. Available from online and electrical supply sources.</i>	Not available from factory		

	Qty	US List	Total
Model 394 GPI Interface (all Serial Numbers)			
Switch Cap Adapter (Order Code: 14294) <i>Note: Switch cap and switch cap adapter are sold separately. See 14295 for 12 mm switch cap.</i>	_____	\$ 1.50	_____
Switch Cap (12 mm) (Order Code: 14295) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____
Terminal Block (4-position) (Order Code: 01434)	_____	\$ 6.00	_____
Model 395 GPO Interface (all Serial Numbers)			
Switch Cap Adapter (Order Code: 14294) <i>Note: Switch cap and switch cap adapter are sold separately. See 14295 for 12 mm switch cap.</i>	_____	\$ 1.50	_____
Switch Cap (12 mm) (Order Code: 14295) <i>Note: Switch cap and switch cap adapter are sold separately. See 14294 for switch cap adapter.</i>	_____	\$ 1.50	_____
Terminal Block (4-position) (Order Code: 01434)	_____	\$ 6.00	_____

	Qty	US List	Total
Model 400 SDI-Over-Fiber Transport Systems (all Serial Numbers)			
Pushbutton Switch (momentary) (Order Code: 12055) Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND		\$ 4.00	
Display Lens (Order Code: 15203)		\$ 4.00	
Power Supply (universal AC mains input/12 V, 3.34 A (40 watts) output) (Order Code: 10303) Mfg. No.: Cincon CFM40S120; Digi-Key No.: 2034-3674-ND; Mouser No.: 418-CFM40S120		\$ 45.00	
Model 403-03 Triple Optical to Electrical Interface Card (Order Code: M403-03) Note: Does not include SFP optical modules (card uses one each 06411 and 06407).		\$450.00	
Model 403-30 Triple Electrical to Optical Interface Card (Order Code: M403-30) Note: Does not include SFP optical modules (card uses one each 06410 and 06408).		\$550.00	
SFP Optical Module (video, single-channel receiver) (Order Code: 06411) Note: Non-MSA, supports 3G SDI video. Mfg. No.: Eoptolink EOLS-30R-DN.		\$156.00	
SFP Optical Module (video, dual-channel receiver) (Order Code: 06407) Note: Non-MSA, supports 3G SDI video. Mfg. No.: Eoptolink EOLS-30DR-DN.		\$185.00	
SFP Optical Module (video, single-channel transmitter) (Order Code: 06410) Note: 1490 nm CWDM laser; non-MSA, supports 3G SDI video. Mfg. No.: Eoptolink EOLS-1630T-DLN.		\$210.00	
SFP Optical Module (video, dual-channel transmitter) (Order Code: 06408) Note: 1310 nm FP laser (channel 1), 1550 nm DFB laser (channel 2), non-MSA, supports 3G SDI video. Mfg. No.: Eoptolink EOLS-1330DT-10DN-V.		\$330.00	
Optical Attenuator (4 dB) (Order Code: 06437) Note: LC UPC-M/F.		\$ 15.00	
ST-ST Optical Barrel Connector (with nut and lockwasher) (Order Code: 01260)		\$ 6.00	
Optical Multiplexer ("mux") (3 inputs/1 output) (Order Code: 10826) Note: 1310, 1490, and 1550 nm inputs use LC optical connectors; output uses ST optical connector.		\$ 70.00	
Optical Demultiplexer ("demux") (1 input/3 outputs) (Order Code: 10827) Note: Input uses ST optical connector; 1310, 1490, and 1550 nm outputs use LC optical connectors.		\$ 95.00	
Model 400A SDI-Over-Fiber Transport Systems (all Serial Numbers)			
Pushbutton Switch (momentary) (Order Code: 12055) Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND		\$ 4.00	
Field-Service Display Replacement Kit (includes a VFD display (10609) with attached ribbon cable (13707)) (Order Code: 32638)		\$122.00	
Display Lens (Order Code: 15203)		\$ 4.00	
Power Supply (universal AC mains input/12 V, 3.34 A (40 watts) output) (Order Code: 10303) Mfg. No.: Cincon CFM40S120; Digi-Key No.: 2034-3674-ND; Mouser No.: 418-CFM40S120		\$ 45.00	
Model 403-03 Triple Optical to Electrical Interface Card (Order Code: M403-03) Note: Does not include SFP optical modules (card uses one each 06411 and 06407).		\$450.00	
Model 403-30 Triple Electrical to Optical Interface Card (Order Code: M403-30) Note: Does not include SFP optical modules (card uses one each 06410 and 06408).		\$550.00	
SFP Optical Module (video, single-channel receiver) (Order Code: 06411) Note: Non-MSA, supports 3G SDI video. Mfg. No.: Eoptolink EOLS-30R-DN.		\$156.00	
SFP Optical Module (video, dual-channel receiver) (Order Code: 06407) Note: Non-MSA, supports 3G SDI video. Mfg. No.: Eoptolink EOLS-30DR-DN.		\$185.00	
SFP Optical Module (video, single-channel transmitter) (Order Code: 06410) Note: 1490 nm CWDM laser; non-MSA, supports 3G SDI video. Mfg. No.: Eoptolink EOLS-1630T-DLN.		\$210.00	
SFP Optical Module (video, dual-channel transmitter) (Order Code: 06408) Note: 1310 nm FP laser (channel 1), 1550 nm DFB laser (channel 2), non-MSA, supports 3G SDI video. Mfg. No.: Eoptolink EOLS-1330DT-10DN-V.		\$330.00	
Optical Attenuator (4 dB) (Order Code: 06437) Note: LC UPC-M/F.		\$ 15.00	
ST-ST Optical Barrel Connector (with nut and lockwasher) (Order Code: 01260)		\$ 6.00	
Optical Multiplexer ("mux") (3 inputs/1 output) (Order Code: 10826) Note: 1310, 1490, and 1550 nm inputs use LC optical connectors; output uses ST optical connector.		\$ 70.00	
Optical Demultiplexer ("demux") (1 input/3 outputs) (Order Code: 10827) Note: Input uses ST optical connector; 1310, 1490, and 1550 nm outputs use LC optical connectors.		\$ 95.00	

	Qty	US List	Total
Model 410 SDI-Over-Fiber Transport Systems (all Serial Numbers)			
Pushbutton Switch (momentary) (Order Code: 12055) Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND	_____	\$ 4.00	_____
Display Lens (Order Code: 15203)	_____	\$ 4.00	_____
Screw-On Bumper Kit (black, set of 8) (Order Code: 31064)	_____	\$ 10.00	_____
12 Vdc, 1.5 A Power Supply (output terminated onto 4-pin female XLR connector) (Order Code: PS-DC-02)	_____	\$ 88.00	_____
Model 403-03 Triple Optical to Electrical Interface Card (Order Code: M403-03) Note: Does not include SFP optical modules (card uses one each 06411 and 06407).	_____	\$450.00	_____
Model 403-30 Triple Electrical to Optical Interface Card (Order Code: M403-30) Note: Does not include SFP optical modules (card uses one each 06410 and 06408).	_____	\$550.00	_____
Model 403-33M Triple Electrical to Optical / Triple Optical to Electrical Interface Card (Order Code: M403-33) Notes: Does not include SFP optical modules. Used as a replacement for both 403-33M and 403-33 cards (card uses one each 06410, 06408, 06411, and 06407).	_____	\$550.00	_____
SFP Optical Module (video, single-channel receiver) (Order Code: 06411) Note: Non-MSA, supports 3G SDI video. Mfg. No.: Eoptolink EOLS-30R-DN.	_____	\$156.00	_____
SFP Optical Module (video, dual-channel receiver) (Order Code: 06407) Note: Non-MSA, supports 3G SDI video. Mfg. No.: Eoptolink EOLS-30DR-DN.	_____	\$185.00	_____
SFP Optical Module (video, single-channel transmitter) (Order Code: 06410) Note: 1490 nm CWDM laser; non-MSA, supports 3G SDI video. Mfg. No.: Eoptolink EOLS-1630T-DLN.	_____	\$210.00	_____
SFP Optical Module (video, dual-channel transmitter) (Order Code: 06408) Note: 1310 nm FP laser (channel 1), 1550 nm DFB laser (channel 2), non-MSA, supports 3G SDI video. Mfg. No.: Eoptolink EOLS-1330DT-10DN-V.	_____	\$330.00	_____
Optical Attenuator (4 dB) (Order Code: 06437) Note: LC UPC-M/F.	_____	\$ 15.00	_____
ST-ST Optical Barrel Connector (with nut and lockwasher) (Order Code: 01260)	_____	\$ 6.00	_____
Optical Multiplexer (“mux”) (3 inputs/1 output) (Order Code: 10826) Notes: 1310, 1490, and 1550 nm inputs use LC optical connectors; output uses ST optical connector. Applicable to M410-3T and M410-3R.	_____	\$ 70.00	_____
Optical Demultiplexer (“demux”) (1 input/3 outputs) (Order Code: 10827) Notes: Input uses ST optical connector; 1310, 1490, and 1550 nm outputs use LC optical connectors. Applicable to M410-3T and M410-3R.	_____	\$ 95.00	_____
Optical Demultiplexer (“demux”) (1 input/3 outputs) (Order Code: 10828) Notes: Input uses ST optical connector; 1310, 1490, and 1550 nm outputs use LC optical connectors. Applicable to M410-3T/3R.	_____	\$ 95.00	_____
Model 412 Fiber Transport Systems (all Serial Numbers)			
Pushbutton Switch (momentary) (Order Code: 12055) Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND	_____	\$ 4.00	_____
Display Lens (Order Code: 15203)	_____	\$ 4.00	_____
Screw-On Bumper Kit (black, set of 8) (Order Code: 31064)	_____	\$ 10.00	_____
12 Vdc, 1.5 A Power Supply (output terminated onto 4-pin female XLR connector) (Order Code: PS-DC-02)	_____	\$ 88.00	_____
SFP Optical Module (video, single-channel receiver) (Order Code: 06411) Note: Non-MSA, supports 3G SDI video. Mfg. No.: Eoptolink EOLS-30R-DN.	_____	\$156.00	_____
SFP Optical Module (video, dual-channel receiver) (Order Code: 06407) Note: Non-MSA, supports 3G SDI video. Mfg. No.: Eoptolink EOLS-30DR-DN.	_____	\$185.00	_____
SFP Optical Module (video, single-channel transmitter) (Order Code: 06410) Note: 1490 nm CWDM laser; non-MSA, supports 3G SDI video. Mfg. No.: Eoptolink EOLS-1630T-DLN.	_____	\$210.00	_____
SFP Optical Module (video, dual-channel transmitter) (Order Code: 06408) Note: 1310 nm FP laser (channel 1), 1550 nm DFB laser (channel 2), non-MSA, supports 3G SDI video. Mfg. No.: Eoptolink EOLS-1330DT-10DN-V.	_____	\$330.00	_____
SFP Optical Module (Ethernet, transceiver) (Order Code: 06433) Note: 1310 nm FP laser, MSA, supports 10/100/1000 Ethernet. Mfg. No.: ATOP APS31123CDL20.	_____	\$ 55.00	_____
Optical Attenuator (4 dB) (Order Code: 06437) Note: LC UPC-M/F.	_____	\$ 15.00	_____
ST-ST Optical Barrel Connector (with nut and lockwasher) (Order Code: 01260)	_____	\$ 6.00	_____

	Qty	US List	Total
Model 543D IFB Interface (all Serial Numbers)			
Screw-On Bumper Kit (black, set of 8) (Order Code: 31064)	_____	\$10.00	_____
Model 544D Audio Interface (all Serial Numbers)			
Screw-On Bumper Kit (black, set of 8) (Order Code: 31064)	_____	\$10.00	_____
Model 545AC Intercom Interface (all Serial Numbers)			
Pushbutton Switch (momentary) – Auto Null (Order Code: 12056)	_____	\$ 4.00	_____
Pushbutton Cap (gray) (Order Code: 14207)	_____	\$ 3.00	_____
Screw-On Bumper Kit (black, set of 8) (Order Code: 31064)	_____	\$10.00	_____
Model 545AR Intercom Interface (all Serial Numbers)			
Pushbutton Switch (momentary) – Auto Null (Order Code: 12056)	_____	\$ 4.00	_____
Pushbutton Cap (gray) (Order Code: 14207)	_____	\$ 3.00	_____
Screw-On Bumper Kit (black, set of 8) (Order Code: 31064)	_____	\$10.00	_____
Model 545DC Intercom Interface (all Serial Numbers)			
Pushbutton Switch (momentary) – Auto Null (Order Code: 12056)	_____	\$ 4.00	_____
Pushbutton Cap (gray) (Order Code: 14207)	_____	\$ 3.00	_____
Screw-On Bumper Kit (black, set of 8) (Order Code: 31064)	_____	\$10.00	_____
Model 545DR Intercom Interface (all Serial Numbers)			
Pushbutton Switch (momentary) – Auto Null (Order Code: 12056)	_____	\$ 4.00	_____
Pushbutton Cap (gray) (Order Code: 14207)	_____	\$ 3.00	_____
Screw-On Bumper Kit (black, set of 8) (Order Code: 31064)	_____	\$10.00	_____
Model 742 Audio Mixer (all Serial Numbers)			
Knob – Inputs 1-8 (black, push-on, 15 mm) (Order Code: 02056)	_____	\$ 3.00	_____
<i>Note: Knob and knob cap are sold separately. See 02057 for knob cap.</i>			
Knob Cap – Inputs 1-8 (black w/white line, 15 mm) (Order Code: 02057)	_____	\$ 1.50	_____
<i>Note: Knob and knob cap are sold separately. See 02056 for knob.</i>			
Potentiometer – Inputs 1-4 (Order Code: 02145)	_____	\$ 4.00	_____
Potentiometer – Inputs 5-8 (Order Code: 02166)	_____	\$ 4.00	_____
Potentiometer – Master and Monitor (dual-shaft) (Order Code: 02167)	_____	\$12.00	_____
Knob (Top) – Master and Monitor (black w/white line, 11 mm) (Order Code: 14253)	_____	\$ 3.00	_____
<i>Note: Knob (top), knob cap (top), and knob (bottom) are sold separately. See 14255 for knob cap (top) and 14254 for knob (bottom).</i>			
Knob Cap (Top) – Master and Monitor (black w/white line, 11 mm) (Order Code: 14255)	_____	\$ 3.00	_____
<i>Note: Knob (top), knob cap (top), and knob (bottom) are sold separately. See 14253 for knob (top) and 14254 for knob (bottom).</i>			
Knob (Bottom) – Master and Monitor (black w/white line, 15 mm) (Order Code: 14254)	_____	\$ 4.00	_____
<i>Note: Knob (top), knob cap (top), and knob (bottom) are sold separately. See 14253 for knob (top) and 14255 for knob cap (top).</i>			

	Qty	US List	Total
Model 742A Audio Mixer (all Serial Numbers)			
4-Position DIP Switch (Order Code: 12071)	_____	\$ 5.00	_____
Knob – Inputs 1-8 (black, push-on, 15 mm) (Order Code: 02056) <i>Note: Knob and knob cap are sold separately. See 02057 for knob cap.</i>	_____	\$ 3.00	_____
Knob Cap – Inputs 1-8 (black w/white line, 15 mm) (Order Code: 02057) <i>Note: Knob and knob cap are sold separately. See 02056 for knob.</i>	_____	\$ 1.50	_____
Potentiometer – Inputs 1-4 (Order Code: 02145)	_____	\$ 4.00	_____
Potentiometer – Inputs 5-8 (Order Code: 02166)	_____	\$ 4.00	_____
Potentiometer – Master and Monitor (dual-shaft) (Order Code: 02167)	_____	\$12.00	_____
Knob (Top) – Master and Monitor (black w/white line, 11 mm) (Order Code: 14253) <i>Note: Knob (top), knob cap (top), and knob (bottom) are sold separately. See 14255 for knob cap (top) and 14254 for knob (bottom).</i>	_____	\$ 3.00	_____
Knob Cap (Top) – Master and Monitor (black w/white line, 11 mm) (Order Code: 14255) <i>Note: Knob (top), knob cap (top), and knob (bottom) are sold separately. See 14253 for knob (top) and 14254 for knob (bottom).</i>	_____	\$ 3.00	_____
Knob (Bottom) – Master and Monitor (black w/white line, 15 mm) (Order Code: 14254) <i>Note: Knob (top), knob cap (top), and knob (bottom) are sold separately. See 14253 for knob (top) and 14255 for knob cap (top).</i>	_____	\$ 4.00	_____
Power Supply (universal AC mains input/12 V, 1.25 A (15 watts) output) (Order Code: 10354) <i>Mfg. No.: Cincon CFM1502S; Digi-Key No.: 2034-3555-ND; Mouser No.: 418-CFM1502S</i>	_____	\$35.00	_____
Model 750 Audio Mixer (Serial Numbers 00151 – 00400)			
Potentiometer – Mic/Line Input (dual-shaft, 3-section 10KB//50KA/50KA) (Order Code: 02130)	_____	\$16.00	_____
Potentiometer – Stereo Line Input, Main, and Aux Outputs (dual-shaft 50KA/50KA) (Order Code: 02131)	_____	\$12.00	_____
Potentiometer – Speaker and Phones (single-shaft, dual-section 10KA/10KA) (Order Code: 02128)	_____	\$ 8.00	_____
Pushbutton Switch (push-push) (Order Code: 12016)	_____	\$ 3.00	_____
Pushbutton Cap (illuminated, gray, 12.5 mm x 6.8 mm) (Order Code: 14228)	_____	\$ 3.00	_____
Pushbutton Cap (gray, 5.5 mm square) (Order Code: 14229)	_____	\$ 1.50	_____
Knob – Speaker and Phones (black w/white line, 16 mm) (Order Code: 14231)	_____	\$ 3.00	_____
Knob Base– Inputs and Master (black w/white line, 16 mm) (Order Code: 14233) <i>Note: Knob base and knob top are sold separately. See 14232 for knob top.</i>	_____	\$ 3.00	_____
Knob Top– Inputs and Master (black w/white line, 10.5 mm) (Order Code: 14232) <i>Note: Knob base and knob top are sold separately. See 14233 for knob base.</i>	_____	\$ 3.00	_____
Model 750 Audio Mixer (Serial Numbers 00401 – later)			
Potentiometer – Mic/Line Input (dual-shaft, 3-section 10KB//50KA/50KA) (Order Code: 02130)	_____	\$16.00	_____
Potentiometer – Stereo Line Input, Main, and Aux Outputs (dual-shaft 50KA/50KA) (Order Code: 02131)	_____	\$12.00	_____
Potentiometer – Speaker and Phones (single-shaft, dual-section 10KA/10KA) (Order Code: 02128)	_____	\$ 8.00	_____
Pushbutton Switch (push-push) (Order Code: 12016)	_____	\$ 3.00	_____
Pushbutton Cap (illuminated, gray, 12.5 mm x 6.8 mm) (Order Code: 14228)	_____	\$ 3.00	_____
Pushbutton Cap (gray, 5.5 mm square) (Order Code: 14229)	_____	\$ 1.50	_____
Knob – Speaker and Phones (black, 15 mm) (Order Code: 02056) <i>Note: Knob and knob cap are sold separately. See 14252 for knob cap.</i>	_____	\$ 3.00	_____
Knob Cap – Speaker and Phones (gray w/black line, 15 mm) (Order Code: 14252) <i>Note: Knob and knob cap are sold separately. See 02056 for knob.</i>	_____	\$ 1.50	_____
Knob Base – Inputs and Master (black w/white line, 15 mm) (Order Code: 14249) <i>Note: Knob base, knob top, and knob cap are sold separately. See 14250 for knob top and 14251 for knob cap.</i>	_____	\$ 3.00	_____
Knob Top – Inputs and Master (black w/white line, push-on, 11 mm) (Order Code: 14250) <i>Note: Knob base, knob top, and knob cap are sold separately. See 14249 for knob base and 14251 for knob cap.</i>	_____	\$ 3.00	_____
Knob Cap – Inputs and Master (gray w/black line, 11 mm) (Order Code: 14251) <i>Note: Knob base, knob top, and knob cap are sold separately. See 14249 for knob base and 14250 for knob top.</i>	_____	\$ 3.00	_____

	Qty	US List	Total
Model 760-Series Central Controllers (all serial numbers)			
Power Supply Assembly (universal AC mains input/12 V, 1.25 A (15 watts) output) (Order Code: 32226)		\$65.00	
Note: Replaces discontinued Phihong PSA15LN3-120-R power supply.			
Model 761 Central Controller (all serial numbers)			
Capacitor (surface mount, aluminum electrolytic, 47 uF, 25 V) (Order Code: 04975)		\$ 2.00	
Mfg. No.: Panasonic FK-Series, EEE-FK1E470P; Digi-Key No.: PCE3804, Mouser No. 667-EEE-FK1E470P			
Alternate, Mfg. No.: Nichicon UUD-Series, UUD1E470MCL1GS; Digi-Key No. 493-2273-2, Mouser No. 647-UUD1E470MCL			
Notes: For revision B circuit boards: C36, C73, C178, C193 (C193 is bypass for -15 volt DC rail and is most critical)			
For revision C circuit boards: C39, C76, C181, C196 (C196 is bypass for -15 volt DC rail and is most critical)			
Model 780-Series Central Controllers (all serial numbers)			
Power Supply Assembly (universal AC mains input/12 V, 1.25 A (15 watts) output) (Order Code: 32226)		\$65.00	
Note: Replaces discontinued Phihong PSA15LN3-120-R power supply.			
Model 790 Control Console (all Serial Numbers)			
Pushbutton Switch (momentary) (Order Code: 12055)		\$ 4.00	
Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND			
Knob – Level (black, collet, 29 mm) (Order Code: 14214)		\$ 7.00	
Note: Knob and knob cap are sold separately. See 14260 for knob cap.			
Knob Cap – Level (black, 29 mm) (Order Code: 14260)		\$ 2.00	
Note: Knob and knob cap are sold separately. See 14214 for knob.			
Rotary Encoder Assembly – Level (Order Code: 31378)		\$ 9.00	
Self-Adhesive Rubber Bumpons (black, set of 4, 1/2" dia. by 0.138" tall) (Order Code: 14028)		\$ 2.00	
9-Pin Male D-Sub/9-Pin Male D-Sub Cable Assembly (overall length 25 feet/7.7 m) (Order Code: 13179-20)		\$26.00	
Model 791 Control Console (all Serial Numbers)			
Pushbutton Switch (momentary) (Order Code: 12055)		\$ 4.00	
Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND			
Knob – Level (black, collet, 29 mm) (Order Code: 14214)		\$ 7.00	
Note: Knob and knob cap are sold separately. See 14260 for knob cap.			
Knob Cap – Level (black, 29 mm) (Order Code: 14260)		\$ 2.00	
Note: Knob and knob cap are sold separately. See 14214 for knob.			
Rotary Encoder – Level (Order Code: 12034)		\$ 4.00	
Self-Adhesive Rubber Bumpons (black, set of 4, 1/2" dia. by 0.138" tall) (Order Code: 14028)		\$ 2.00	
9-Pin Male D-Sub/9-Pin Male D-Sub Cable Assembly (overall length 25 feet/7.7 m) (Order Code: 13179-20)		\$26.00	
Model 792 Central Controller (all Serial Numbers)			
Knob (black w/white line, 9 mm) (Order Code: 14287)		\$ 3.00	
Note: Knob and set screw are sold separately. See 08210-1/8 for set screw.			
Set Screw (Order Code: 08210-1/8)		\$ 0.50	
Note: Set screw and knob are sold separately. See 14287 for knob.			
Push-Pot Potentiometer Assembly (dual-section) (Order Code: 32298)		\$ 9.00	
Note: Includes push-pot (02171) and sleeve (14297).			
Power Supply (universal AC mains input/12 V, 1.8 A (20 watts) output) (Order Code: 10355)		\$32.00	
Mfg. No.: Cincon CFM2002S; Digi-Key No.: 2034-3589-ND; Mouser No.: 418-CFM2002S			

	Qty	US List	Total
Model 793 Control Console (all Serial Numbers)			
Pushbutton Switch (momentary) (Order Code: 12055) Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND	_____	\$ 4.00	_____
Knob – Level (black, collet, 29 mm) (Order Code: 14214) Note: Knob and knob cap are sold separately. See 14260 for knob cap.	_____	\$ 7.00	_____
Knob Cap – Level (black, 29 mm) (Order Code: 14260) Note: Knob and knob cap are sold separately. See 14214 for knob.	_____	\$ 2.00	_____
Rotary Encoder Assembly – Level (Order Code: 12110)	_____	\$ 9.00	_____
Self-Adhesive Rubber Bumpers (black, set of 4, 1/2" dia. by 0.138" tall) (Order Code: 14028)	_____	\$ 2.00	_____
9-Pin Male D-Sub/9-Pin Male D-Sub Cable Assembly (overall length 25 feet/7.7 m) (Order Code: 13179-20)	_____	\$26.00	_____
Model 794-Series Central Controllers (all Serial Numbers)			
Knob (black w/white line, 9 mm) (Order Code: 14287) Note: Knob and set screw are sold separately. See 08210-1/8 for set screw.	_____	\$ 3.00	_____
Set Screw (Order Code: 08210-1/8) Note: Set screw and knob are sold separately. See 14287 for knob.	_____	\$ 0.50	_____
Push-Pot Potentiometer Assembly (dual-section) (Order Code: 32298) Note: Includes push-pot (02171) and sleeve (14297).	_____	\$ 9.00	_____
Power Supply (universal AC mains input/12 V, 1.8 A (20 watts) output) (Order Code: 10355) Mfg. No.: Cincon CFM2002S; Digi-Key No.: 2034-3589-ND; Mouser No.: 418-CFM2002S	_____	\$32.00	_____
Model 795 Control Console (all Serial Numbers)			
Pushbutton Switch (momentary) (Order Code: 12055) Mfg. No.: E-Switch 320E1-1BLK; Digi-Key No.: EG1301-ND	_____	\$ 4.00	_____
Knob – Level (black, collet, 29 mm) (Order Code: 14214) Note: Knob and knob cap are sold separately. See 14260 for knob cap.	_____	\$ 7.00	_____
Knob Cap – Level (black, 29 mm) (Order Code: 14260) Note: Knob and knob cap are sold separately. See 14214 for knob.	_____	\$ 2.00	_____
Rotary Encoder Assembly – Level (Order Code: 12110)	_____	\$ 9.00	_____
Self-Adhesive Rubber Bumpers (black, set of 4, 1/2" dia. by 0.138" tall) (Order Code: 14028)	_____	\$ 2.00	_____
9-Pin Male D-Sub/9-Pin Male D-Sub Cable Assembly (overall length 25 feet/7.7 m) (Order Code: 13179-20)	_____	\$26.00	_____

	Qty	US List	Total
Model 5100-Series Broadcast Support Modules (all Serial Numbers)			
Contact Factory as Required			
Model 5202 Dante to Phones and Line Output Interface (all Serial Numbers)			
Knob (black w/white line, 9 mm) (Order Code: 14287)	_____	\$ 3.00	_____
<i>Note: Knob and set screw are sold separately. See 08210-1/8 for set screw.</i>			
Set Screw (Order Code: 08210-1/8)	_____	\$ 0.50	_____
<i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>			
Push-Pot Potentiometer Assembly (dual-section) (Order Code: 32298)	_____	\$ 9.00	_____
<i>Note: Includes push-pot (02171) and sleeve (14297).</i>			
1/4" Phone Jack (Order Code: 01084)	_____	\$ 4.00	_____
<i>Note: Nut is required for installation of 1/4" phone jack. See 01090 for nut.</i>			
Nut (plastic) (Order Code: 01090)	_____	\$ 1.50	_____
<i>Note: Nut is required for installation of 1/4" phone jack.</i>			
Model 5204 Dual Line Input to Dante Interface (all Serial Numbers)			
Knob (black w/white line, 9 mm) (Order Code: 14287)	_____	\$ 3.00	_____
<i>Note: Knob and set screw are sold separately. See 08210-1/8 for set screw.</i>			
Set Screw (Order Code: 08210-1/8)	_____	\$ 0.50	_____
<i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>			
Push-Pot Potentiometer Assembly (dual-section) (Order Code: 32298)	_____	\$ 9.00	_____
<i>Note: Includes push-pot (02171) and sleeve (14297).</i>			
3.5 mm Stereo Jack (Order Code: 01198)	_____	\$ 3.00	_____
Model 5304 Intercom Station (all Serial Numbers)			
Knob – Glow (black w/clear center, 13 mm dia. x 13.8 mm tall) (Order Code: 14340)	_____	\$ 5.00	_____
Rotary Encoder (24-step w/switch, 21 mm overall length) (Order Code: 12109)	_____	\$ 8.00	_____
Pushbutton Switch (momentary, 17 mm x 17 mm) (Order Code: 12106)	_____	\$ 6.00	_____
<i>Note: Includes button cap and lens. See 32649 for replacement button cap and lens kit.</i>			
Button Cap and Lens Kit (includes four each button cap and frosted lens) (Order Code: 32649)	_____	\$24.00	_____
3.5 mm Stereo Jack (Order Code: 01198)	_____	\$ 3.00	_____
Rubber Bumper (black, set of 4, 1/2" dia. by 7/32" tall) (Order Code: 14339)	_____	\$ 6.00	_____
<i>Note: Bumpers and machine screws are sold separately. See 08032-5/16 for screws.</i>			
Machine Screw (SEMS, 4-40x5/16") (Order Code: 08032-5/16)	_____	\$ 0.50	_____
<i>Note: Machine screws and bumpers are sold separately. See 14339 for bumpers.</i>			
Model 5312 Intercom Station (all Serial Numbers)			
Knob – Glow (black w/clear center, 13 mm dia. x 13.8 mm tall) (Order Code: 14340)	_____	\$ 5.00	_____
Rotary Encoder (24-step w/switch, 21 mm overall length) (Order Code: 12109)	_____	\$ 8.00	_____
Pushbutton Switch (momentary, 17 mm x 17 mm) (Order Code: 12106)	_____	\$ 6.00	_____
<i>Note: Includes button cap and lens. See 32649 for replacement button cap and lens kit.</i>			
Button Cap and Lens Kit (includes four each button cap and frosted lens) (Order Code: 32649)	_____	\$24.00	_____
Loudspeaker (37 mm dia., 8 ohm) (Order Code: 10702)	_____	\$22.00	_____
<i>Mfg. No.: Visaton: BF37/2261; Parts Express No.: 292-655</i>			
Set Screw (Order Code: 08210-1/8)	_____	\$ 0.50	_____
<i>Note: For use with microphone bushing.</i>			
Power Supply (universal AC mains input/12 V, 2.5 A (30 watts) output) (Order Code: 10362)	_____	\$32.00	_____
<i>Mfg. No.: Mean Well MFM-30-12; Digi-Key No.: 1866-3418-ND; Mouser No.: 709-MFM30-12</i>			

	Qty	US List	Total
Model 5330 Flex-Use Dante Audio Interface (all Serial Numbers)			
Knob (black w/white line, 9 mm) (Order Code: 14287)	_____	\$ 3.00	_____
<i>Note: Knob and set screw are sold separately. See 08210-1/8 for set screw.</i>			
Set Screw (Order Code: 08210-1/8)	_____	\$ 0.50	_____
<i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>			
Push-Pot Potentiometer Assembly (dual-section) (Order Code: 32298)	_____	\$ 9.00	_____
<i>Note: Includes push-pot (02171) and sleeve (14297).</i>			
1/4" Phone Jack (Order Code: 01084)	_____	\$ 4.00	_____
<i>Note: Nut is required for installation of 1/4" phone jack. See 01090 for nut.</i>			
Nut (plastic) (Order Code: 01090)	_____	\$ 1.50	_____
<i>Note: Nut is required for installation of 1/4" phone jack.</i>			
Power Supply (universal AC mains input/12 V, 1.25 A (15 watts) output) (Order Code: 10354)	_____	\$35.00	_____
<i>Mfg. No.: Cincon CFM1502S; Digi-Key No.: 2034-3555-ND; Mouser No.: 418-CFM1502S</i>			
3.5 mm Stereo Jack (Order Code: 01198)	_____	\$ 3.00	_____
Model 5364 Headset Interface (all Serial Numbers)			
Rubber Bumper (black, set of 4, 1/2" dia. by 7/32" tall) (Order Code: 14339)	_____	\$ 6.00	_____
<i>Note: Bumpers and machine screws are sold separately. See 08032-5/16 for screws.</i>			
Machine Screw (SEMS, 4-40x5/16") (Order Code: 08032-5/16)	_____	\$ 0.50	_____
<i>Note: Machine screws and bumpers are sold separately. See 14339 for bumpers.</i>			
Model 5365 Headset Interface (all Serial Numbers)			
Rubber Bumper (black, set of 4, 1/2" dia. by 7/32" tall) (Order Code: 14339)	_____	\$ 6.00	_____
<i>Note: Bumpers and machine screws are sold separately. See 08032-5/16 for screws.</i>			
Machine Screw (SEMS, 4-40x5/16") (Order Code: 08032-5/16)	_____	\$ 0.50	_____
<i>Note: Machine screws and bumpers are sold separately. See 14339 for bumpers.</i>			
Model 5401 Dante Master Clock (all Serial Numbers)			
Power Supply (universal AC mains input/12 V, 1.25 A (15 watts) output) (Order Code: 10354)	_____	\$35.00	_____
<i>Mfg. No.: Cincon CFM1502S; Digi-Key No.: 2034-3555-ND; Mouser No.: 418-CFM1502S</i>			
Model 5401A Dante Leader Clock (Serial Numbers 00151 – 02200)			
Power Supply (universal AC mains input/12 V, 1.25 A (15 watts) output) (Order Code: 10354)	_____	\$35.00	_____
<i>Mfg. No.: Cincon CFM1502S; Digi-Key No.: 2034-3555-ND; Mouser No.: 418-CFM1502S</i>			
Model 5401A Dante Leader Clock (Serial Numbers 02201 – later)			
Power Supply (universal AC mains input/12 V, 2.5 A (30 watts) output) (Order Code: 10362)	_____	\$32.00	_____
<i>Mfg. No.: Mean Well MFM-30-12; Digi-Key No.: 1866-3418-ND; Mouser No.: 709-MFM30-12</i>			
Model 5402 Dante Leader Clock with GNSS Synchronization (Serial Numbers 00151 – 02100)			
Power Supply (universal AC mains input/12 V, 1.25 A (15 watts) output) (Order Code: 10354)	_____	\$35.00	_____
<i>Mfg. No.: Cincon CFM1502S; Digi-Key No.: 2034-3555-ND; Mouser No.: 418-CFM1502S</i>			
GNSS Antenna (Order Code: ANT-GNSS-01)	_____	\$92.00	_____
<i>Mfg. No.: U-Blox ANN-MB-00-00; Digi-Key No.: 672-ANN-MB-00-00-ND</i>			
Model 5402 Dante Leader Clock with GNSS Synchronization (Serial Numbers 02101 – later)			
Power Supply (universal AC mains input/12 V, 2.5 A (30 watts) output) (Order Code: 10362)	_____	\$32.00	_____
<i>Mfg. No.: Mean Well MFM-30-12; Digi-Key No.: 1866-3418-ND; Mouser No.: 709-MFM30-12</i>			
GNSS Antenna (Order Code: ANT-GNSS-01)	_____	\$92.00	_____
<i>Mfg. No.: U-Blox ANN-MB-00-00; Digi-Key No.: 672-ANN-MB-00-00-ND</i>			
Model 5412-Series Audio Interfaces (Serial Numbers 00151 – 01100)			
Power Supply (universal AC mains input/12 V, 1.8 A (20 watts) output) (Order Code: 10355)	_____	\$32.00	_____
<i>Mfg. No.: Cincon CFM2002S; Digi-Key No.: 2034-3589-ND; Mouser No.: 418-CFM2002S</i>			
Model 5412-Series Audio Interfaces (Serial Numbers 01101 – later)			
Power Supply (universal AC mains input/12 V, 2.5 A (30 watts) output) (Order Code: 10362)	_____	\$32.00	_____
<i>Mfg. No.: Mean Well MFM-30-12; Digi-Key No.: 1866-3418-ND; Mouser No.: 709-MFM30-12</i>			

	Qty	US List	Total
Model 5414 Mic/Line Input & Line Output Interface			
Knob (black w/white line, 9 mm) (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 08210-1/8 for set screw.</i>	_____	\$ 3.00	_____
Set Screw (Order Code: 08210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
Pushbutton Switch (momentary) – Channel Select (Order Code: 12056)	_____	\$ 4.00	_____
Pushbutton Cap (gray) (Order Code: 14207)	_____	\$ 3.00	_____
1/4" Phone Jack (Order Code: 01084) <i>Note: Nut is required for installation of 1/4" phone jack. See 01090 for nut.</i>	_____	\$ 4.00	_____
Nut (plastic) (Order Code: 01090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
Power Supply (universal AC mains input/12 V, 1.25 A (15 watts) output) (Order Code: 10354) <i>Mfg. No.: Cincon CFM1502S; Digi-Key No.: 2034-3555-ND; Mouser No.: 418-CFM1502S</i>	_____	\$35.00	_____
For Serial Numbers 00151-01150			
Push-Pot Potentiometer Assembly (dual-section) (Order Code: 32298) <i>Note: Includes push-pot (02171) and sleeve (14297).</i>	_____	\$ 9.00	_____
For Serial Numbers 01151-later			
Push-Pot Potentiometer Assembly (single-section) (Order Code: 32299) <i>Note: Includes push-pot (02172) and sleeve (14297).</i>	_____	\$ 9.00	_____
MD-4 Mic/Line Input & Line Output Interface (all Serial Numbers)			
Knob (black w/white line, 9 mm) (Order Code: 14287) <i>Note: Knob and set screw are sold separately. See 08210-1/8 for set screw.</i>	_____	\$ 3.00	_____
Set Screw (Order Code: 08210-1/8) <i>Note: Set screw and knob are sold separately. See 14287 for knob.</i>	_____	\$ 0.50	_____
Push-Pot Potentiometer Assembly (single-section) (Order Code: 32299) <i>Note: Includes push-pot (02172) and sleeve (14297).</i>	_____	\$ 9.00	_____
Pushbutton Switch (momentary) – Channel Select (Order Code: 12056)	_____	\$ 4.00	_____
Pushbutton Cap (gray) (Order Code: 14207)	_____	\$ 3.00	_____
1/4" Phone Jack (Order Code: 01084) <i>Note: Nut is required for installation of 1/4" phone jack. See 01090 for nut.</i>	_____	\$ 4.00	_____
Nut (plastic) (Order Code: 01090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
Power Supply (universal AC mains input/12 V, 1.25 A (15 watts) output) (Order Code: 10354) <i>Mfg. No.: Cincon CFM1502S; Digi-Key No.: 2034-3555-ND; Mouser No.: 418-CFM1502S</i>	_____	\$35.00	_____
Model 5418 Mic/Line Interface (Serial Numbers 00151 – 00500)			
Pushbutton Cap (gray) (Order Code: 14207)	_____	\$ 3.00	_____
1/4" Phone Jack (Order Code: 01084) <i>Note: Nut is required for installation of 1/4" phone jack. See 01090 for nut.</i>	_____	\$ 4.00	_____
Nut (plastic) (Order Code: 01090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
Power Supply (universal AC mains input/12 V, 1.8 A (20 watts) output) (Order Code: 10355) <i>Mfg. No.: Cincon CFM2002S; Digi-Key No.: 2034-3589-ND; Mouser No.: 418-CFM2002S</i>	_____	\$32.00	_____
Model 5418 Mic/Line Interface (Serial Numbers 00501 – later)			
Pushbutton Cap (gray) (Order Code: 14207)	_____	\$ 3.00	_____
1/4" Phone Jack (Order Code: 01084) <i>Note: Nut is required for installation of 1/4" phone jack. See 01090 for nut.</i>	_____	\$ 4.00	_____
Nut (plastic) (Order Code: 01090) <i>Note: Nut is required for installation of 1/4" phone jack.</i>	_____	\$ 1.50	_____
Power Supply (universal AC mains input/12 V, 2.5 A (30 watts) output) (Order Code: 10362) <i>Mfg. No.: Mean Well MFM-30-12; Digi-Key No.: 1866-3418-ND; Mouser No.: 709-MFM30-12</i>	_____	\$32.00	_____
Model 5421 Dante Intercom Audio Engine (all Serial Numbers)			
Screw-On Bumper Kit (black, set of 8) (Order Code: 31064)	_____	\$10.00	_____
Model 5421A Dante Intercom Audio Engine (all Serial Numbers)			
Screw-On Bumper Kit (black, set of 8) (Order Code: 31064)	_____	\$10.00	_____

	Qty	US List	Total
Model 5422-Series Dante Audio Intercom Engines (all Serial Numbers)			
Power Supply (universal AC mains input/12 V, 1.25 A (15 watts) output) (Order Code: 10354) Mfg. No.: Cincon CFM1502S; Digi-Key No.: 2034-3555-ND; Mouser No.: 418-CFM1502S	_____	\$35.00	_____
Model 5422A-Series Dante Audio Intercom Engines (Serial Numbers 00151 – 01400)			
Power Supply (universal AC mains input/12 V, 1.25 A (15 watts) output) (Order Code: 10354) Mfg. No.: Cincon CFM1502S; Digi-Key No.: 2034-3555-ND; Mouser No.: 418-CFM1502S	_____	\$35.00	_____
Model 5422A-Series Dante Audio Intercom Engines (Serial Numbers 01401 – later)			
Power Supply (universal AC mains input/12 V, 2.5 A (30 watts) output) (Order Code: 10362) Mfg. No.: Mean Well MFM-30-12; Digi-Key No.: 1866-3418-ND; Mouser No.: 709-MFM30-12	_____	\$32.00	_____
Model 5482-Series Dante Bridges (Serial Numbers 00151 – 00400)			
Power Supply (universal AC mains input/12 V, 1.25 A (15 watts) output) (Order Code: 10354) Mfg. No.: Cincon CFM1502S; Digi-Key No.: 2034-3555-ND; Mouser No.: 418-CFM1502S	_____	\$35.00	_____
Model 5482-Series Dante Bridges (Serial Numbers 00401 – later)			
Power Supply (universal AC mains input/12 V, 2.5 A (30 watts) output) (Order Code: 10362) Mfg. No.: Mean Well MFM-30-12; Digi-Key No.: 1866-3418-ND; Mouser No.: 709-MFM30-12	_____	\$32.00	_____
Model 5512-Series Audio Interfaces (all Serial Numbers)			
Power Supply (universal AC mains input/12 V, 1.8 A (20 watts) output) (Order Code: 10355) Mfg. No.: Cincon CFM2002S; Digi-Key No.: 2034-3589-ND; Mouser No.: 418-CFM2002S	_____	\$32.00	_____
Model 5512A-Series Audio Interfaces (Serial Numbers 00151 – 00500)			
Power Supply (universal AC mains input/12 V, 1.8 A (20 watts) output) (Order Code: 10355) Mfg. No.: Cincon CFM2002S; Digi-Key No.: 2034-3589-ND; Mouser No.: 418-CFM2002S	_____	\$32.00	_____
Model 5512A-Series Audio Interfaces (Serial Numbers 00501 – later)			
Power Supply (universal AC mains input/12 V, 2.5 A (30 watts) output) (Order Code: 10362) Mfg. No.: Mean Well MFM-30-12; Digi-Key No.: 1866-3418-ND; Mouser No.: 709-MFM30-12	_____	\$32.00	_____
Model 5518 Mic/Line Interface (Serial Numbers 00151 – 00500)			
Pushbutton Cap (gray) (Order Code: 14207)	_____	\$ 3.00	_____
1/4" Phone Jack (Order Code: 01084)	_____	\$ 4.00	_____
Note: Nut is required for installation of 1/4" phone jack. See 01090 for nut.			
Nut (plastic) (Order Code: 01090)	_____	\$ 1.50	_____
Note: Nut is required for installation of 1/4" phone jack.			
Power Supply (universal AC mains input/12 V, 1.8 A (20 watts) output) (Order Code: 10355) Mfg. No.: Cincon CFM2002S; Digi-Key No.: 2034-3589-ND; Mouser No.: 418-CFM2002S	_____	\$32.00	_____
Model 5518 Mic/Line Interface (Serial Numbers 00501 – later)			
Pushbutton Cap (gray) (Order Code: 14207)	_____	\$ 3.00	_____
1/4" Phone Jack (Order Code: 01084)	_____	\$ 4.00	_____
Note: Nut is required for installation of 1/4" phone jack. See 01090 for nut.			
Nut (plastic) (Order Code: 01090)	_____	\$ 1.50	_____
Note: Nut is required for installation of 1/4" phone jack.			
Power Supply (universal AC mains input/12 V, 2.5 A (30 watts) output) (Order Code: 10362) Mfg. No.: Mean Well MFM-30-12; Digi-Key No.: 1866-3418-ND; Mouser No.: 709-MFM30-12	_____	\$32.00	_____
Model 5518A Mic/Line Interface (all Serial Numbers)			
Pushbutton Cap (gray) (Order Code: 14207)	_____	\$ 3.00	_____
1/4" Phone Jack (Order Code: 01084)	_____	\$ 4.00	_____
Note: Nut is required for installation of 1/4" phone jack. See 01090 for nut.			
Nut (plastic) (Order Code: 01090)	_____	\$ 1.50	_____
Note: Nut is required for installation of 1/4" phone jack.			
Power Supply (universal AC mains input/12 V, 2.5 A (30 watts) output) (Order Code: 10362) Mfg. No.: Mean Well MFM-30-12; Digi-Key No.: 1866-3418-ND; Mouser No.: 709-MFM30-12	_____	\$32.00	_____

	Qty	US List	Total
Model 5532, Model 5534, and Model 5536 Announcer's Consoles			
Pushbutton Switch (momentary) (Order Code: 12106)	_____	\$ 8.00	_____
<i>Note: Does not include button cap. See 32670 for replacement button cap kit.</i>			
Button Cap Kit (includes four 12112 button caps, 17.3 mm square) (Order Code: 32670)	_____	\$32.00	_____
1/4" Phone Jack (Order Code: 01084)	_____	\$ 4.00	_____
<i>Note: Nut is required for installation of 1/4" phone jack. See 01090 for nut.</i>			
Nut (plastic) (Order Code: 01090) <i>Note: For use with 1/4" phone jack.</i>	_____	\$ 1.50	_____
Self-Adhesive Rubber Bumpons (black, set of 4, 1/2" dia. by 1/4" tall) (Order Code: 14326)	_____	\$ 3.00	_____
Blank Plate – XLR (black) (Order Code: 01073)	_____	\$ 3.00	_____
Knob – Glow (black w/clear center, 13 mm dia. x 13.8 mm tall) (Order Code: 14340)	_____	\$ 5.00	_____
Rotary Encoder (24-step w/switch, 21 mm overall length) (Order Code: 12109)	_____	\$ 8.00	_____
Model 5682-Series ST 2110 to Dante Bridges (All Serial Numbers)			
Power Supply (universal AC mains input/12 V, 2.5 A (30 watts) output) (Order Code: 10362)	_____	\$32.00	_____
<i>Mfg. No.: Mean Well MFM-30-12; Digi-Key No.: 1866-3418-ND; Mouser No.: 709-MFM30-12</i>			

	Qty	US List	Total
Live-Link Sr. Remote Camera Interface Systems (all Serial Numbers)			
Live-Link Sr. Portable Cover Assembly for Anton-Bauer Battery (Order Code: LL-COVER-01) <i>Note: Consists of portable cover (31341) with lifting handle (32204), Anton-Bauer Bracket Kit (31414), and bumpers (32297) installed.</i>	_____	\$303.00	_____
Portable Cover (Order Code: 31341) <i>Note: Does not include lifting handle, battery bracket, bumpers, or hardware.</i>	_____	\$150.00	_____
Lifting Handle Kit (black lifting handle and set of 6 6-32x1/4" screws) (Order Code: 32204)	_____	\$ 26.00	_____
Anton-Bauer Battery Bracket Kit (battery bracket w/insulator and 15" cable assembly) (Order Code: 31414)	_____	\$115.00	_____
Back of Cover Bumper Kit (set of 4 each 3/4" dia. by 5/8" tall bumpers, 10-24x3/4" screws, and 10-24 nylock nuts) (Order Code: 32297) <i>Note: Used for back of portable enclosure.</i>	_____	\$ 12.00	_____
Live-Link Sr. Cover for Special Installations (Order Code: LL-COVER-02) <i>Note: Consists only of protective cover (31351) with no provision for attaching lifting handle, battery bracket, or bumpers.</i>	_____	\$150.00	_____
Live-Link Sr. Portable Cover Assembly for V-Mount Battery (Order Code: LL-COVER-03) <i>Note: Consists of portable cover (modified 31341) with lifting handle (32204), V-Mount Bracket (14301), and bumpers (32297) installed.</i>	_____	\$303.00	_____
Chassis Bumper Kit (set of 4 each 1.5" dia. by 3/4" tall bumpers, 80918-.708 screws, and 1/4-20 Keps nuts) (Order Code: 32203) <i>Note: Used for bottom of portable enclosure.</i>	_____	\$ 16.00	_____
12 Vdc, 5 A Power Supply (output terminated onto 4-pin female XLR connector) (Order Code: PS-DC-01)	_____	\$110.00	_____
Audio Cable (XLR5M to XLR3F/XLR3M) (Order Code: 13662)	_____	\$ 42.00	_____
10/100/1000 Ethernet Media Converter Upgrade Kit (Order Code: M432-KIT)	_____	\$240.00	_____
Live-Link Jr. Remote Camera Interface Systems (all Serial Numbers)			
Pushbutton Switch (momentary) – Auto Null (Order Code: 12056)	_____	\$ 4.00	_____
Pushbutton Cap – Truck End Auto Null (gray) (Order Code: 14207)	_____	\$ 3.00	_____
Chassis Bumper Kit (set of 4 each 3/4" dia. by 3/8" tall bumpers and 6-32x3/8" screws) (Order Code: 32202) <i>Note: Used for bottom of portable enclosure.</i>	_____	\$ 12.00	_____
Lifting Handle Kit (black lifting handle and set of 6 6-32x1/4" screws) (Order Code: 32204)	_____	\$ 26.00	_____
12 Vdc, 1.55 A Power Supply (output terminated onto 4-pin female XLR connector) (Order Code: PS-DC-02)	_____	\$ 88.00	_____
Live-Link Mini Remote Camera Interface Systems (all Serial Numbers)			
Pushbutton Switch (momentary) – Auto Null (Order Code: 12056)	_____	\$ 4.00	_____
Pushbutton Cap – Camera End and Truck End Auto Null (gray) (Order Code: 14207)	_____	\$ 3.00	_____
Chassis Bumper Kit (set of 4 each 5/8" dia. by 3/4" tall bumpers and 6-32x5/8" screws) (Order Code: 32205) <i>Note: Used for bottom of portable enclosure.</i>	_____	\$ 12.00	_____
Lifting Handle Kit (black lifting handle and set of 6 6-32x1/4" screws) (Order Code: 32204)	_____	\$ 26.00	_____
12 Vdc, 1.55 A Power Supply (output terminated onto 4-pin female XLR connector) (Order Code: PS-DC-02)	_____	\$ 88.00	_____
Audio Cable (XLR5F to Dual XLR3M) (Order Code: 13684)	_____	\$ 42.00	_____

	Qty	US List	Total
Live-Link Miscellaneous Parts (contact factory for part identification assistance)			
BNC-BNC Bulkhead Connector (with nut and lockwasher) (Order Code: 01243)		\$ 10.00	
ST-ST Optical Barrel Connector (with nut and lockwasher) (Order Code: 01260)		\$ 6.00	
SFP Optical Module (video, transceiver) (Order Code: 06406)		\$184.00	
<i>Note: 1310 nm FP Laser; MSA, supports 3G SDI video. Mfg. No.: Eoptolink EOLS-1330-10D.</i>			
SFP Optical Module (video, transceiver) (Order Code: 06412)		\$290.00	
<i>Note: 1550 nm CWDM Laser; MSA, supports 3G SDI video. Mfg. No.: Eoptolink EOLS-1630-18D0.</i>			
SFP Optical Module (video, single-channel receiver) (Order Code: 06411)		\$156.00	
<i>Note: Non-MSA, supports 3G SDI video. Mfg. No.: Eoptolink EOLS-30R-DN.</i>			
SFP Optical Module (video, single-channel transmitter) (Order Code: 06413)		\$210.00	
<i>Note: 1530 nm CWDM Laser; non-MSA, supports 3G SDI video. Mfg. No.: Eoptolink EOLS-1630T-DNN.</i>			
SFP Optical Module (Ethernet, transceiver) (Order Code: 06418)		\$ 85.00	
<i>Note: 1490 nm CWDM laser, MSA, supports 10/100/1000 Ethernet. Mfg. No.: ATOP APSC49123CXL40.</i>			
Optical Multiplexer ("mux") (3 inputs/1 output) (Order Code: 10826)		\$ 70.00	
<i>Note: 1310, 1490, and 1550 nm inputs use LC optical connectors; output uses ST optical connector.</i>			
Optical Demultiplexer ("demux") (1 input/3 outputs) (Order Code: 10827)		\$ 95.00	
<i>Note: Input uses ST optical connector; 1310, 1490, and 1550 nm outputs use LC optical connectors.</i>			
Optical Multiplexer ("mux") (3 inputs/1 output) (Order Code: 10833)		\$ 70.00	
<i>Note: 1310, 1490, and 1550 nm inputs use LC connectors; output uses LC optical connector.</i>			
Optical Demultiplexer ("demux") (1 input/3 outputs) (Order Code: 10834)		\$ 95.00	
<i>Note: Input uses LC optical connector; 1310, 1490, and 1550 nm outputs use LC optical connectors.</i>			
Optical Multiplexer ("mux") (4 inputs/1 output) (Order Code: 10831)		\$105.00	
<i>Note: 1310, 1490, 1530, and 1550 nm inputs use LC optical connectors; output uses ST optical connector.</i>			
Optical Demultiplexer ("demux") (1 input/4 outputs) (Order Code: 10832)		\$120.00	
<i>Note: Input uses ST optical connector; 1310, 1490, 1530, and 1550 nm outputs use LC optical connectors.</i>			
Optical Demultiplexer ("demux") (1 input/6 outputs) (Order Code: 10853)		\$160.00	
<i>Note: Input uses ST optical connector; 1310, 1470, 1490, 1510, 1530, and 1550 nm outputs use LC optical connectors.</i>			
Optical Jumper Cable (single-mode, length 280 mm overall) (Order Code: 010845)		\$ 9.00	
<i>Note: LC optical connectors on both ends.</i>			
Optical Jumper Cable (single-mode, length 300 mm overall) (Order Code: 010846)		\$ 9.00	
<i>Note: LC optical connector on one end, ST optical connector on other end.</i>			
Miscellaneous Parts			
Knob (black w/white line, 9 mm) (Order Code: 14287)		\$ 3.00	
<i>Note: Knob and set screw are sold separately. See 08210-1/8 for set screw.</i>			
Knob (blue w/no line, 9 mm) (Order Code: 14310)		\$ 3.00	
<i>Note: Knob and set screw are sold separately. See 08210-1/8 for set screw.</i>			
Knob (green w/no line, 9 mm) (Order Code: 14311)		\$ 3.00	
<i>Note: Knob and set screw are sold separately. See 08210-1/8 for set screw.</i>			
Knob (gold w/no line, 9 mm) (Order Code: 14312)		\$ 3.00	
<i>Note: Knob and set screw are sold separately. See 08210-1/8 for set screw.</i>			
Set Screw (Order Code: 08210-1/8)		\$ 0.50	
<i>Note: Set screw and knob are sold separately.</i>			

Notes:

Prices effective August 28, 2025. Subject to change without notice. All shipments FOB Skokie, IL 60077 USA.